

GROUP 42

BODY

CONTENTS

BODY MOUNTING	42-4	WINDOW GLASS	42-11
REMOVAL AND INSTALLATION	42-4	GENERAL INFORMATION	42-11
HOOD	42-5	WINDSHIELD	42-13
BODY DIAGNOSIS	42-5	REMOVAL AND INSTALLATION	42-13
INTRODUCTION TO HOOD DIAGNOSIS	42-5	QUARTER WINDOW GLASS	42-16
HOOD DIAGNOSTIC TROUBLESHOOTING		REMOVAL AND INSTALLATION	42-16
STRATEGY	42-5	LIFTGATE WINDOW GLASS	42-18
SYMPTOM CHART	42-5	REMOVAL AND INSTALLATION	42-18
SYMPTOM PROCEDURES	42-5	DOOR	42-20
HOOD	42-7	GENERAL DESCRIPTION	42-20
REMOVAL AND INSTALLATION	42-7	CENTRAL DOOR LOCKING SYSTEM	
INSPECTION	42-8	DIAGNOSIS	42-20
FENDER	42-8	INTRODUCTION TO CENTRAL DOOR	
REMOVAL AND INSTALLATION	42-8	LOCKING SYSTEM DIAGNOSIS	42-20
FUEL FILLER LID	42-9	CENTRAL DOOR LOCKING SYSTEM	
REMOVAL AND INSTALLATION	42-9	TROUBLESHOOTING STRATEGY	42-20
WINDOW GLASS	42-10	TROUBLE SYMPTOM CHART	42-20
WINDOW GLASS DIAGNOSIS ...	42-10	SYMPTOM PROCEDURES	42-21
INTRODUCTION TO WINDOW GLASS		POWER WINDOW DIAGNOSIS ...	42-75
DIAGNOSIS	42-10	INTRODUCTION TO POWER WINDOWS	
WINDOW GLASS DIAGNOSTIC		DIAGNOSIS	42-75
TROUBLESHOOTING STRATEGY ...	42-10	POWER WINDOWS DIAGNOSTIC	
SYMPTOM CHART	42-10	TROUBLESHOOTING STRATEGY	42-75
SYMPTOM PROCEDURES	42-10	SYMPTOM CHART	42-75
SPECIAL TOOL	42-11	SYMPTOM PROCEDURES	42-76

Continued on next page

DOOR DIAGNOSIS	42-94	DOOR HANDLE AND LATCH	42-111
INTRODUCTION TO GLASS AND		REMOVAL AND INSTALLATION.....	42-111
DOOR DIAGNOSIS	42-94	INSPECTION	42-113
GLASS AND DOOR DIAGNOSTIC		WINDOW GLASS RUNCHANNEL	
TROUBLESHOOTING STRATEGY ...	42-94	AND DOOR OPENING	
SYMPTOM CHART	42-94	WEATHER-STRIP	42-116
SYMPTOM PROCEDURES	42-94	REMOVAL AND INSTALLATION	42-116
HOW TO LOCATE WIND NOISES	42-97	LIFTGATE	42-117
SPECIAL TOOLS	42-99	LIFTGATE DIAGNOSIS	42-117
ON-VEHICLE SERVICE	42-100	INTRODUCTION TO LIFTGATE	
DOOR FIT ADJUSTMENT.....	42-100	DIAGNOSIS	42-117
DOOR WINDOW GLASS ADJUSTMENT	42-100	LIFTGATE DIAGNOSTIC	
ADJUSTMENT AND REPLACEMENT		TROUBLESHOOTING STRATEGY....	42-117
WHEN THERE IS A MALFUNCTION OF		SYMPTOM CHART	42-117
THE POWER WINDOWS	42-101	SYMPTOM PROCEDURES.....	42-117
DOOR OUTSIDE HANDLE PLAY CHECK	42-101	SPECIAL TOOL	42-118
POWER WINDOW OPERATING		ON-VEHICLE SERVICE	42-119
CURRENT CHECK	42-102	LIFTGATE FIT ADJUSTMENT.....	42-119
CIRCUIT BREAKER (INCORPORATED		LIFTGATE HANDLE PLAY CHECK....	42-119
IN THE POWER WINDOW MOTOR)		LIFTGATE	42-120
CHECK	42-102	REMOVAL AND INSTALLATION.....	42-120
DOOR INSIDE HANDLE PLAY CHECK		LIFTGATE TRIM AND WATERPROOF	
AND ADJUSTMENT	42-102	FILM	42-122
DOOR ASSEMBLY	42-103	REMOVAL AND INSTALLATION.....	42-122
REMOVAL AND INSTALLATION	42-103	LIFTGATE HANDLE AND LATCH	42-123
INSPECTION.....	42-104	REMOVAL AND INSTALLATION.....	42-123
DOOR TRIM AND WATERPROOF		INSPECTION	42-124
FILM	42-105		
REMOVAL AND INSTALLATION	42-105		
INSPECTION.....	42-107		
DOOR GLASS AND REGULATOR	42-108		
REMOVAL AND INSTALLATION	42-108		
INSPECTION.....	42-110		


Continued on next page

KEYLESS ENTRY SYSTEM . . .	42-125	INTRODUCTION TO SUNROOF DIAGNOSIS	42-136
GENERAL INFORMATION	42-125	SUNROOF DIAGNOSTIC TROUBLESHOOTING STRATEGY	42-136
KEYLESS ENTRY SYSTEM DIAGNOSIS	42-125	SYMPTOM CHART	42-137
INTRODUCTION TO KEYLESS ENTRY SYSTEM DIAGNOSIS	42-125	SYMPTOM PROCEDURES	42-137
KEYLESS ENTRY SYSTEM DIAGNOSTIC TROUBLESHOOTING STRATEGY . . .	42-125	CHECKING AT THE SUNROOF-ECU . .	42-151
SYMPTOM CHART	42-126		
SYMPTOM PROCEDURES	42-126		
MEASUREMENT AT THE RECEIVER TERMINALS	42-131		
SPECIAL TOOLS	42-132	SPECIAL TOOLS	42-151
ON-VEHICLE SERVICE	42-132	ON-VEHICLE SERVICE	42-152
HOW TO REPLACE THE TRANSMITTER BATTERY	42-132	WATER TEST	42-152
SECRET CODE REGISTRATION METHOD	42-132	SUNROOF FIT ADJUSTMENT	42-152
ETACS-ECU FUNCTION ADJUSTMENT PROCEDURE	42-134	OPERATION CHECK	42-153
KEYLESS ENTRY SYSTEM	42-135	SUNROOF ASSEMBLY	42-157
REMOVAL AND INSTALLATION	42-135	REMOVAL AND INSTALLATION	42-157
INSPECTION	42-136	INSPECTION	42-163
SUNROOF ASSEMBLY	42-136	SUNROOF MOTOR CHECK	42-163
GENERAL INFORMATION	42-136	SUNROOF SWITCH CONTINUITY CHECK	42-163
SUNROOF DIAGNOSIS	42-136	UNDER COVER	42-164
		REMOVAL AND INSTALLATION	42-164
		SPECIFICATIONS	42-165
		FASTENER TIGHTENING SPECIFICATIONS	42-165
		SERVICE SPECIFICATIONS	42-166
		SEALANTS AND ADHESIVES . . .	42-166


BODY MOUNTING

REMOVAL AND INSTALLATION

M1421003700069



AC003757AB



1. MOUNTING BOLT
2. PLAIN WASHER
3. BODY MOUNTING RUBBER
4. BODY MOUNTING RUBBER A
5. SPACER

6. BODY MOUNTING RUBBER B
7. BODY MOUNT WASHER
8. BODY MOUNT STOPPER
9. SELF JAM NUT

HOOD

BODY DIAGNOSIS

INTRODUCTION TO HOOD DIAGNOSIS

Wind noise at the hood may be caused by improper hood adjustment.

M1421005800299

HOOD DIAGNOSTIC TROUBLESHOOTING STRATEGY

M1421005900263

Use these steps to plan your diagnostic strategy. If you follow them carefully, you will be sure that you have exhausted most of the possible ways to find a hood fault.

1. Gather information from the customer.
2. Verify that the condition described by the customer exists.
3. Find the malfunction by following the Symptom Chart.
4. Verify that the malfunction is eliminated.

SYMPTOM CHART

M1421006000241

SYMPTOM	INSPECTION PROCEDURE	REFERENCE PAGE
Difficult locking and unlocking	1	P.42-5
Uneven body clearance	2	P.42-6
Uneven height	3	P.42-6

SYMPTOM PROCEDURES

INSPECTION PROCEDURE 1: Difficult Locking and Unlocking

DIAGNOSIS

STEP 1. Check the release cable routing condition.

Q: Is the release cable routing condition good?

YES : Go to Step 2.

NO : Repair release cable, then go to Step 4.

STEP 2. Check the engagement of the hood latch and hood striker.

Q: Are the hood latch and hood striker engaged correctly?

YES : Go to Step 3.

NO : Adjust hoodlatch and hood striker. Refer to P.42-7. Then go to Step 4.

STEP 3. Check for proper lubrication of release cable.

Q: Is the release cable properly lubricated?

YES : Go to Step 4.

NO : Lubricate, then go to Step 4.

STEP 4. Retest the system.

Q: Does the hood lock operate easily?

YES : The procedure is complete.

NO : Return to Step 1.

INSPECTION PROCEDURE 2: Uneven Body Clearance

DIAGNOSIS

STEP 1. Check the hood installation condition.**Q: Is the hood installation in good condition?****YES :** Go to Step 2.**NO :** Adjust hood latch and hood striker. Refer to [P.42-7](#). Then go to Step 2.

STEP 2. Retest the system.**Q: Is the clearance with the body even?****YES :** The procedure is complete.**NO :** Return to Step 1.

INSPECTION PROCEDURE 3 : Uneven Height

DIAGNOSIS




STEP 1. Check the hood bumper height.**Q: Is the hood bumper height proper?****YES :** Go to Step 2.**NO :** Adjust hood bumper height. Refer to [P.42-7](#). Then go to Step2.

STEP 2. Retest the system.**Q: Are the hood and body height even?****YES :** The procedure is complete.**NO :** Return to Step 1.



HOOD

REMOVAL AND INSTALLATION

M1421001600185



AC003758AB




1. HOOD LOCK RELEASE HANDLE
 2. HOOD BUMPER
 3. HOOD BUMPER
 4. HOOD DAMPER
 5. HOOD SIDE WEATHERSTRIP
 6. HOOD WEATHERSTRIP
 7. FRONT HOOD WEATHERSTRIP
 8. HOOD SUPPORT ROD
 9. HOOD SWITCH <VEHICLES WITH THEFT-ALARM SYSTEM>
- HOOD AND HOOD HINGE REMOVAL STEPS**
- WASHER HOSE CONNECTION
10. HOOD

- HOOD AND HOOD HINGE REMOVAL STEPS (Continued)**
- FRONT DECK GARNISH (REFER TO GROUP 51, WINDSHIELD WIPER AND WASHER P.51-16.)
11. HOOD HINGE
- HOOD LATCH AND HOOD LOCK RELEASE CABLE REMOVAL STEPS**
- RADIATOR GRILL
12. HOOD LATCH
 13. CABLE PROTECTOR
 - JUNCTION BLOCK
 14. HOOD LOCK RELEASE CABLE

INSPECTION

M1421001700171

HOOD SWITCH CONTINUITY CHECK <VEHICLES
WITH THEFT-ALARM SYSTEM>



SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
Hood switch unpressed	1 – 2	Less than 2 ohms
Hood switch depressed	1 – 2	Open circuit


FENDER

REMOVAL AND INSTALLATION

M1421001900186

Pre-removal and Post-installation Operation

- Front Bumper Removal and Installation (Refer to GROUP 51, Front Bumper [P.51-2.](#))
- Front Deck Garnish Removal and Installation (Refer to GROUP 51, Windshield Wiper and Washer [P.51-16.](#))
- Headlight Removal and Installation (Refer to GROUP 54, Lighting System [P.54-137.](#))
- Wide Fender Removal and Installation (Refer to GROUP 51, Wide Fender [P.51-10.](#))



REMOVAL STEPS

1. MUD GUARD
2. SPLASH SHIELD
3. FENDER




FUEL FILLER LID

REMOVAL AND INSTALLATION

M1421002500192

Pre-removal and Post-installation Operation

- Driver's Seat and Rear Seat Removal and Installation (Refer to GROUP 52A, Front Seat P.52A-39 and Rear Seat P.52A-44.)
- Quarter Trim Lower Removal and Installation (Refer to GROUP 52A, Trims P.52A-36.)



REMOVAL STEPS

1. FUEL FILLER DOOR PANEL ASSEMBLY
2. FUEL FILLER DOOR HOOK ASSEMBLY

REMOVAL STEPS (Continued)

3. LID LOCK RELEASE HANDLE
4. FUEL FILLER DOOR LOCK RELEASE CABLE

WINDOW GLASS

WINDOW GLASS DIAGNOSIS

INTRODUCTION TO WINDOW GLASS DIAGNOSIS

M1422006700209

If water leaks from the windshield, the quarter window glass, the liftgate glass, or the seal or body flange may be faulty.

WINDOW GLASS DIAGNOSTIC TROUBLESHOOTING STRATEGY

M1422006800206

Use these steps to plan your diagnostic strategy. If you follow them carefully, you will be sure that you have exhausted most of the possible ways to find a window glass fault.

1. Gather information from the customer.

2. Verify that the condition described by the customer exists.

3. Find the malfunction by following the Symptom Chart.

4. Verify that the malfunction is eliminated.

SYMPTOM CHART

M1422006900214

SYMPTOM	INSPECTION PROCEDURE	REFERENCE PAGE
Water leak through windshield	1	P.42-10
Water leak through quarter window glass		
Water leak through back glass		

SYMPTOM PROCEDURES

INSPECTION PROCEDURE 1: Water Leak Through Windshield/Water Leak Through Quarter Window Glass/Water Leak Through Liftgate Glass

DIAGNOSIS

STEP 1. Check if the seal is faulty.

Q: Is the seal faulty?

YES : Repair the seal, then go to Step 3.

NO : Go to Step 2.

STEP 2. Check if the body flange is deformed.

Q: Is the body flange deformed?

YES : Repair the body flange, then go to Step 3.

NO : Go to Step 3.

STEP 3. Retest the system.


Q: Is any water leaking?

YES : Return to Step 1.

NO : This procedure is complete.

SPECIAL TOOL

M1422000600204

TOOL	TOOL NUMBER AND NAME	SUPERSESSION	APPLICATION
 MB990480	MB990480 Glass holder	General service tool	Removal and installation of window glass

WINDOW GLASS


GENERAL INFORMATION

M1422000100243

The windshield, quarter window and liftgate glass are attached by an urethane-base adhesive to the window frame. This adhesive provides improved glass holding and sealing, and also permits use of body openings having a greater structural strength.

ITEM	APPLICATION	QUANTITY
Wire (dia. × length)	For cutting adhesive	Five pieces of wire 0.6 mm × 1 m (0.02 in × 3.3 ft)
Sealant gun	For adhesive application	One
Wiping shop towels	–	As required
Sealer	For prevention of water leaks and gathering after adhesive application	As required
3M™ AAD Part No. 8880 or equivalent	For cleaning	As required
Glass holder MB990480	–	2
Windshield molding (service part)	–	1
Dam (service part)	–	As required
Tectyl 506T (Valvoline oil company)	–	As required

WINDOW GLASS INSTALLATION



AC006000AB




WINDSHIELD

REMOVAL AND INSTALLATION

M1422001000186

Pre-removal and Post-installation Operation

- Front Deck Garnish Removal and Installation (Refer to GROUP 51, Windshield Wiper and Washer [P.51-16.](#))
- Front Pillar Trim Removal and Installation (Refer to GROUP 52A, Trims [P.52A-36.](#))
- Headlining Removal and Installation (Refer to GROUP 52A, Headlining [P.52A-37.](#))



REMOVAL STEPS

- <<A>> >>A<<
1. WINDSHIELD
 2. WINDSHIELD MOLDING
 3. WINDOW SPACER
 4. GLASS STOPPER
 - >>A<< 5. DUAL LOCK FASTENER

Required Special Tools:

- MB990449: Window Molding Remover
- MB990480: Glass Holder

REMOVAL SERVICE POINT


<<A>> WINDSHIELD REMOVAL

1. To protect the body (paint surface), apply cloth tape to all body areas around the installed windshield.
2. Make mating marks on the windshield and body.
3. Using a sharp-point drill, make a hole in the windshield adhesive.
4. Pass the piano wire from the inside of the vehicle through the hole.


⚠ CAUTION

Do not let the piano wire touch the edge of the windshield.

5. Pull the piano wire alternately from the inside and outside along the windshield to cut the adhesive.



ACX00474 AB



ACX00475 AB

6. Use special tool MB990480 to remove the windshield.

⚠ CAUTION

- Be careful not to remove more adhesive than is necessary.
- Be careful also not to damage the paintwork on the body surface with the knife. If the paintwork is damaged, repair the damaged area with repair paint or anti-rust agent.

7. Use a knife to cut away the remaining adhesive so that the thickness is within 2 mm (0.08 inch) around the entire circumference of the body flange.


8. Finish the flange surfaces so that they are smooth.

⚠ CAUTION

Allow the cleaned area to dry for at least three minutes. Do not touch any surface that has been cleaned.

9. When reusing the windshield, remove the adhesive still adhering to the windshield, and clean with 3M™ AAD Part number 8906 or equivalent.

10. Clean the body side in the same way.



ACX00476 AB



INSTALLATION SERVICE POINT

>>A<< DUAL LOCK FASTENER/WINDSHIELD INSTALLATION

1. When replacing the windshield, temporarily set the windshield against the body, and place a mating mark on the windshield and body.
2. Use 3M™ AAD Part number 8906 or equivalent to degrease the inside and outside of the windshield and the body flanges.

⚠ CAUTION

- The primer strengthens the adhesive, so be sure to apply it evenly around the entire circumference. However, a too thick application will weaken the adhesive.
 - Do not touch the coated surface.
3. Soak a sponge in the primer, and apply evenly to the windshield and the body in the specified places.
 4. Allow the windshield to dry for at least three minutes after applying primer.
 5. Install the dual lock fasteners to the windshield in the position shown in the illustration.
 6. Install the dual lock fasteners to the body flange in the positions that are corresponding to those on the windshield.



7. Fill a sealant gun with adhesive. Then apply the adhesive evenly around the windshield within 30 minutes after applying the primer.

NOTE: Cut the tip of the sealant gun nozzle into a V shape to simplify adhesive application.

8. Align the mating marks on the windshield and the body, and lightly press the windshield evenly so that it adheres completely.
9. Use a spatula or similar tool to remove any excessive adhesive. Clean the surface with 3M™ AAD Part number 8906 or equivalent. Avoid moving the vehicle until the adhesive sets.

⚠ CAUTION



- Do not move the vehicle unless absolutely necessary.
 - When testing for water leakage, do not pinch the end of the hose to spray the water.
10. Wait 30 minutes or more, and then test for water leakage.

QUARTER WINDOW GLASS REMOVAL AND INSTALLATION

M1422002500151

Pre-removal and Post-installation Operation

- Quarter Trim Upper Removal and Installation (Refer to GROUP 52A, Trims [P.52A-36.](#))



REMOVAL STEPS

- <<A>> >>A<< 1. QUARTER WINDOW GLASS ASSEMBLY

REMOVAL STEPS (Continued)

- >>A<< 2. DUAL LOCK FASTENER
>>A<< 3. WINDOW DAM

REMOVAL SERVICE POINT

<<A>> QUARTER WINDOW GLASS REMOVAL

Remove the quarter window glass by the same procedure as for the windshield. (Refer to [P.42-13.](#))

INSTALLATION SERVICE POINT


>>A<< WINDOW DAM/DUAL LOCK FASTENER/QUARTER WINDOW GLASS INSTALLATION

1. Use 3M™ AAD Part number 8880 or equivalent to degrease the window dam and dual lock fastener mounting surface on both the glass and the body.

CAUTION

Allow the degreased portion to dry for at least three minutes before proceeding to the next procedure. Do not touch any surface that has been cleaned.

2. Attach the window dam.
3. Install the dual lock fastener to the shown position.
4. Apply primer and adhesive .
5. Install the glass in the same way as for the windshield.





LIFTGATE WINDOW GLASS
REMOVAL AND INSTALLATION

M1422003700103

Pre-removal and Post-installation Operation

- Liftgate Garnish Removal and Installation (Refer to GROUP 51, Grill, Molding and Garnish P.51-6.)
- High Mounted Stoplight Removal and Installation (Refer to GROUP 54, High-mounted Stoplight P.54-156.)
- Liftgate Trim Removal and Installation (Refer to P.52A-36.)



REMOVAL SERVICE POINT



<<A>> LIFTGATE WINDOW GLASS REMOVAL

Remove the liftgate window glass using the same procedure as for the windshield. (Refer to [P.42-13.](#))


INSTALLATION SERVICE POINT

>>A<< CLIP/DUAL LOCK FASTENER/LIFTGATE WINDOW GLASS LOWER DAM/LIFTGATE WINDOW GLASS SIDE DAM/LIFTGATE WINDOW GLASS UPPER DAM/LIFTGATE WINDOW GLASS

1. Use 3M™ AAD Part number 8906 or equivalent to degrease the inside and outside edges of the liftgate window glass and the surface of the body flange.
2. Face the clip's claws downward, and attach to the inner side of the liftgate window glass as shown in the illustration.



3. Align the dual lock fastener to the markings on the glass, and install. Then, install the liftgate outer panel so that it is aligned.



4. Attach the liftgate glass dam from the dam attachment reference mark to the edge of the glass.
5. Apply primer and adhesive. (Refer to [P.42-18.](#))
6. Install the glass in the same way as for the windshield. (Refer to [P.42-13.](#))

DOOR

GENERAL DESCRIPTION

OPERATION

CENTRAL DOOR LOCKING SYSTEM

The central door locking system operates the door lock actuator to lock or unlock the doors using the operation of the door lock switch or key built into the driver's side inside door lock knob and power window (main or sub) switch. The system has the following operations and features:

- All doors can be locked or unlocked using the door (LH or RH) key cylinder key operation.
- All doors can be locked using the driver's inside door lock knob.
- All doors can be locked using the door lock switch built into the power window (main or sub) switch.
- You cannot lock an open door if the key is in the ignition switch. The key reminder function automatically unlocks all doors when the door is locked.

POWER WINDOWS

Power windows are used in all vehicles. When the power window (main or sub) switch is operated, the door windows will open or close. This system has the following operations and features:

- When the power window (main or sub) switch is depressed (UP or DOWN) with the ignition switch in the "ON" position, current flows through fusible link number 4 to the power window motor. This energizes the power window motor, causing the door window glass to open or close.
- When all doors are closed and the ignition is turned off, the power windows can be operated for 30 seconds from the time the ignition is turned off.
- When the power window lock switch is placed in the "LOCK" (OFF) position, no switch other than the main switch at the driver's side window can operate the power window motor.
- The power window motor has a circuit breaker that protects the motor from damage caused by excessive current.

M1423000100172

CENTRAL DOOR LOCKING SYSTEM DIAGNOSIS

INTRODUCTION TO CENTRAL DOOR LOCKING SYSTEM DIAGNOSIS

The central door locking system is controlled by the ETACS-ECU. By operating the door key, inside door lock knob or door lock switch, the ETACS-ECU lock or unlock the door lock actuator. If the following type of symptom occurs, there may be a fault.

- None of the door lock functions operate.
- There is a door that does not lock or unlock when the door key, inside door lock knob or door lock switch is operated.

M1427002400052

CENTRAL DOOR LOCKING SYSTEM TROUBLESHOOTING STRATEGY

Use these steps to plan your diagnostic strategy. If you follow them carefully, you will be sure that you have exhausted most of the possible ways to find a central door locking system fault.

- Gather information from the customer.
- Verify that the condition described by the customer exists.
- Follow the Symptom Chart and find the fault.

M1427002100051

TROUBLE SYMPTOM CHART

M1427001800046




SYMPTOM	INSPECTION PROCEDURE	REFERENCE PAGE
Only the ETACS-ECU input signal cannot be checked using the scan tool (MUT-II).	1	P.42-21
None of the door lock functions operate.	2	P.42-23
The other door(s) do(es) not lock or unlock by the door lock switch or the front passenger's side door lock key cylinder. (However, they can be operated by the driver's inside door lock knob.)	3	P.42-27

SYMPTOM	INSPECTION PROCEDURE	REFERENCE PAGE
The other door(s) do(es) not lock or unlock by the driver's inside door lock knob or driver's side door lock key cylinder.	4	P.42-41
Some doors do not lock or unlock.	5	P.42-48
Forgotten key prevention function does not operate (center door locking system function works normally).	6	P.42-62

SYMPTOM PROCEDURES

INSPECTION PROCEDURE 1: Only the ETACS-ECU Input Signal Cannot be Checked Using the Scan Tool (MUT-II).

Data Link Connector Circuit



CIRCUIT OPERATION

The ETACS-ECU signal is sent to the data link connector. A trouble can be diagnosed by connecting the scan tool to the data link connector.

TECHNICAL DESCRIPTION (COMMENT)

The cause may be a malfunction of the data link check circuit or of the scan tool.

TROUBLESHOOTING HINTS

- Malfunction of the ETACS-ECU
- Malfunction of the scan tool
- Damaged harness wires or connectors

DIAGNOSIS

Required Special Tool:

- MB991223: Harness Set



STEP 1. Check the harness wire between data link connector C-69 (terminal No.9) and ETACS-ECU connector D-10 (terminal No.25) or D-27(terminal No.48).

- (1) Remove the instrument panel side cover <LH> (Refer to [P.52A-32.](#)).
- (2) Check the harness wire between data link connector C-69 and ETACS-ECU connector D-10 or D-27.

Q: Is the harness wire between data link connector C-69 (terminal No.9) and ETACS-ECU connector D-10 (terminal No.25) or D-27 (terminal No.48) is damaged?

YES : Repair or replace the harness wire. then go to Step 2.
(Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection.)

NO : Replace the ETACS-ECU. Then go to Step 2.



STEP 2. Retest the system




Q: Does the scan tool (MUT-II) communicate normally?


YES : The procedure is complete.

NO : Return to Step 1.

INSPECTION PROCEDURE 2: None of the Door Lock Function Operate.

ECU Power Supply Circuit





CIRCUIT OPERATION

The ETACS-ECU power is supplied from fusible link number 8.

TECHNICAL DESCRIPTION (COMMENT)

The cause may be a malfunction of the ETACS-ECU power supply circuit system or of the ground circuit system.

TROUBLESHOOTING HINTS

- Malfunction of the ETACS-ECU
- Damaged wiring harness or connector

DIAGNOSIS

Required Special Tool:

- MB991223: Harness Set


STEP 1. Measure the power supply line voltage at junction block connector D-11.


- (1) Remove the ETACS-ECU and measure at the junction block side.
- (2) Measure the voltage between terminal 1 and ground, and between terminal 2 and ground.
 - The measured value should be approximately 12 volts (battery positive voltage).

Q: Does the measured voltage correspond with this range?

YES : Go to Step 3.

NO : Go to Step 2.






STEP 2. Check ETACS-ECU connector D-11 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Q: Are the connectors and terminals in good condition?



YES : Go to step 3.

NO : Repair or replace damaged components. Refer to GROUP 00E [P.00E-2](#), Harness Connector inspection. Then go to Step 6.



STEP 3. Check the harness wires between fusible link number 8 and ETACS-ECU connector D-11 (terminal No.1 and 2).


NOTE: After inspecting intermediate connector A-54X, junction block connector D-01 or D-02 inspect the wire. If intermediate connector A-54X, junction block connector D-01 or D-02 is damaged, repair or replace it. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 6.



Q: Are there any damaged wires between fusible link number 8 and ETACS-ECU connector D-11 (terminal No.1 and 2)?

YES : Repair or replace the harness wire, then go to Step 6.

NO : Go to Step 4.




STEP 4. Check ETACS-ECU connector D-11 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Q: Is ETACS-ECU connector D-11 in good condition?

YES : Go to step 5.

NO : Repair or replace the damaged components. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 6.




STEP 5. Check the harness wires between ETACS-ECU connector D-11 and ground.

NOTE: After inspecting junction block connector D-13 inspect the wire. If junction block connector D-13 is damaged, repair or replace it. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 6.

Q: Is the harness wire between ETACS-ECU connector D-11 and ground damaged?

YES : Repair or replace the harness wire. Then go to Step 6.

NO : Replace the ETACS-ECU. Then go to Step 6.



STEP 6. Retest the system.

Q: Does the door lock function operate normally?


YES : The procedure is complete.

NO : Return to Step 1.

INSPECTION PROCEDURE 3: The other Door(s) do(es) not Lock or Unlock by the Door Switch or the Front Passenger's Side Door Lock Key Cylinder. (However, they can be Operated by the Driver's Inside Door Lock Knob.)


Door Lock Switch Circuit

<Vehicles without keyless entry system>




W3P02M29AA


<Vehicles with keyless entry system>






CONNECTOR: C-12



CONNECTORS: C-39, C-40





CIRCUIT OPERATION

When the door lock switch or door lock key cylinder switch is locked or unlocked, the ETACS-ECU will lock or unlock the door lock actuator.

TECHNICAL DESCRIPTION (COMMENT)

The door lock switch, the door lock key cylinder switch, the ETACS-ECU, harness or connector may be defective.

TROUBLESHOOTING HINTS

- Malfunction of the door lock switch
- Malfunction of the door lock key cylinder switch
- Malfunction of the ETACS-ECU
- Damaged wiring harness or connector

DIAGNOSIS

Required Special Tool:

- MB991223: Harness Set
- MB991502: Scan Tool (MUT-II)
- MB991529: Diagnostic Trouble Code Check Harness

STEP 1. Choose method of ETACS-ECU input signal check.


Q: Is the ETACS-ECU input signal check performed by scan tool MB991502 or a voltmeter?

By Scan tool MB991502 : Go to Step 2.

By a Voltmeter <Door lock switch (incorporated with power window main switch) check> : Go to Step 3.

By a Voltmeter <Door lock switch (incorporated with power window sub switch) check> : Go to Step 4.

By a Voltmeter <Door lock key cylinder switch> : Go to Step 5.

**STEP 2. Check the input signal (by using pulse check).**

Check the input signal (door lock switch or door lock key cylinder switch) by using scan tool MB991502.

⚠ CAUTION

To prevent damage to scan tool MB991502, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991502.

- (1) Connect scan tool MB991502 to the data link connector (16-pin).
- (2) Check that the tone alarm of the scan tool MB991502 sounds when the door lock switch or door lock key cylinder switch is operated (lock/unlock).


Q: Does the tone alarm of scan tool MB991502 sound when the input signal enters?

YES : Replace the ETACS-ECU and then go to Step 15.

NO <The door lock switch (incorporated with power window main switch) input signal> : Go to Step 6.

NO <The door lock switch (incorporated with power window sub switch) input signal> : Go to Step 7.

NO (The door lock key cylinder switch) input signal) :
Go to Step 10.


**STEP 3. Check the ETACS-ECU input signal from the door lock switch (incorporated with power window main switch) (by using a voltmeter).**

- (1) Use special tool MB991529 to connect a voltmeter between ground terminal 4 or 5 and ETACS-ECU terminal 9 of the data link connector.
- (2) Check that the voltmeter indicator deflects once when the door lock switch (incorporated with power window main switch) is operated (lock/unlock).

Q: Does the voltmeter indicator deflect?

YES : Replace the ETACS-ECU and then go to Step 15.

NO : Go to Step 6.


**STEP 4. Check the input signal from the door lock switch (incorporated with power window sub switch) (by using a voltmeter).**

- (1) Use special tool MB991529 to connect a voltmeter between ground terminal 4 or 5 and ETACS-ECU terminal 9 of the data link connector.
- (2) Check that the voltmeter indicator deflects once when the door lock switch (incorporated with power window sub switch) is operated (lock/unlock).

Q: Does the voltmeter indicator deflect?

YES : Replace the ETACS-ECU and then go to Step 15.

NO : Go to Step 7.




STEP 5. Check the input signal from the door lock key cylinder switch (by using a voltmeter).

- (1) Use special tool MB991529 to connect a voltmeter between ground terminal 4 or 5 and ETACS-ECU terminal 9 of the data link connector.
- (2) Check that the voltmeter indicator deflects once when the door lock key cylinder is operated (lock/unlock).

Q: Does the voltmeter indicator deflect?

YES : Replace the ETACS-ECU and then go to Step 15.
NO : Go to Step 10.




STEP 6. Check the door lock switch (incorporated with power window main switch) continuity.

- (1) Remove the power window main switch (Refer to P.42-105.).
- (2) Follow the table to check the resistance when the door lock switch is operated (lock/unlock).

SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
At the LOCK position	5 – 12	Less than 2 ohms
OFF	5 – 12 12 – 10	Open circuit
At the UNLOCK position	12 – 10	Less than 2 ohms

Q: Is the door lock switch damaged?

YES : Replace the power window main switch, then go to Step 15.
NO : Go to Step 8.

**STEP 7. Check the door lock switch (incorporated with power window sub switch) continuity.**

- (1) Remove the power window sub switch (Refer to [P.42-105](#)).
- (2) Follow the table to check the resistance when the door lock switch is operated (lock/unlock).

SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
At the LOCK position	1 – 2	Less than 2 ohms
OFF	1 – 2 2 – 3	Open circuit
At the UNLOCK position	2 – 3	Less than 2 ohms

Q: Is the door lock switch damaged?

YES : Replace the power window sub switch, then go to Step 15.




NO : Go to Step 8.

STEP 8. Check ETACS-ECU connector D-10 <Vehicles without keyless entry system> or D-27 <Vehicles with keyless entry system> and door lock switch connector F-05 or F-17 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Q: Are ETACS-ECU connector D-10 <Vehicles without keyless entry system> or D-27 <Vehicles with keyless entry system> and door lock switch connector F-05 or F-17 in good condition?



YES : Go to step 9.

NO : Repair or replace the damaged components. Refer to GROUP 00E [P.00E-2](#), Harness Connector inspection. Then go to Step 15.




STEP 9. Check the harness wire between ETACS-ECU connector D-10 (terminal No.27 and 28) <Vehicles without keyless entry system> or D-27(terminal No.49 and 50) <Vehicles with keyless entry system> and door lock switch connectors F-05 (terminal No.5 and 10) or F-17(terminal No.1 and 3).

NOTE: After inspecting intermediate connector C-12 or C-39 inspect the wires. If intermediate connector C-12 or C-39 is damaged, repair or replace it. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 15.



CONNECTORS: D-10, D-27



D-10 COMPONENT SIDE

23	22		21
28	27	26	25 24

D-27 COMPONENT SIDE

48	47	46	45	44	43	42	41
56	30	55	53	52	51	50	49

AC202002 AB


Q: Are there any damaged harness wires?

YES : Repair or replace the harness wire, then go to Step 15.

NO : Go to Step 15.

CONNECTOR: F-05

FRONT
DOOR (LH)




COMPONENT SIDE

6	5	4	3	2	1
14	13	12	11	10	9 8 7

AC202003 AB

CONNECTOR: F-17


FRONT DOOR
<RH>



COMPONENT SIDE

3	2	1
8	7	6 5 4

AC202004 AB

**STEP 10. Check the door lock key cylinder switch <RH>.**

- (1) Remove the door lock key cylinder switch (Refer to [P.42-111.](#)).
- (2) Follow the table to check the resistance when the door lock key cylinder switch is operated (lock/unlock).

SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
At the LOCK position	2 – 3	Less than 2 ohms
OFF	1 – 2 2 – 3	Open circuit
At the UNLOCK position	1 – 2	Less than 2 ohms

Q: Is the door lock key cylinder switch damaged?

YES : Replace the door lock key cylinder switch, then go to Step15.

NO : Go to Step 11.


STEP 11. Check ETACS-ECU connector D-10 <Vehicles without keyless entry system> or D-26 <Vehicles with keyless entry system> and door lock key cylinder switch connector F-18 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Q: Are ETACS-ECU connector D-10 <Vehicles without keyless entry system> or D-26 <Vehicles with keyless entry system> and door lock key cylinder switch connector F-18 in good condition?

YES : Go to step 12.

NO : Repair or replace the damaged components. Refer to GROUP 00E [P.00E-2](#), Harness Connector inspection. Then go to Step 15.

CONNECTORS: D-10, D-26



D-10 COMPONENT SIDE


23	22		21
28	27	26	25 24

D-26 COMPONENT SIDE

26	25	24	23	22	21
32	31	30	29	28	27

AC202005 AB


CONNECTOR: F-18



COMPONENT SIDE


3	2	1
---	---	---

AC202006AB



STEP 12. Check the harness wire between ETACS-ECU connector D-10 (terminal No.27 and 28) <Vehicles without keyless entry system> or D-26 (terminal No.22 and 28) <Vehicles with keyless entry system> and door lock key cylinder switch connector F-18 (terminal No. 1 and 3)


NOTE: After inspecting intermediate connector C-12 inspect the wires. If intermediate connector C-12 is damaged, repair or replace it. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 15.




Q: Are there any damaged harness wires between ETACS-ECU connector D-10 (terminal No.27 and 28) <Vehicles without keyless entry system> or D-26 (terminal No.22 and 28) <Vehicles with keyless entry system> and door lock key cylinder switch connector F-18 (terminal No. 1 and 3)?

YES : Repair or replace the harness wire, then go to Step 15.

NO : Go to Step 13.










STEP 13. Check door lock switch connector F-05 or F-17 and door lock key cylinder switch connector F-18 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Q: Are door lock switch connector F-05 or F-17 and door lock key cylinder switch connector F-18 in good condition?

YES : Go to step 14.

NO : Repair or replace the damaged components. Refer to GROUP 00E [P.00E-2](#), Harness Connector inspection. Then go to Step 15.





STEP 14. Check the harness wire between door lock switch connector F-05 (terminal No.12) or F-17 (terminal No.2) and ground, or between door lock key cylinder switch connector F-18 (terminal No.2) and ground.

NOTE: After inspecting intermediate connector C-12 or C-40 inspect the wire. If intermediate connector C-12 or C-40 is damaged, repair or replace it. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 15.

Q: Is the harness wire damaged?

YES : Repair or replace the harness wire, then go to Step 15.

NO : Replace the ETACS-ECU then go to Step 15.

STEP 15. Retest the system.




Q: Does the door lock function operate normally?

YES : The procedure is complete.

NO : Return to Step 1.

Door Lock Key Cylinder Switch Circuit





CIRCUIT OPERATION

When the driver's inside door knob is operated to the lock side, the ETACS-ECU will output the door lock signal for 0.5 second. If the driver's door side door lock key cylinder is operated to the unlock side, the ETACS-ECU will output the unlock signal for 0.5 second.

TECHNICAL DESCRIPTION (COMMENT)

The front door lock actuator <LH>, the door lock key cylinder <LH>, the ETACS-ECU, harness or connector may be defective.

TROUBLESHOOTING HINTS

- Malfunction of the front door lock actuator <LH>
- Malfunction of the door lock key cylinder switch <LH>
- Malfunction of the ETACS-ECU
- Damaged wiring harness or connector

DIAGNOSIS

Required Special Tool:

- MB991223: Harness Set
- MB991502: Scan Tool (MUT-II)
- MB991529: Diagnostic Trouble Code Check Harness

STEP 1. Choose method of ETACS-ECU input signal check

Q: Is the ETACS-ECU input signal check performed by scan tool MB991502 or a voltmeter?

By Scan tool MB991502 : Go to Step 2.

By a Voltmeter <The door lock actuator switch (LH) check> : Go to Step 3.

By a Voltmeter <The door lock key cylinder switch (LH) check> : Go to Step 4.

STEP 2. Check the input signal (by using pulse check).

Check the ETACS-ECU input signal (door lock actuator switch - LH side) by using scan tool MB991502.

⚠ CAUTION

To prevent damage to scan tool MB991502, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991502.


- (1) Connect scan tool MB991502 to the data link connector (16-pin).
- (2) Check that the tone alarm of scan tool MB991502 sounds when the door lock actuator switch <LH> or door lock key cylinder switch <LH> is operated (lock/unlock).

Q: Does the tone alarm of scan tool MB991502 sound when the input signal enters?

YES : Replace the ETACS-ECU and then go to Step 11.

NO (The door lock actuator switch <LH> input signal) :
Go to Step 5.

NO (The door lock key cylinder switch <LH> input signal) : Go to Step 6 .




STEP 3. Check the ETACS-ECU input signal from the door lock actuator switch <LH> (by using a voltmeter).

- (1) Use special tool MB991529 to connect a voltmeter between ground terminal 4 or 5 and ETACS-ECU terminal 9 of the data link connector.
- (2) Check that the voltmeter indicator deflects once when the door lock actuator switch <LH> is operated (lock/unlock).

Q: Does the voltmeter indicator deflect?

YES : Replace the ETACS-ECU and then go to Step 11.

NO : Go to Step 5.




STEP 4. Check the input signal from the door lock key cylinder switch <LH> (by using a voltmeter).


- (1) Use special tool MB991529 to connect a voltmeter between ground terminal 4 or 5 and ETACS-ECU terminal 9 of the data link connector.
- (2) Check that the voltmeter indicator deflects once when the door lock key cylinder switch <LH> is operated (lock/unlock).

Q: Does the voltmeter indicator deflect?

YES : Replace the ETACS-ECU and then go to Step 11.

NO : Go to Step 6.



**STEP 5. Check the front door lock actuator switch <LH>.**


- (1) Remove the door latch assembly. (Refer to [P.42-111.](#))
- (2) Follow the table to check the resistance when the door lock actuator switch <LH> is operated (lock/unlock).

SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
At the LOCK position	1 – 2	Less than 2 ohms
At the UNLOCK position	1 – 3	Less than 2 ohms

Q: Is the front door lock actuator switch <LH> damaged?

YES : Replace front door lock actuator assembly <LH>, go to Step 11 .

NO : Go to Step 7.

**STEP 6. Check the door lock key cylinder switch <LH>.**

- (1) Remove the door lock key cylinder switch (Refer to [P.42-111.](#)).
- (2) Follow the table to check the resistance when the door lock key cylinder switch <LH> is operated (lock/unlock).

SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
At the LOCK position	2 – 3	Less than 2 ohms
OFF	1 – 2 2 – 3	Open circuit
At the UNLOCK position	1 – 2	Less than 2 ohms

Q: Is the door lock key cylinder switch <LH> damaged?

YES : Replace the door lock key cylinder switch <LH>, go to Step 11.



NO : Go to Step 7.

STEP 7. Check door lock actuator connector F-12, ETACS-ECU connector D-10 <Vehicles without keyless entry system>, D-26 <Vehicles with keyless entry system> or D-27 <Vehicles with keyless entry system> and door lock key cylinder switch <LH> connector F-06 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Q: Are the connectors in good condition?


YES : Go to step 8.

NO : Repair or replace the damaged components. Refer to GROUP 00E [P.00E-2](#), Harness Connector inspection. Then go to Step 11.



STEP 8. Check the harness wires between ETACS-ECU connector D-10 (terminal No.21, 23 and 24) <Vehicles without keyless entry system> or D-27 (terminal No.41, 43 and 45) <Vehicles with keyless entry system> and door lock actuator connector F-12 (terminal No.2, 4 and 6), and between ETACS-ECU connector D-10 (terminal No.26) <Vehicles without keyless entry system>, D-26 (terminal No.28) <Vehicles with keyless entry system> or D-27 (terminal No.52) <Vehicles with keyless entry system> and door lock key cylinder switch <LH> connector F-06 (terminal No.1 and 3).


NOTE: After inspecting intermediate connector C-39 inspect the wire. If intermediate connector C-39 is damaged, repair or replace it. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 11.




Q: Are there any damaged harness wires between ETACS-ECU connector D-10 (terminal No.21, 23 and 24) <Vehicles without keyless entry system> or D-27 (terminal No.41, 43 and 45) <Vehicles with keyless entry system> and door lock actuator connector <LH> F-12 (terminal No.2, 4 and 6), between ETACS-ECU connector D-10 (terminal No.26) <Vehicles without keyless entry system>, D-26 (terminal No.28) <Vehicles with keyless entry system> or D-27 (terminal No.52) <Vehicles with keyless entry system> and door lock key cylinder switch <LH> connector F-06 (terminal No.1 and 3)?

YES : Repair or replace the harness wire, then go to Step 11.

NO : Go to Step 9.






STEP 9. Check door lock actuator connector F-12 door lock key cylinder switch connector F-06 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Q: Are the connectors in good condition?

YES : Go to step 10.

NO : Repair or replace the damaged connector. Refer to GROUP 00E, Harness Connector inspection [P.00E-2](#). Then go to Step 11.





STEP 10. Check the harness wire between door lock actuator connector F-12 (terminal No.1) and ground, or between door lock key cylinder switch connector F-06 and ground.

NOTE: After inspecting intermediate connector C-39 inspect the wire. If intermediate connector C-39 is damaged, repair or replace it. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 11.

Q: Is the harness wire between door lock actuator connector F-12 (terminal No.1) and ground, or between door lock key cylinder switch connector F-06 and ground damaged?

YES : Repair or replace the harness wire, then go to Step 11.

NO : Go to Step 11.



STEP 11. Retest the system.

Q: Does the door lock function operate normally?


YES : The procedure is complete.

NO : Return to Step 1.


INSPECTION PROCEDURE 5: Some Doors do not Lock or Unlock.






Door Lock Actuator Circuit

<Vehicles without keyless entry system>



W1P05M06AA
AC004328AC





CIRCUIT OPERATION

When the door lock actuator receives the lock or unlock signal from the ETACS-ECU, the actuator will lock or unlock the door.

TECHNICAL DESCRIPTION (COMMENT)

The cause may be a malfunction of the door lock actuator or of a wiring harness or connector.

TROUBLESHOOTING HINTS

- Malfunction of the door lock actuator
- Damaged wiring harness or connector

DIAGNOSIS

Required Special Tool:

- MB991223: Harness Set
- MB991502: Scan Tool (MUT-II)
- MB991529: Diagnostic Trouble Code Check Harness

STEP 1. Choose method of ETACS-ECU input signal check

Q: Is the ETACS-ECU input signal check performed by the scan tool MB991502 or a voltmeter?

By Scan tool MB991502 : Go to Step 2.

By a Voltmeter <Front door lock actuator check > : Go to Step 3.

By a Voltmeter <Rear door lock actuator check > : Go to Step 4.

By a Voltmeter <Liftgate lock actuator check > : Go to Step 5.

STEP 2. Check the input signal (by using pulse check).

Check the ETACS-ECU input signal (front and rear door lock actuator and rear door lock actuator) by using scan tool MB991502.

⚠ CAUTION

To prevent damage to scan tool MB991502, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991502.

- (1) Connect scan tool MB991502 to the data link connector (16-pin).
- (2) Check that the tone alarm of the scan tool MB991502 sounds when the front door lock actuator, rear door lock actuator or liftgate lock actuator is operated (lock/unlock).


Q: Does the tone alarm of scan tool MB991502 sound when the input signal enters?

YES : Replace the ETACS-ECU and then go to Step 11.

NO (Front door lock actuator input signal) : Go to Step 6.

NO (Rear door lock actuator input signal) : Go to Step 7.

NO (Liftgate lock actuator input signal) : Go to Step 8.




STEP 3. Check the ETACS-ECU input signal from the front door lock actuator (by using a voltmeter).


- (1) Use special tool MB991529 to connect a voltmeter between ground terminal 4 or 5 and ETACS-ECU terminal 9 of the data link connector.
- (2) Check that the voltmeter indicator deflects once when front door lock actuator is operated (lock/unlock).

Q: Does the voltmeter indicator deflect?

YES : Replace the ETACS-ECU and then go to Step 11.

NO : Go to Step 6.





STEP 4. Check the input signal from the rear door lock actuator (by using a voltmeter).

- (1) Use special tool MB991529 to connect a voltmeter between ground terminal 4 or 5 and ETACS-ECU terminal 9 of the data link connector.
- (2) Check that the voltmeter indicator deflects once when the rear door lock actuator is operated (lock/unlock).

Q: Does the voltmeter indicator deflect?


YES : Replace the ETACS-ECU and then go to Step 11.
NO : Go to Step 7.


STEP 5. Check the input signal from the liftgate lock actuator (by using a voltmeter).

- (1) Use special tool MB991529 to connect a voltmeter between ground terminal 4 or 5 and ETACS-ECU terminal 9 of the data link connector.
- (2) Check that the voltmeter indicator deflects once when the liftgate lock actuator is operated (lock/unlock).

Q: Does the voltmeter indicator deflect?

YES : Replace the ETACS-ECU and then go to Step 11.
NO : Go to Step 8 .


STEP 6. Check the front door lock actuator switch.

- (1) Remove the door latch assembly (Refer to P.42-111.).
- (2) Follow the table to check the front door lock actuator operation (lock/unlock).

Actuator Operation Check <Left side>

LEVER POSITION	BATTERY CONNECTION	LEVER OPERATION
At the "UNLOCK" position	<ul style="list-style-type: none"> Connect terminal No. 6 and the positive battery terminal. Connect terminal No. 4 and the negative battery terminal. 	The lever moves from the "UNLOCK" position to the "LOCK" position.
At the "LOCK" position	<ul style="list-style-type: none"> Connect terminal No. 4 and the positive battery terminal. Connect terminal No. 6 and the negative battery terminal. 	The lever moves from the "LOCK" position to the "UNLOCK" position.

Actuator Switch Check <Left side>

SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
At the "UNLOCK" position	1 – 3	Less than 2 ohms
At the "LOCK" position	1 – 2	Less than 2 ohms

Actuator Operation Check <Right side>

LEVER POSITION	BATTERY CONNECTION	LEVER OPERATION
At the "UNLOCK" position	<ul style="list-style-type: none"> • Connect terminal No. 4 and the positive battery terminal. • Connect terminal No. 6 and the negative battery terminal. 	The lever moves from the "UNLOCK" position to the "LOCK" position.
At the "LOCK" position	<ul style="list-style-type: none"> • Connect terminal No. 6 and the positive battery terminal. • Connect terminal No. 4 and the negative battery terminal. 	The lever moves from the "LOCK" position to the "UNLOCK" position.

Q: Is the front door lock actuator switch damaged?

YES : Replace the door latch assembly, then go to Step 11 .

NO : Go to Step 9.

STEP 7. Check the rear door lock actuator.


- (1) Remove the door lock key cylinder switch (Refer to [P.42-111.](#)).
- (2) Follow the table to check the rear door lock actuator (lock/unlock).

Actuator Operation Check

LEVER POSITION	BATTERY CONNECTION	LEVER OPERATION
At the "B" position	<ul style="list-style-type: none">• Connect terminal No. 1 and the positive battery terminal.• Connect terminal No. 2 and the negative battery terminal.	The lever moves from the "B" position to the "C" position.
At the "C" position	<ul style="list-style-type: none">• Connect terminal No. 2 and the positive battery terminal.• Connect terminal No. 1 and the negative battery terminal.	The lever moves from the "C" position to the "B" position.

Q: Is the rear door lock actuator damaged?


- YES :** Replace the door lock actuator assembly, go to Step 11 .
- NO :** Go to Step 9.



STEP 8. Check the liftgate lock actuator.

- (1) Remove the liftgate lock key cylinder (Refer to [P.42-123.](#)).
- (2) Follow the table to check the liftgate lock actuator operation (lock/unlock).

Actuator Operation Check



LEVER POSITION	BATTERY CONNECTION	LEVER OPERATION
At the "LOCK" position	<ul style="list-style-type: none"> Connect terminal No. 1 and the positive battery terminal. Connect terminal No. 2 and the negative battery terminal. 	The lever moves from the "LOCK" position to the "UNLOCK" position.
At the "UNLOCK" position	<ul style="list-style-type: none"> Connect terminal No. 2 and the positive battery terminal. Connect terminal No. 1 and the negative battery terminal. 	The lever moves from the "UNLOCK" position to the "LOCK" position.

Q: Is the liftgate lock actuator damaged?

YES : Replace liftgate lock actuator, then go to Step 11 .

NO : Go to Step 9.


STEP 9. Check ETACS-ECU connector D-10 <Vehicles without keyless entry system> or D-27 <Vehicles with keyless entry system> and door lock actuator connectors F-09, F-12, F-21, F-24 and G-04 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

NOTE: After inspecting intermediate connector C-01, C-12, C-39, E-01, E-18, E-31 or E-42 inspect the wire. If junction block connector C-01, C-12, C-39, E-01, E-18, E-31 or E-42 is damaged, repair or replace damaged component. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 11.


Q: Are the connectors in good condition?

YES : Go to step 10.

NO : Repair or replace the damaged components. Refer to GROUP 00E [P.00E-2](#), Harness Connector inspection. Then go to Step 11.



CONNECTORS: D-10, D-27



D-10 COMPONENT SIDE


23	22		21
28	27	26	25 24

D-27 COMPONENT SIDE

48	47	46	45	44	43	42	41
56	30	55	53	52	51	50	49

AC202002 AB

CONNECTORS: E-01, E-18, E-31, E-42



E-01, E-03

1		2
3	4	5 6 7

E-18


1	2		3	4	5
6	7	8	9	10	11 12 13

E-42

1	2	3	4		5	6	7	8
9	10	11	12	13	14	15	16	17 18 19

AC202037 AB

CONNECTORS: F-09, F-12
<DRIVER'S SIDE>



F-09 COMPONENT SIDE




F-12 COMPONENT SIDE



AC202034 AB

CONNECTORS: F-21, F-24
<PASSENGER'S SIDE>



F-21 COMPONENT SIDE




F-24 COMPONENT SIDE



AC202035AB

CONNECTOR: G-04



COMPONENT
SIDE



AC202036AB



STEP 10. Check the harness wires between ETACS-ECU connector D-10 (terminal No.21, 23 and 24) <Vehicles without keyless entry system> or D-27 (terminal No.41, 42, 43 and 45) <Vehicles with keyless entry system> and door lock actuator connector F-09 (terminal No.1 and 2)/F-12 (terminal No.2, 4 and 6)/F-21 (terminal No.1 and 2)/F-24 (terminal No.4 and 6)/G-04 (terminal No.1 and 2).

NOTE: After inspecting intermediate connector C-01, C-12, C-39, E-01, E-18, E-31 or E-42 inspect the wire. If junction block connector C-01, C-12, C-39, E-01, E-18, E-31 or E-42 is damaged, repair or replace it. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 11.


Q: Are there any damaged harness wires between ETACS-ECU connector D-10 <Vehicles without keyless entry system> or D-27 <Vehicles with keyless entry system> and door lock actuator connectors F-09/F-12/F-21/F-24/G-04?

YES : Repair or replace the harness wire, then go to Step 11.

NO : Go to Step 11.



CONNECTORS: D-10, D-27



D-10 COMPONENT SIDE

23	22		21
28	27	26	25 24


D-27 COMPONENT SIDE

48	47	46	45	44	43	42	41
56	30	55	53	52	51	50	49

AC202002 AB

CONNECTORS: F-09, F-12

<DRIVER'S SIDE>



F-09 COMPONENT SIDE


2	1
5	4 3

F-12 COMPONENT SIDE

3	2	1
6	5	4

AC202034 AB

CONNECTORS: F-21, F-24
<PASSENGER'S SIDE>



F-21 COMPONENT SIDE




F-24 COMPONENT SIDE



AC202035AB

CONNECTOR: G-04



COMPONENT
SIDE



AC202036AB

STEP 11. Retest the system.


Q: Does the door lock function operate normally?

YES : The procedure is complete.

NO : Return to Step 1.


INSPECTION PROCEDURE 6: Forgotten Key Prevention Function does not Operate (Center Door Locking System Function Works Normally).

Key Reminder Switch Circuit









W1P12M05AA
AC004333AB

CONNECTOR: C-72



CONNECTORS: D-11, D-27





TECHNICAL DESCRIPTION (COMMENT)

The ETACS-ECU operates the forgotten key prevention function, based on the input signals from the following switches:

- Key reminder switch
- Driver's or front passenger's door switch

If the function does not work normally, a defect on the relevant circuit or the ETACS-ECU may be suspected.

TROUBLESHOOTING HINTS

- Malfunction of the key reminder switch
- Malfunction of the driver's or front passenger's door switch
- Malfunction of the ETACS-ECU
- Damaged harness wires or connectors

DIAGNOSIS

Required Special Tools:

- MB991223: Test Harness Set
- MB991502: Scan Tool (MUT-II)
- MB991529: Diagnostic Trouble Code Check Harness

STEP 1. Choose method of ETACS-ECU input signal check.

Q: Is the ETACS-ECU input signal check performed by scan tool MB991502 or a voltmeter?

By Scan tool MB991502 : Go to Step 2.

By a Voltmeter <Key reminder switch input signal check> : Go to Step 3.

By a Voltmeter <Driver's door switch input signal check> : Go to Step 4.

By a Voltmeter <Front passenger's door switch input signal check> : Go to Step 5.

STEP 2. Check the input signal (by using pulse check).

Check the ETACS-ECU input signal (key reminder switch and front door switch) by using scan tool MB99152.

Check the input signals from the following switches:

- Key reminder switch
- Driver's and front passenger's door switch

⚠ CAUTION

To prevent damage to scan tool MB991502, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991502.

- (1) Connect scan tool MB991502 to the data link connector (16-pin).
- (2) Check that the tone alarm of scan tool MB991502 sounds when the input signal enters.


Q: Does the tone alarm of scan tool MB991502 sound when the input signal enters?

YES : Replace the ETACS-ECU and then go to Step 17.

NO <Key reminder switch input signal> : Go to Step 6.

NO <Driver's door switch input signal> : Go to Step 7.

NO <Front passenger's door switch input signal> : Go to Step 8.


**STEP 3. Check the ETACS-ECU input signal from the key reminder switch (by using a voltmeter).**


- (1) Use special tool MB991529 to connect a voltmeter between ground terminal 4 or 5 and ETACS-ECU terminal 9 of the data link connector.
- (2) Check that the voltmeter indicator deflects once when the key reminder switch is operated <key in (off)/key out (on)>.

Q: Does the voltmeter indicator deflect?

YES : Replace the ETACS-ECU and then go to Step 17.

NO : Go to Step 6.






STEP 4. Check the input signal from the driver's door switch (by using a voltmeter).

- (1) Use special tool MB991529 to connect a voltmeter between ground terminal 4 or 5 and ETACS-ECU terminal 9 of the data link connector.
- (2) Check that the voltmeter indicator deflects once when the Driver's door switch is operated <open (on)/depressed (off)>.

Q: Does the voltmeter indicator deflect?

YES : Replace the ETACS-ECU and then go to Step 17.

NO : Go to Step 7.




STEP 5. Check the input signal from the front passenger's door switch (by using a voltmeter).

- (1) Use special tool MB991529 to connect a voltmeter between ground terminal 4 or 5 and ETACS-ECU terminal 9 of the data link connector.
- (2) Check that the voltmeter indicator deflects once when the front passenger's door switch is operated <open (on)/depressed (off)>.

Q: Does the voltmeter indicator deflect?

YES : Replace the ETACS-ECU and then go to Step 17.

NO : Go to Step 8.



STEP 6. Check the key reminder switch.


- (1) Remove the driver's side under cover.
- (2) Remove the column cover, lower and upper.
- (3) Disconnect the key reminder switch connector and measure at the key reminder switch side.
- (4) Measure the resistance between terminal numbers 4 and 6.
- (5) Follow the table below to check the key reminder switch continuity.

STATUS OF IGNITION KEY	TESTER CONNECTION	SPECIFIED CONDITION
Key removed	4 – 6	Less than 2 ohms
Key inserted	4 – 6	Open circuit

Q: Is the key reminder switch damaged?

YES : Replace the key reminder switch, then go to Step 18.

NO : Go to Step 7.




STEP 7. Check for continuity between key reminder switch connector D-16 terminal 4 and each of the other terminals as well as terminal 6 and each of the other terminals.

- (1) Disconnect key reminder switch connector D-16 and measure the resistance available at the equipment side of the connector.
- (2) Check for continuity between key reminder switch connector D-16 terminal 4 and each of the other terminals as well as terminal 6 and each of the other terminals.

Q: Does the continuity exist between the terminals?

NO : Go to Step 8.

YES : Replace the key reminder switch (Refer to GROUP 54, Ignition switch [P.54-65](#)). Then go to Step 18 .



STEP 8. Check the driver's door switch


- (1) Remove the driver's side door switch. (Refer to [P.42-103](#).)
- (2) Follow the table below to check the driver's door switch continuity.

SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
Released (ON)	1 - 2, 1 - 3, 2 - 3	Less than 2 ohms
Depressed (OFF)	1 - 2, 1 - 3, 2 - 3	Open circuit

Q: Is the driver's side door switch in good condition?

YES : Go to Step 14.

NO : Replace the front driver's side door switch, then go to Step 18.



STEP 9. Check the front passenger's door switch

- (1) Remove the front passenger's door switch. (Refer to [P.42-103](#).)
- (2) Follow the table below to check the passenger's door switch continuity.

SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
Released (ON)	1 - 2, 1 - 3, 2 - 3	Less than 2 ohms
Depressed (OFF)	1 - 2, 1 - 3, 2 - 3	Open circuit

Q: Is the front passenger's door switch in good condition?

YES : Go to Step 16.



NO : Replace the front passenger's door switch, then go to Step 18.


STEP 10. Check ETACS-ECU connector D-11 and key reminder switch connector D-16 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Q: Are the connectors in good condition?

YES : Go to Step 11.

NO : Repair or replace the damaged components. Refer to GROUP 00E, Harness Connector inspection [P.00E-2](#). Then go to Step 18.








STEP 11. Check the harness wire between ETACS-ECU connector D-11 (terminal No.8) and key reminder switch connectors D-16 (terminal No.6).


NOTE: After inspecting intermediate connector C-72, junction block connector D-13 inspect the wires. If intermediate connector C-72, junction block connector D-13 is damaged, repair or replace it. Refer to GROUP 00E, Harness Connector Inspection P.00E-2. Then go to Step 17.

Q: Are there any damaged harness wires?

YES : Repair or replace the harness wire, then go to Step 18.

NO : Go to Step 12.






STEP 12. Check key reminder switch connector D-16.

Q: Is key reminder switch connector D-16 in good condition?

YES : Go to Step 12.

NO : Repair or replace the damaged components. Refer to GROUP 00E [P.00E-2](#), Harness Connector inspection. Then go to Step 18.




STEP 13. Check the harness wire between key reminder switch connector D-16 and ground.

Q: Is the harness wire between key reminder switch connector D-16 and ground damaged?

YES : Repair or replace the harness wire, then go to Step 18.

NO : Go to Step 14.

CONNECTORS: D-11, D-27**D-11 COMPONENT SIDE**

1	2	1	1	1	0	9	8	7	6	5	4	3	2	1
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---

D-27 COMPONENT SIDE

41	42	43	44	45	46	47	48
49	50	51	52	53	54	55	56


AC202055 AB

STEP 14. Check ETACS-ECU connectors D-11, D-27 and driver's door switch connector E-33 for loose, corroded or damaged terminals, or terminals pushed back in the connector.


Q: Are the connectors in good condition?

YES : Go to Step 15.

NO : Repair or replace the damaged components. Repair or replace them. Refer to GROUP 00E [P.00E-2](#), Harness Connector inspection. Then go to Step 18.

CONNECTOR: E-33

AC202056 AB






STEP 15. Check the harness wires between ETACS-ECU connectors D-11 (terminal No.9), D-27 (terminal No.51) and driver's door switch connector E-33 (terminal No.1 and 2).
NOTE: After inspecting junction block connector D-14, intermediate connectors E-41 and E-42 inspect the wire. If junction block connector D-14, intermediate connectors E-41 or E-42 is damaged, repair or replace it. Refer to GROUP 00E [P.00E-2](#), *Harness Connector Inspection*. Then go to Step 17.

Q: Are there any damaged harness wires between ETACS-ECU connectors D-11 (terminal No.9), D-27 (terminal No.51) and driver's door switch connector E-33 (terminal No.1 and 2)?

YES : Repair or replace the harness wire, then go to Step 18.

NO : Go to Step 16.






STEP 16. Check ETACS-ECU connectors D-26, D-27 and front passenger's door switch connector E-46 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Q: Are the connectors in good condition?

YES : Go to Step 17.

NO : Repair or replace the damaged components. Refer to GROUP 00E [P.00E-2](#), Harness Connector inspection. Then go to Step 18.

CONNECTORS: D-26, D-27



D-26 COMPONENT SIDE


26	25	24	23	22	21
32	31	30	29	28	27

D-27 COMPONENT SIDE

41	42	43	44	45	46	47	48
49	50	51	52	53	54	55	56


AC202057AB

CONNECTOR: E-46



AC202058AB

CONNECTORS: E-41, E-42



E-41

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20
21	22								

E-42

1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16
17	18	19					

AC202059 AB

STEP 17. Check the harness wires between ETACS-ECU connector D-26 (terminal No.23), D-27 (terminal No.51) and front passenger's door switch connector E-46 (terminal No.1 and 2).


NOTE: After inspecting intermediate connectors E-41 and E-42 inspect the wire. If intermediate connectors E-41 or E-42 is damaged, repair or replace it. Refer to GROUP 00E [P.00E-2](#), *Harness Connector Inspection*. Then go to Step 17.

Q: Are there any damaged harness wires between ETACS-ECU connectors D-26 (terminal No.23), D-27 (terminal No.51) and front passenger's door switch connector E-46 (terminal No.1 and 2)?

YES : Repair or replace the harness wire, then go to Step 18.

NO : Go to Step 17.

CONNECTORS: D-26, D-27




D-26 COMPONENT SIDE

26	25	24	23	22	21
32	31	30	29	28	27

D-27 COMPONENT SIDE

41	42	43	44	45	46	47	48
49	50	51	52	53	54	55	56

AC202057 AB

**STEP 18. Retest the system.****Q: Does the door lock function operate normally?****YES :** The procedure is complete.**NO :** Return to Step 1.**POWER WINDOW DIAGNOSIS****INTRODUCTION TO POWER WINDOWS DIAGNOSIS**

If the power windows cannot be operated, the fuse, relay, main switch, sub switch, ETACS-ECU or motor may be faulty.

When the power window switch (main or sub) is operated, the power window motor operates and opens or closes the door window.

A timer function has been provided to allow the door windows to be opened or closed in 30 seconds after the ignition switch is turned from "ON" to "LOCK" (OFF) position when a front door <LH> and <RH> is closed (door switch is OFF). When the lock switch is changed from unlock to lock, the door windows can only be opened or closed by the power window main switch on the driver's side.

If the following types of symptom occur, there may be a fault.

- None of the door windows open or close.
- There are door windows that do not open or close using the power window (main or sub) switch.
- The windows cannot be opened or closed using the power window (main or sub) switch within 30 seconds after the ignition switch is turned from "ON" to "LOCK" (OFF) position.

M1429002600148

POWER WINDOWS DIAGNOSTIC TROUBLESHOOTING STRATEGY

Use these steps to plan your diagnostic strategy. If you follow them carefully, you will be sure that you have exhausted most of the possible ways to find a power windows fault.

1. Gather information from customer.

2. Verify that the condition described by the customer exists.
3. Find the malfunction by following the Symptom Chart.
4. Verify that the malfunction is eliminated.

M1429002700145

SYMPTOM CHART


M1429002800175







SYMPTOM	INSPECTION PROCEDURE	REFERENCE PAGE
All windows does not open or close using the power window main/sub switch	1	P.42-76
Power window timer function does not work normally. (power window operates)	2	P.42-88

SYMPTOM PROCEDURES

INSPECTION PROCEDURE 1: All Windows does not Open or Close Using the Power Window Main/ Sub Switch.

Power Window Switch Circuit





CIRCUIT OPERATION

The ETACS-ECU turns ON the power window relay when the ignition switch (IG1) is turned ON.

TECHNICAL DESCRIPTION (COMMENT)

The power window relay or the ETACS-ECU may be defective.

TROUBLESHOOTING HINTS

- Malfunction of the power window relay
- Malfunction of the ETACS-ECU
- Damaged harness wires or connectors
- Malfunction of the power window main switch

DIAGNOSIS

Required Special Tools:

- MB991223: Test Harness Set
- MB991502: Scan Tool (MUT-II)
- MB991529: Diagnostic Trouble Code Check Harness

STEP 1. Choose method of ETACS-ECU input signal check.

Q: Is the ETACS-ECU input signal check performed by scan tool MB991502 or a voltmeter?

By Scan tool MB991502 : Go to Step 2.

By a Voltmeter : Go to Step 3.

STEP 2. Check the input signal (by using pulse check).

Check the ETACS-ECU input signal ignition switch (IG1) by using scan tool MB991502.

⚠ CAUTION


To prevent damage to scan tool MB991502, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991502.

- (1) Connect scan tool MB991502 to the data link connector (16-pin).
- (2) Check that the tone alarm of scan tool MB991502 sounds when the ignition switch (IG1) is turned to "ON" position.

Q: Does the tone alarm of scan tool MB991502 sound when the input signal enters?

YES : Go to Step 11.

NO : Go to Step 4.


**STEP 3. Check the ETACS-ECU input signal from the ignition switch (by using a voltmeter).**


- (1) Use special tool MB991529 to connect a voltmeter between ground terminal 4 or 5 and ETACS-ECU terminal 9 of the data link connector.
- (2) Check that the voltmeter indicator deflects once when the ignition switch (IG1) is turned to "ON" position.

Q: Does the voltmeter indicator deflect?

YES : Go to Step 11.

NO : Go to Step 4 .






STEP 4. Measure the ETACS-ECU power supply circuit ignition switch (IG1) at ETACS- ECU connector D-11.

- (1) Remove the ETACS-ECU, and measure at ETACS-ECU connector D-11 (junction block side).
- (2) Measure the voltage between terminal 3 and ground.

Q: Is the measured voltage approximately 12 volts (battery positive voltage)?

YES : Replace the ETACS-ECU and then go to Step 23.

NO : Go to Step 5.




STEP 5. Check ETACS-ECU connector D-11 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Q: Are the connector in good condition?

YES : Go to step 6.

NO : Repair or replace the damaged components. Refer to GROUP 00E [P.00E-2](#), Harness Connector inspection. Then go to Step 23.




STEP 6. Check the harness wire between ignition switch (IG1) and ETACS-ECU connector D-11.

NOTE: After inspecting junction block connector D-08 inspect the wires. If junction block connector D-08 is damaged, repair or replace it. Refer to GROUP 00E P.00E-2, Harness Connector Inspection. Then go to Step 23.

Q: Are the harness wire damaged?

- YES :** Repair or replace the harness wire, then go to Step 23.
- NO :** Go to Step 23.



STEP 7. Measure the power window relay continuity.

- (1) Remove the power window relay. (Refer to P.42-108.)
- (2) Follow the table to check the power window relay continuity.

BATTERY VOLTAGE	TESTER CONNECTION	SPECIFIED CONDITION
Not applied	1 – 3	Open circuit
<ul style="list-style-type: none">Connect terminal No. 2 to the positive battery terminalConnect terminal No. 4 to the negative battery terminal	1 – 3	Less than 2 ohms

Q: Does the measured resistance value correspond with this range?

- YES :** Go to Step 8.
- NO :** Replace power window relay, then go to Step 23.


STEP 8. Measure the power window relay supply circuit [ignition switch (IG1)] at the power window relay connector C-75X.

- (1) Remove the power window relay, and measure at the power window relay connector C-75X (relay box side).
- (2) Turn the ignition switch to "ON" position.
- (3) Measure the voltage between terminal 4 and ground.

Q: Is the measured voltage approximately 12 volts (battery positive voltage)?

YES : Go to Step 11.

NO : Go to Step 9.








STEP 9. Check ETACS-ECU connector D-26 and power window relay connector C-75X for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Q: Are the connectors in good condition?

YES : Go to step 10.

NO : Repair or replace the damaged components. Refer to GROUP 00E [P.00E-2](#), Harness Connector inspection. Then go to Step 23.





STEP 10. Check the harness wire between ETACS-ECU connector D-26 (terminal No.26) and power window relay connector C-75X (terminal No.4).

Q: Are the harness wire damaged?

YES : Repair or replace the harness wire, then go to Step 23.

NO : Replace the ETACS-ECU go to Step 23.

STEP 11. Measure the power window relay supply circuit at power window relay connector C-75X.

(1) Remove the power window relay, and measure at power window relay connector C-75X (relay box side).


(2) Measure the resistance between terminal 2 and ground.

Q: Is the measured resistance less than 2 ohms?

YES : Go to Step 14.

NO : Go to Step 12.

CONNECTOR: C-75X



AC202074 AB


STEP 12. Check the power window relay connectors C-75X and ground for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Q: Is the connector in good condition?

YES : Go to step 13.

NO : Repair or replace the damaged components. Refer to GROUP 00E [P.00E-2](#), Harness Connector inspection. Then go to Step 23.

CONNECTOR: C-75X



AC202074 AB


STEP 13. Check the harness wire between power window relay connector C-75X (terminal No.2) and ground.

Q: Is the harness wire damaged?

YES : Repair or replace the harness wire, then go to Step 23.

NO : Go to Step 23.

C-75X HARNESS CONNECTOR:
COMPONENT SIDE



AC005051 AC

STEP 14. Check the power window relay supply circuit [fusible link number 10] at power window relay connector C-75X.


(1) Remove the power window relay, and measure at power window relay connector C-75X (relay box side).

(2) Measure the voltage between terminal 3 and ground.

Q: Is the measured voltage approximately 12 volts (battery positive voltage)?

YES : Go to Step 17.

NO : Go to Step 15.




STEP 15. Check power window relay connector C-75X for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Q: Is the connector in good condition?

YES : Go to step 20.

NO : Repair or replace the damaged components. Refer to GROUP 00E [P.00E-2](#), Harness Connector inspection. Then go to Step 23.




STEP 16. Check the harness wire between fusible link number 10 and power window relay connector C-75X (terminal No.3).


NOTE: After inspecting intermediate connector C-41 inspect the wires. If intermediate connector C-41 is damaged, repair or replace it. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 23.

Q: Is the harness wire damaged?

YES : Repair or replace the harness wire, then go to Step 23.

NO : Go to Step 23.






STEP 17. Check the power supply circuit [fusible link number 10] at power window main switch connector F-05.

- (1) Disconnect power window main switch connector F-05, and measure at the harness side.
- (2) Turn the ignition switch to "ON" position.
- (3) Measure the voltage between terminal 13 and ground.
 - The measured value should be approximately 12 volts (battery positive voltage).

Q: Does the measured voltage correspond with this range?

YES : Go to Step 20.

NO : Go to Step 18.








STEP 18. Check power window relay connector C-75X and power window main switch connector F-05 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Q: Are the connectors in good condition?

YES : Go to step 19.

NO : Repair or replace the damaged components. Refer to GROUP 00E [P.00E-2](#), Harness Connector inspection. Then go to Step 23.





STEP 19. Check the harness wire between power window relay connector C-75X (terminal No.1) and power window main switch connector F-05 (terminal No.13).

NOTE: After inspecting intermediate connector C-40 inspect the wires. If intermediate connector C-40 is damaged, repair or replace it. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 23.

Q: Is the harness wire damaged?

YES : Repair or replace the harness wire, then go to Step 23.

NO : Go to Step 23.

STEP 20. Measure the power window main switch ground circuit at power window main switch connector F-05.


(1) Disconnect power window main switch connector F-05, and measure at the harness side.

(2) Measure the resistance between terminal 12 and ground.

Q: Is the measured resistance less than 2 ohms?

YES : Replace the power window main switch then go to Step 23 .

NO : Go to Step 21.




STEP 21. Check power window main switch connector F-05 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Q: Are the connectors in good condition?

YES : Go to Step 22.

NO : Repair or replace the damaged components. Refer to GROUP 00E [P.00E-2](#), Harness Connector inspection. Then go to Step 23.




STEP 22. Check the harness wire between power window main switch connector F-05 (terminal No.12) and ground.

NOTE: After inspecting intermediate connector C-40 inspect the wires. If intermediate connector C-40 is damaged, repair or replace it. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 23.

Q: Is the harness wire damaged?

YES : Repair or replace the harness wire, then go to Step 23.

NO : Go to Step 23.



STEP 23. Retest the system.


Q: Does the power window function operate normally?



YES : The procedure is complete.

NO : Return to Step 1.

INSPECTION PROCEDURE 2: Power Window Timer Function does not Work Normally. (Power Window Operates)

Front Door Switch Circuit





TECHNICAL DESCRIPTION (COMMENT)

The ETACS-ECU operates the power window timer function, based on input signals from the following switches:

- Ignition switch (IG1)
- Driver's or front passenger's door switch

If the power window timer function do not work normally, the input signal circuit or the ETACS-ECU may be defective.

TROUBLESHOOTING HINTS

- Malfunction of the front door switch
- Malfunction of the ignition switch
- Malfunction of the ETACS-ECU
- Damaged harness wires or connectors

DIAGNOSIS

Required Special Tools:


- MB991223: Test Harness Set
- MB991502: Scan Tool (MUT-II)
- MB991529: Diagnostic Trouble Code Check Harness

STEP 1. Choose method of the ETACS-ECU input signal check.

Q: Is the ETACS-ECU input signal check performed by scan tool MB991502 or a voltmeter?

By scan tool MB991502 : Go to Step 2.

By a voltmeter : Go to Step 3.

**STEP 2. Check the input signal (by using pulse check).**

Check the ETACS-ECU input signal (front door switch and ignition switch) by using scan tool MB991502.

Check the input signals from the following switches:

- Driver's door switch
- Front passenger's door switch
- ignition switch

⚠ CAUTION

To prevent damage to scan tool MB991502, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991502.


- (1) Connect scan tool MB991502 to the data link connector (16-pin).
- (2) Check that the tone alarm of the scan tool MB991502 sounds when driver's door switch or front passenger's door switch is operated <open (on)/depressed (off)>.

Q: Does the tone alarm of scan tool MB991502 sound when the input signal enters?

YES : Replace the ETACS-ECU and then go to Step 11.

NO <Driver's door switch and passenger's door switch input signal> : Go to Step 5.

NO <Ignition switch input signal> : Go to Step 8.


**STEP 3. Check the ETACS-ECU input signal from the driver's door switch and passenger's door switch (by using a voltmeter).**

- (1) Use special tool MB991529 to connect a voltmeter between ground terminal 4 or 5 and ETACS-ECU terminal 9 of the data link connector.
- (2) Check that the voltmeter indicator deflects once when driver's door switch or passenger's door switch operated <open (on)/depressed (off)>.

Q: Does the voltmeter indicator deflect?

YES : Go to Step 4.

NO : Go to Step 5 .


**STEP 4. Check the input signal from the ignition switch (by using a voltmeter).**

- (1) Use special tool MB991529 to connect a voltmeter between ground terminal 4 or 5 and ETACS-ECU terminal 9 of the data link connector.
- (2) Check that the voltmeter indicator deflects once when the ignition switch is operated <ACC - ON>.

Q: Does the voltmeter indicator deflect?

YES : Replace the ETACS-ECU and then go to Step 11.

NO : Go to Step 8 .



STEP 5. Check the front door switch.

- (1) Remove the driver's door or passenger's door switch (Refer to P.42-103.).
- (2) Follow the table to check the front door switch continuity.

SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
Released (ON)	1 – 2, 1 – 3, 2 – 3	Less than 2 ohms
Depressed (OFF)	1 – 2, 1 – 3, 2 – 3	Open circuit

Q: Is the front door switch in good condition?

YES : Go to Step 6 .



NO : Replace front door switch, then go to Step 11.


STEP 6. Check ETACS-ECU connector D-11, D-26 and driver's door switch connector E-33 and passenger's door switch connector E-46 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Q: Are ETACS-ECU connector D-11, D-26 and driver's door switch connector E-33, passenger's door switch E-46 in good condition?

YES : Go to step 7.

NO : Repair or replace the damaged components. Refer to GROUP 00E P.00E-2, Harness Connector inspection. Then go to Step 11.



CONNECTORS: D-11, D-14, D-26**D-11 COMPONENT SIDE**

1	2	1	1	0	9	8	7	6	5	4	3	2	1
---	---	---	---	---	---	---	---	---	---	---	---	---	---

D-26 COMPONENT SIDE

2	6	2	5	2	4	2	3	2	2	2	1
3	2	3	1	3	0	2	9	2	8	2	7

D-14 COMPONENT SIDE

7	6	5	4	○	3	2	1	
16	15	14	13	12	11	10	9	8

AC202081AB


STEP 7. Check the harness wire between ETACS-ECU connector D-11 (terminal No.9), D-26 (terminal No.26) and driver's door switch connectors E-33 (terminal No.2), passenger's side door switch connector E-46 (terminal No.2).

NOTE: After inspecting junction block connector D-14 and intermediate connector E-42 inspect the wire. If junction block connector D-14 or intermediate connector E-42 is damaged, repair or replace it. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 11.

Q: Are there any damaged harness wires between ETACS-ECU connector D-11 (terminal No.9), D-26 (terminal No.23) and driver's door switch connectors E-33 (terminal No.2), passenger's side door switch connector E-46 (terminal No.2)?


YES : Repair or replace the harness wire, then go to Step11.

NO : Replace the ETACS-ECU and then go to Step11.


CONNECTORS: E-33, E-42, E-46**E-33, E-46 COMPONENT SIDE**

2	1
---	---

E-42

1	2	3	4			5	6	7	8
9	10	11	12	13	14	15	16	17	18

AC202082AB




STEP 8. Check ETACS-ECU connector D-11 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Q: Is ETACS-ECU connector D-11 good condition?

YES : Go to Step 9.

NO : Repair or replace the damaged components. Refer to GROUP 00E [P.00E-2](#), Harness Connector inspection.



STEP 9. Check the harness wire between ETACS-ECU connector D-11 (terminal No.3) and ignition switch.

NOTE: After inspecting junction block connector D-08 inspect the wire. If junction block connector D-08 is damaged, repair or replace it. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 11.

Q: Are ETACS-ECU connector D-11 and ignition switch in good condition?

YES : Go to step 10.

NO : Repair or replace the harness wire. Refer to GROUP 00E [P.00E-2](#), Harness Connector inspection.

STEP 10. Retest the system.

Q: Does the power window timer function operate normally?

YES : The procedure is complete.

NO : Return to Step 1.

DOOR DIAGNOSIS**INTRODUCTION TO GLASS AND DOOR DIAGNOSIS**

M1423007300207

Glass and door faults include water leaks and improper opening and closing. Causes for these faults can include faults in the glass, weatherstrip, drain hole, waterproof film or door installation.

GLASS AND DOOR DIAGNOSTIC TROUBLESHOOTING STRATEGY

M1423006700202

Use these steps to plan your diagnostic strategy. If you follow them carefully, you will be sure that you have exhausted most of the possible ways to find a glass and door fault.

1. Gather information from the customer.

2. Verify that the condition described by the customer exists.

3. Find the malfunction by following the Symptom Chart.

4. Verify that the malfunction is eliminated.

SYMPTOM CHART

M1423007000228

SYMPTOM	INSPECTION PROCEDURE	REFERENCE PAGE
Water leak through door window glass	1	P.42-94
Door window malfunction	2	P.42-95
Water leak through door edge	3	P.42-95
Water leak from door center	4	P.42-95
Door hard to open	5	P.42-96
Door does not open or close completely.	6	P.42-96
Uneven gap between body	7	P.42-96
Wind noise around door	8	P.42-97

SYMPTOM PROCEDURES**INSPECTION PROCEDURE 1: Water Leak Through Door Window Glass****DIAGNOSIS**

STEP 1. Check the door window glass installation.

Q: Is the door window glass installed correctly?

YES : Go to Step 2.

NO : Adjust the door window glass. (Refer to [P.42-100.](#)) Then go to Step 3.

STEP 2. Check the clearance at the top of the window glass.

Q: Is the clearance at the top of the window glass correct?

YES : Go to Step 3.

NO : Adjust the door window glass. (Refer to [P.42-100.](#)) Then go to Step 3.

STEP 3. Retest the system.

Q: Is any water leaking?

YES : Return to Step 1.

NO : This procedure is complete.

INSPECTION PROCEDURE 2: Door Window Malfunction

DIAGNOSIS

STEP 1. Check the door window installation condition.

- Q: Is the door window installation condition good?**
YES : Go to Step 2.
NO : Adjust door window glass. (Refer to [P.42-100.](#)) Then go to Step 4.

STEP 2. Check the door sash.

- Q: Is the door sash in good condition?**
YES : Go to Step 3.
NO : Repair or replace door sash, then go to Step 4.

STEP 3. Inspect the window regulator assembly.

- Q: Is the window regulator assembly in good condition?**
YES : Go to Step 4.
NO : Replace door window regulator assembly, then go to Step 4.

STEP 4. Retest the system.

- Q: Does the door window operate correctly?**
YES : This procedure is complete.
NO : Return to Step 1.

INSPECTION PROCEDURE 3: Water Leak through Door Edge

DIAGNOSIS

STEP 1. Check the weatherstrip.

- Q: Is the weatherstrip in good condition?**
YES : Go to Step 2.
NO : Replace weatherstrip, then go to Step 3.

STEP 2. Check door fit (alignment).

- Q: Is the door fit (alignment) correct?**
YES : Go to Step 3.
NO : Adjust door fit. (Refer to [P.42-100.](#)) Then go to Step 3.

STEP 3. Retest the system.

- Q: Is any water leaking?**
YES : Return to Step 1.
NO : This procedure is complete.

INSPECTION PROCEDURE 4: Water Leak From Door Center

DIAGNOSIS

STEP 1. Check the drain hole.

- Q: Is the drain hole clogged?**
YES : Cleaning door hole, then go to Step 3.
NO : Go to Step 2.

STEP 2. Check the waterproof film.

- Q: Is the waterproof film in good condition?**
YES : Go to Step 3.
NO : Repair or replace waterproof, then go to Step 3.

STEP 3. Retest the system.

- Q: Is any water leaking?**
YES : Return to Step 1.
NO : This procedure is complete.

INSPECTION PROCEDURE 5: Door Hard to Open

DIAGNOSIS

STEP 1. Adjust the latch and striker engagement.
(Refer to [P.42-100.](#))

- Q: Is the latch and striker engagement adjusted?**
YES : Go to Step 2.
NO : Adjust the door fit. (Refer to [P.42-100.](#))
Then go to Step 4.

STEP 2. Check for possible lock rod damage.

- Q: Is the possible lock rod damaged?**
YES : Repair or replace the possible lock rod, then go to Step 4.
NO : Go to Step 3.

STEP 3. Check door handle flexibility (amount of movement of handle required to open door).

- Q: Is the door handle flexibility good?**
YES : Go to Step 4.
NO : Adjust inside handle play (Refer to [P.42-102](#)) and adjust outside handle play [P.42-101](#)). Then go to Step 4.

STEP 4. Retest the system.

- Q: Does the door open easily?**
YES : This procedure is complete.
NO : Return to Step 1.

INSPECTION PROCEDURE 6: Door does not Open or Close Completely.

DIAGNOSIS

STEP 1. Check the door hinge position.

- Q: Is the door hinge position correct?**
YES : Go to Step 2.
NO : Adjust door hinge position. (Refer to [P.42-100.](#)) Then go to Step 4.

STEP 2. Check the door.

- Q: Is the door in good condition?**
YES : Go to Step 3.
NO : Repair or replace door assembly, then go to Step 4.

STEP 3. Check the grease.

- Q: Is the door check or door hinge grease sufficient?**
YES : Go to Step 4.
NO : Apply the grease, then go to Step 4.

STEP 4. Retest the system.

- Q: Does the door open and close correctly?**
YES : This procedure is complete.
NO : Return to Step 1.

INSPECTION PROCEDURE 7: Uneven Gap Between Body

DIAGNOSIS

Adjust the door fit. (Refer to [P.42-100.](#)) Then check that the gap has been improved.

INSPECTION PROCEDURE 8: Wind Noise Around Door

DIAGNOSIS

STEP 1. Check the weatherstrip for holding condition.

- Q: Is the weatherstrip and molding installed properly?**
YES : Go to Step 2.
NO : Replace the weatherstrip and molding.
 Then go to Step 5.

STEP 2. Check the weatherstrip and molding for installation condition.

- Q: Is the weatherstrip installed properly?**
YES : Go to Step 3.
NO : Replace the weatherstrip and molding.
 Then go to Step 5.

STEP 3. Check the clearance.

- Q: Is the clearance between the door glass and the door weatherstrip holder proper?**
YES : Go to Step 4.
NO : Go to Step 5.

STEP 4. Check the door.

- Q: Is the door deformed?**
YES : Repair or replace door assembly. Then go to Step 5.
NO : Go to Step 5.



STEP 5. Retest the system.




- Q: Has the wind noise been improved?**
YES : Return to Step 1.
NO : This procedure is complete.

HOW TO LOCATE WIND NOISES

M1421004200164

1. Attach cloth tape to every place, such as panel seams, projections, molding seams, glass and body seams, etc. which might conceivably be the source of wind noise.
2. Then make a road test to check that the places not covered by tape are not sources of wind noise.
3. Remove the strips of tape one by one, making a road test after each is removed, until a wind noise source is discovered.








4. When such a place is found, cover it again and repeat the procedure to check if there are any other noise source.
5. If no others are found, the last remaining tape is the only source.
6. Cut the remaining piece of tape into smaller pieces, attach it again as it was before, and then remove the pieces one by one to narrow down the source.
7. Check that wind noise occurs when the last remaining tape is removed, and that noise does not occur when it is re-attached.
8. When the sources of the wind noise is finally located, attach butyl tape, body sealer or similar material to obstruct this source as much as possible.

SPECIAL TOOLS


M1423000600229

TOOL	TOOL NUMBER AND NAME	SUPERSESION	APPLICATION
 MB990900	MB990900 or MB991164 Door adjusting wrench	MB990900-01	Adjustment of door fit
 MB990784	MB990784 Ornament remover	General service tool	Removal of trim, etc.
 MB991223AD	MB991223 Harness set A: MB991219 Test harness B: MB991220 LED harness C: MB991221 LED harness adapter D: MB991222 Probe	MB991223	Measurement of terminal voltage A: Connector pin contact pressure inspection B: Power circuit inspection C: Power circuit inspection D: Commercial tester connection


ON-VEHICLE SERVICE

DOOR FIT ADJUSTMENT

M1423001100108



AC003774



AC003775


1. If the clearance between the door and body is uneven, remove the splash shield, loosen the mounting bolt of the body side door hinges from inside the fender, and then move the door to adjust so that the clearance is even.
2. If there is a step between the door and body, loosen the mounting bolts and nuts of the door hinges, and adjust the door alignment.
3. If the striker and latch do not engage properly, move the striker up and down or to the left and right.

DOOR WINDOW GLASS ADJUSTMENT

M1423001000190

Check that the door glass moves while contacting the door glass channel when it is raised and lowered fully. If not, adjust the door window according to the following procedures.

1. Remove the door trim and waterproof film. (Refer to [P.42-105.](#))
2. Raise the window glass, loosen the channel guide mounting bolts and adjust the vertical tilt of the glass.



AC003776AB

ADJUSTMENT AND REPLACEMENT WHEN THERE IS A MALFUNCTION OF THE POWER WINDOWS

M1429000900057

If the window glass automatically starts moving downwards at the wrong time while it is being raised, carry out the following adjustment or replacement procedures.

1. Remove the door trim and waterproof film. (Refer to P.42-105.)


NOTE: Insert a cushion or similar object to prevent damage to the glass if it should happen to fall down.

2. Remove the window regulator assembly from the door window glass, and then raise and lower the door window glass by hand to check the operation force.
3. If the door window glass does not move up and down smoothly, check or repair the following points.

- Check the installation condition of the runchannel.
- Repair any twisting in the door sash.
- Check the installation condition of the lower sash or the center sash.

NOTE: The lower sash cannot normally be adjusted, but it may be possible to adjust the sash span slightly within the range allowed by manufacturing tolerances by pushing the lower sash outwards while re-installing it.

4. If repair or adjustment is not possible, replace the door assembly.




DOOR OUTSIDE HANDLE PLAY CHECK


M1423001600170

1. Check that the door outside handle play is within the standard value range.

Standard value (B): 2.8 mm (0.11 inch) or more

2. If the door outside handle play is not within the standard value range, check the door outside handle or the door latch assembly. Replace if necessary.





POWER WINDOW OPERATING CURRENT CHECK

M1429001100098

1. Remove the power window fuse and connect an ammeter as shown in the illustration.
2. When the power window switch is pressed to the "UP" position, a large amount of current flows at the time the window starts to close and when it is fully closed, so measure the operation current in the interval between these two points.

Standard value: 7 A or more [at 20°C (68°F)]

3. If the operation current is outside the standard value, refer to Power Window Diagnosis [P.42-75](#).


CIRCUIT BREAKER (INCORPORATED IN THE POWER WINDOW MOTOR) CHECK

M1429001000165

1. Pull the power window switch to the UP position to fully close the door window glass, and keep pulling the switch for 10 additional seconds.
2. Release the power window switch from the UP position and immediately press it to the DOWN position. The condition of the circuit breaker is good if the door window glass starts to move downwards within 60 seconds.

DOOR INSIDE HANDLE PLAY CHECK AND ADJUSTMENT

M1423001500173



1. Check that the door inside handle play is within the standard value range.

Standard value (A): 7.3 mm (0.29 inch) or more


2. If the door inside handle play is outside the standard value range, remove the door trim. (Refer to [P.42-105](#)).
3. Loosen the inside handle mounting screws, and then move the inside handle back and forth to adjust the play.

DOOR ASSEMBLY REMOVAL AND INSTALLATION


M1423002200175

Post-installation Operation


- Door Fit Adjustment (Refer to [P.42-100.](#))



FRONT DOOR



REAR DOOR



DOOR ASSEMBLY REMOVAL STEPS

1. HARNESS CONNECTOR
2. SPRING PIN
3. DOOR ASSEMBLY
- >>A<< 4. DOOR UPPER HINGE
- >>A<< 5. DOOR LOWER HINGE

STRIKER REMOVAL STEPS

6. STRIKER


DOOR SWITCH REMOVAL STEPS

7. DOOR SWITCH CAP
8. DOOR SWITCH

INSTALLATION SERVICE POINT

>>A<< DOOR LOWER HINGE/DOOR UPPER HINGE
INSTALLATION

The door hinges differ according to where they are used, so check the identification marks before installation.




APPLICABLE LOCATION		IDENTIFICATION MARK
Front left side door	Upper hinge	F1
	Lower hinge	E1
Front right side door	Upper hinge	E1
	Lower hinge	F1
Rear left side door	Upper hinge	A1
	Lower hinge	B1
Rear right side door	Upper hinge	B1
	Lower hinge	A1

INSPECTION

M1423006000225


DOOR SWITCH CONTINUITY CHECK

TYPE1



SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
Released (ON)	1 – 2, 1 – 3, 2 – 3	Less than 2 ohms
Depressed (OFF)	1 – 2, 1 – 3, 2 – 3	Open circuit



TYPE2



SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
Released (ON)	1 – 2	Less than 2 ohms
Depressed (OFF)	1 – 2	Open circuit

DOOR TRIM AND WATERPROOF FILM REMOVAL AND INSTALLATION

M1423004300189



NOTE
← : Resin clip position


<<A>>

REMOVAL STEPS

1. PULL HANDLE BOX
2. COVER
3. DOOR LIGHT
5. HARNESS CONNECTOR
6. POWER WINDOW SWITCH ASSEMBLY
7. INNER DELTA COVER
8. DOOR TRIM

REMOVAL STEPS (Continued)

11. SPEAKER BRACKET
12. TWEETER
13. DOOR INSIDE HANDLE
14. PULL HANDLE BRACKET
15. SPEAKER
16. SPEAKER COVER
17. WATERPROOF FILM

**REMOVAL STEPS**

1. PULL HANDLE BOX
2. COVER
4. ASHTRAY
5. HARNESS CONNECTOR
8. DOOR TRIM
9. POWER WINDOW SWITCH
10. POWER WINDOW SWITCH COVER
13. DOOR INSIDE HANDLE

REMOVAL STEPS (Continued)


14. PULL HANDLE BRACKET
15. SPEAKER
16. SPEAKER COVER
17. WATERPROOF FILM

Required Special Tool:

- MB990784: Ornament Remover

REMOVAL SERVICE POINT**<<A>> POWER WINDOW SWITCH ASSEMBLY**

There is a clip (driver's side) or a claw (other sides) on the front of the power window switch assembly. Work from the front side using special tool MB990784.




INSPECTION

M1429001600178

POWER WINDOW SWITCH CONTINUITY CHECK


POWER WINDOW MAIN SWITCH CHECK



SWITCH POSITION		TESTER CONNECTION	SPECIFIED CONDITION
FRONT (LH)	UP	8 – 13 9 – 12	Less than 2 ohms
	OFF	8 – 12 9 – 12	Less than 2 ohms
	DOWN	8 – 12 9 – 13	Less than 2 ohms
FRONT (RH)	UP	11 – 12* 3 – 13	Less than 2 ohms
	OFF	11 – 12* 3 – 12	Less than 2 ohms
	DOWN	11 – 13 3 – 12*	Less than 2 ohms
REAR (LH)	UP	1 – 13 2 – 12*	Less than 2 ohms
	OFF	2 – 12* 1 – 12*	Less than 2 ohms
	DOWN	2 – 13 1 – 12*	Less than 2 ohms
REAR (RH)	UP	13 – 14 6 – 12*	Less than 2 ohms
	OFF	6 – 12* 12 – 14	Less than 2 ohms
	DOWN	6 – 13, 12 – 14*	Less than 2 ohms

NOTE: *:Set switch to UNLOCK position.

POWER WINDOW SUB SWITCH CHECK



SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
UP	5 – 7 6 – 8	Less than 2 ohms
OFF	4 – 7 6 – 8	Less than 2 ohms
DOWN	4 – 7 5 – 6	Less than 2 ohms

DOOR GLASS AND REGULATOR REMOVAL AND INSTALLATION

M1429001300207




<FRONT DOOR>

Pre-removal Operation

- Door Trim and Waterproof Film Removal (Refer to [P.42-105.](#))
- Door Mirror Removal (Refer to [P.51-26.](#))

Post-installation Operation

- Door Trim and Waterproof Film Installation (Refer to [P.42-105.](#))
- Door Mirror Installation (Refer to [P.51-26.](#))
- Door Window Glass Adjustment (Refer to [P.42-100.](#))



AC003785AB

POWER WINDOW RELAY REMOVAL STEPS

- DRIVER'S SIDE UNDER COVER
(REFER TO GROUP 52A,
INSTRUMENT PANEL [P.52A-32.](#))
1. POWER WINDOW RELAY
<VEHICLES WITH POWER
WINDOWS>

FRONT WINDOW REGULATOR ASSEMBLY REMOVAL STEPS

2. DOOR BELTLINE INNER
WEATHERSTRIP
3. DOOR BELTLINE MOLDING
ASSEMBLY
4. DOOR WINDOW GLASS
RUNCHANNEL
6. DOOR WINDOW GLASS
- >>B<< 7. DOOR GLASS HOLDER
8. DOOR GLASS PAD
9. WINDOW REGULATOR ASSEMBLY
- >>A<< 10. REAR LOWER SASH


<REAR DOOR>

Pre-removal Operation

- Door Trim and Waterproof Film Removal (Refer to P.42-105.)

Post-installation Operation

- Door Trim and Waterproof Film Installation (Refer to P.42-105.)
- Door Window Glass Adjustment (Refer to P.42-100.)



AC003786AB

REMOVAL STEPS

2. DOOR BELTLINE INNER WEATHERSTRIP
3. DOOR BELTLINE MOLDING ASSEMBLY
4. DOOR WINDOW GLASS RUNCHANNEL
5. DOOR CENTER SASH
6. DOOR WINDOW GLASS
7. DOOR GLASS HOLDER
8. DOOR GLASS PAD

REMOVAL STEPS (Continued)

9. POWER WINDOW REGULATOR ASSEMBLY
9. WINDOW REGULATOR ASSEMBLY
11. STATIONARY WINDOW GLASS AND WEATHERSTRIP ASSEMBLY
12. STATIONARY WINDOW GLASS AND WEATHERSTRIP ASSEMBLY
13. STATIONARY WINDOW WEATHERSTRIP


<<A>>

>>B<<

REMOVAL SERVICE POINT

<<A>> DOOR CENTER SASH REMOVAL (REAR DOOR)

1. Remove the door outer opening weatherstrip from the door center sash section only.
2. Remove the mounting screw for the door center sash, and remove the door center sash from the door panel.



INSTALLATION SERVICE POINT


>>A<< REAR LOWER SASH INSTALLATION

Securely insert the rear lower sash into the window rear sash.

>>B<< DOOR GLASS HOLDER INSTALLATION

Install the glass pad and the glass holders to the window glass as shown in the illustration.


Standard value: (A) 106.7 – 108.2 mm (4.20 – 4.26 inches) (B) 417.5 – 420.5 mm (16.44 – 16.56 inches) (C) 127 – 131 mm (5.0 – 5.2 inches)



INSPECTION

M1429001400185

POWER WINDOW RELAY CONTINUITY CHECK



BATTERY VOLTAGE	TESTER CONNECTION	SPECIFIED CONDITION
Not applied	1 – 3	Open circuit
<ul style="list-style-type: none"> Connect terminal 2 to the positive battery terminal Connect terminal 4 to the positive battery terminal 	1 – 3	Less than 2 ohms

POWER WINDOW MOTOR CHECK

1. Connect a battery directly to the motor terminals and check that the motor runs smoothly.
2. Check that the motor runs in the opposite direction when the battery is connected with the polarity reversed.
3. If defect is found, replace the window regulator as an assembly.

DOOR HANDLE AND LATCH REMOVAL AND INSTALLATION



M1423004600210

Pre-removal Operation

- Door Trim Removal (Refer to [P.42-105.](#))

Post-installation Operation

- Door Inside Handle Play Check (Refer to [P.42-102.](#))
- Door Outside Handle Play Check (Refer to [P.42-101.](#))
- Door Trim Installation (Refer to [P.42-105.](#))
- Door Fit Adjustment (Refer to [P.42-100.](#))



AC003790AB

DOOR HANDLE AND DOOR LATCH ASSEMBLY REMOVAL STEPS

1. DOOR INSIDE HANDLE
 - WATERPROOF FILM (REFER [P.42-105.](#))
3. DOOR OUTSIDE HANDLE
4. DOOR LOCK KEY CYLINDER
- >>B<< 5. REAR LOWER SASH
6. DOOR LATCH ASSEMBLY

REAR DOOR HANDLE AND DOOR LATCH ASSEMBLY REMOVAL STEPS

1. DOOR INSIDE HANDLE
 - WATERPROOF FILM (REFER [P.42-105.](#))


>>C<< 2. REAR DOOR LOCK ACTUATOR ASSEMBLY

3. DOOR OUTSIDE HANDLE
6. DOOR LATCH ASSEMBLY

DOOR CHECK REMOVAL STEPS

7. SPRING PIN
 - >>A<< 8. DOOR CHECK
- ### ETACS-ECU REMOVAL
9. ETACS-ECU

INSTALLATION SERVICE POINT



>>A<< DOOR CHECK INSTALLATION

Install the door check so that the identification mark faces upwards.


ITEM		IDENTIFICATION MARK
Front Door	Left door	19L
	Right door	19L
Rear Door	Left door	25L
	Right door	25R

>>B<< REAR LOWER SASH INSTALLATION

Securely insert the rear lower sash into the window rear sash.

>>C<< REAR DOOR LOCK ACTUATOR INSTALLATION

1. Lock the inside lock knob.
2. Lock the actuator lever and install.
3. Fit the clip into the inside lock rod.




INSPECTION

FRONT DOOR LOCK ACTUATOR CHECK

Actuator Operation Check <Left side>

LEVER POSITION	BATTERY CONNECTION	LEVER OPERATION
At the "UNLOCK" position	<ul style="list-style-type: none">Connect terminal No. 6 and the positive battery terminal.Connect terminal No. 4 and the negative battery terminal.	The lever moves from the "UNLOCK" position to the "LOCK" position.
At the "LOCK" position	<ul style="list-style-type: none">Connect terminal No. 4 and the positive battery terminal.Connect terminal No. 6 and the negative battery terminal.	The lever moves from the "LOCK" position to the "UNLOCK" position.



Actuator Switch Continuity Check <Left side>


SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
At the "UNLOCK" position	1 - 3	Less than 2 ohms
At the "LOCK" position	1 - 2	Less than 2 ohms

Actuator Operation Check <Right side>

LEVER POSITION	BATTERY CONNECTION	LEVER OPERATION
At the "UNLOCK" position	<ul style="list-style-type: none">Connect terminal No. 4 and the positive battery terminal.Connect terminal No. 6 and the negative battery terminal.	The lever moves from the "UNLOCK" position to the "LOCK" position.
At the "LOCK" position	<ul style="list-style-type: none">Connect terminal No. 6 and the positive battery terminal.Connect terminal No. 4 and the negative battery terminal.	The lever moves from the "LOCK" position to the "UNLOCK" position.

Actuator Switch Continuity Check <Right side – Vehicles with keyless entry system only>


SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
At the LOCK position	2 – 3	Less than 2 ohms
At the UNLOCK position	1 – 3	Less than 2 ohms

REAR DOOR LOCK ACTUATOR CHECK**Actuator Operation Check**

LEVER POSITION	BATTERY CONNECTION	LEVER OPERATION
At the "B" position	<ul style="list-style-type: none"> Connect terminal No. 1 and the positive battery terminal. Connect terminal No. 2 and the negative battery terminal. 	The lever moves from the "B" position to the "C" position.
At the "C" position	<ul style="list-style-type: none"> Connect terminal No. 2 and the positive battery terminal. Connect terminal No. 1 and the negative battery terminal. 	The lever moves from the "C" position to the "B" position.

Actuator Switch Continuity Check <Vehicles with keyless entry system>

ACTUATOR	SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
LH side	At the C position	3 – 4	Less than 2 ohms
RH side	At the B position	3 – 5	Less than 2 ohms

**DOOR LOCK KEY CYLINDER SWITCH
CONTINUITY CHECK****<DRIVER'S SIDE>**


SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
At the LOCK position	2 – 3	Less than 2 ohms
At the NEUTRAL (OFF) position	1 – 2 2 – 3	Open circuit
At the UNLOCK position	1 – 2	Less than 2 ohms

<PASSENGER'S SIDE>


SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
At the LOCK position	2 – 3	Less than 2 ohms
At NEUTRAL (OFF) position	1 – 2 2 – 3	Open circuit
At the UNLOCK position	1 – 2	Less than 2 ohms

CENTER DOOR LOCK SWITCH CONTINUITY CHECK

Remove the power window switch. (Refer to [P.42-105.](#))

Driver's side

SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
At the LOCK position	5 – 12	Less than 2 ohms
At the OFF position	5 – 12 10 – 12	Open circuit
At the UNLOCK position	10 – 12	Less than 2 ohms


Passenger's side

SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
At the LOCK position	1 – 2	Less than 2 ohms
At the OFF position	1 – 2 2 – 3	Open circuit
At the UNLOCK position	2 – 3	Less than 2 ohms


WINDOW GLASS RUNCHANNEL AND DOOR OPENING WEATHER-STRIP REMOVAL AND INSTALLATION

M1423003100182

FRONT DOOR



REAR DOOR



AC003794AB

DOOR INNER OPENING WEATHERSTRIP REMOVAL STEPS

- FRONT SCUFF PLATE, REAR SCUFF PLATE, CENTER PILLAR LOWER TRIM AND COWL SIDE TRIM (REFER TO GROUP 52A, TRIMS [P.52A-36.](#))

1. DOOR INNER OPENING WEATHERSTRIP

DOOR OUTER OPENING WEATHERSTRIP REMOVAL

<<A>> >>A<<

2. SPRING PIN
3. DOOR OUTER OPENING WEATHERSTRIP

DOOR WINDOW GLASS RUNCHANNEL REMOVAL STEPS

4. DOOR WINDOW GLASS RUNCHANNEL

DOOR BELTLINE INNER WEATHERSTRIP REMOVAL STEPS

- DOOR TRIM (REFER TO [P.42-105.](#))
- 5. DOOR BELTLINE INNER WEATHERSTRIP


DOOR BELTLINE INNER WEATHERSTRIP REMOVAL STEPS

- DOOR MIRROR (REFER TO GROUP 51, DOOR MIRROR [P.51-26.](#))
- 6. DOOR BELTLINE OUTER WEATHERSTRIP

REMOVAL SERVICE POINT

<<A>> DOOR OUTER OPENING WEATHERSTRIP REMOVAL

Make a tool as shown and remove the door opening weather-strip.



INSTALLATION SERVICE POINT**>>A<< DOOR OUTER OPENING WEATHERSTRIP INSTALLATION**

The clip color identifies the left and right weatherstrips, so be sure to use the colors so as to install correctly.

APPLICABLE SIDE	IDENTIFICATION COLOR
Left door	Brown or yellow
Right door	Natural (White)

LIFTGATE**LIFTGATE DIAGNOSIS****INTRODUCTION TO LIFTGATE DIAGNOSIS**

M1424002500094

Refer to [P.42-75](#).

LIFTGATE DIAGNOSTIC TROUBLESHOOTING STRATEGY

M1424002600091

Use these steps to plan your diagnostic strategy. If you follow them carefully, you will be sure that you have exhausted most of the possible ways to find a liftgate fault.

1. Gather information from the customer.
2. Verify that the condition described by the customer exists.
3. Find the malfunction by following the Symptom Chart.
4. Verify that the malfunction is eliminated.

SYMPTOM CHART

M1424002700106

SYMPTOM	INSPECTION PROCEDURE	REFERENCE PAGE
Liftgate hard to open	1	P.42-96
Liftgate does not open or close completely.	2	P.42-96
Uneven gap between body	3	P.42-96

SYMPTOM PROCEDURES**INSPECTION PROCEDURE 1: Liftgate Hard to Open****DIAGNOSIS**

STEP 1. Adjust the latch and striker engagement.
(Refer to [P.42-119](#).)

Q: Is the latch and striker engagement adjusted?

YES : Go to Step 2.

NO : Adjust lift gate. (Refer to [P.42-119](#).) Then go to Step 4.

STEP 2. Check for possible lock rod damage.


Q: Is the possible lock rod damaged?

YES : Repair or replace possible lock rod, then go to Step 4.

NO : Go to Step 3.

STEP 3. Check liftgate handle flexibility (amount of movement of handle required to open liftgate).**Q: Is the liftgate handle flexibility good?****YES :** Go to Step 4.**NO :** Adjust lift gate handle play. (Refer to [P.42-119.](#)) Then go to Step 4.**STEP 4. Retest the system.****Q: Does the liftgate open easily?****YES :** This procedure is complete.**NO :** Return to Step 1.**INSPECTION PROCEDURE 2: Liftgate does not Open or Close Completely.****DIAGNOSIS****STEP 1. Check the liftgate hinge position.****Q: Is the liftgate hinge position correct?****YES :** Go to Step 2.**NO :** Adjust lift gate position. (Refer to [P.42-119.](#)) Then go to Step 4.**STEP 2. Check the liftgate.****Q: Is the liftgate in good condition?****YES :** Go to Step 3.**NO :** Repair or replace lift gate assembly, then go to Step 4.**STEP 3. Check the grease.****Q: Is the door hinge grease sufficient?****YES :** Go to Step 4.**NO :** Apply the grease, then go to Step 4.**STEP 4. Retest the system.****Q: Does the liftgate open and close correctly?****YES :** This procedure is complete.**NO :** Return to Step 1.**INSPECTION PROCEDURE 3: Uneven Gap between Body****DIAGNOSIS**Adjust the liftgate fit. (Refer to [P.42-119.](#)) Then check that the gap has been improved.**SPECIAL TOOL**


M1424000600103

TOOL	TOOL NUMBER AND NAME	SUPERSESSION	APPLICATION
 MB990784	MB990784 Ornament remover	General service tool	Removal of liftgate trim


ON-VEHICLE SERVICE

LIFTGATE FIT ADJUSTMENT


M1424000900074



1. If the striker and latch do not mesh properly, move the striker up and down and to the left and right.




2. If the clearance around the liftgate is not even when the liftgate is closed, move the liftgate hinge forward and back or to the left and right.



3. Check the fitting of the damper male when the liftgate is closed. If the position is not correct, move the damper male forward and back.

LIFTGATE HANDLE PLAY CHECK

M1424002400064



1. Check the back boor handle play.
Standard value (B): 1.5 – 5.5 mm (0.06 – 0.22 inches)
2. If the play is not within the standard value range, check and replace the liftgate handle or the liftgate latch assembly.

LIFTGATE

REMOVAL AND INSTALLATION

M1424001100101

CAUTION


- Do not disassemble or throw the liftgate gas spring into fire.
- Punch a hole in the gas spring before disposal to release the gas inside.
- Ensure the liftgate gas spring piston rod does not come into contact with foreign material.

Pre-removal Operation




- Rear Headlining Removal (Refer to GROUP 52A, Headlining [P.52A-37.](#))

Post-installation Operation

- Rear Headlining Installation (Refer to GROUP 52A, Headlining [P.52A-37.](#))
- Liftgate Fit Adjustment (Refer to [P.42-119.](#))



AC003799AB

**REMOVAL STEPS**

1. HARNESS CONNECTOR
2. REAR WINDOW WASHER TUBE CONNECTION
3. LIFTGATE GAS SPRING
4. LIFTGATE ASSEMBLY
5. LIFTGATE BUMPER

REMOVAL STEPS (Continued)



6. LIFTGATE HINGE
7. DAMPER MALE
8. DAMPER MALE
9. STRIKER

>>A<<

INSTALLATION SERVICE POINT

>>A<< LIFTGATE OPENING WEATHERSTRIP INSTALLATION


1. Check the identification color, and then align the positioning mark with the top center of the liftgate to install the weatherstrip.



2. Check that the liftgate opening weatherstrip joint is centered.

LIFTGATE TRIM AND WATERPROOF FILM REMOVAL AND INSTALLATION

M1424001400094



AC003802AB

REMOVAL STEPS

1. COVER <VEHICLES WITH HIGH-MOUNTED STOPLIGHT>
2. LIFTGATE UPPER TRIM <LH>

REMOVAL STEPS (Continued)

3. LIFTGATE UPPER TRIM <RH>
4. LIFTGATE LOWER TRIM
5. WATERPROOF FILM

LIFTGATE HANDLE AND LATCH REMOVAL AND INSTALLATION


M1424001700095

Pre-removal Operation

- Liftgate Garnish Removal (Refer to GROUP 51, Grill, Molding and Garnish P.51-6.)
- Liftgate Trim and Waterproof Film Removal (Refer to P.42-122.)



Post-installation Operation

- Liftgate Handle Play Inspection (Refer to P.42-119.)
- Liftgate Trim and Waterproof Film Installation (Refer to P.42-122.)
- Liftgate Garnish Installation (Refer to GROUP 51, Grill, Molding and Garnish P.51-6.)



LIFTGATE LOCK KEY CYLINDER REMOVAL STEPS

1. LIFTGATE HANDLE
2. CYLINDER LOCK RETAINER
3. LIFTGATE LOCK KEY CYLINDER



AC003803AB


LIFTGATE LATCH REMOVAL STEPS

4. LIFTGATE LOCK ACTUATOR
5. HOLDER
6. LIFTGATE LATCH ASSEMBLY

INSPECTION

LIFTGATE LOCK ACTUATOR CHECK

Actuator Operation Check




LEVER POSITION	BATTERY CONNECTION	LEVER OPERATION
At the "LOCK" position	<ul style="list-style-type: none"> Connect terminal No. 1 to the positive battery terminal Connect terminal No. 2 to the negative battery terminal 	The lever moves from the "LOCK" position to the "UNLOCK" position.
At the "UNLOCK" position	<ul style="list-style-type: none"> Connect terminal No. 2 to the positive battery terminal Connect terminal No. 1 to the negative battery terminal 	The lever moves from the "UNLOCK" position to the "LOCK" position.

Actuator Switch Check

<Vehicles with keyless entry system>

SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
At the "LOCK" position	3 – 5	Less than 2 ohms
At the "UNLOCK" position	4 – 5	Less than 2 ohms

LIFTGATE LOCK KEY CYLINDER SWITCH CHECK



SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
At the "LOCK" position	1 – 2	Less than 2 ohms
NEUTRAL (OFF)	1 – 2 2 – 3	Open circuit
At the "UNLOCK" position	2 – 3	Less than 2 ohms

KEYLESS ENTRY SYSTEM

GENERAL INFORMATION

Some models are equipped with a keyless entry system. The main features are:

- The antenna is incorporated in the keyless entry receiver-ECU.
- ID code can be registered by using the scan tool (MUT-II).
- Transmitter is a key holder type, which incorporates lock switch, unlock switch, and panic switch.

M1428000100155

- The locking is answered back by two times' flashing of the room lamp, two times' flashing of the turn signal lamp and one time sounding of the horn answerback.
- The unlocking is answered back by illuminating of the room lamp for 15 seconds and one time flashing of the turn signal lamp.

KEYLESS ENTRY SYSTEM DIAGNOSIS

INTRODUCTION TO KEYLESS ENTRY SYSTEM DIAGNOSIS

A signal is transmitted from the transmitter to the keyless entry receiver-ECU. If the signal corresponds with that stored in the keyless entry receiver-ECU, the ECU send a signal to the ETACS-ECU. Then the door lock/unlock control is operated. When doors are locked, the dome light, the cargo space light and hazard warning lights will flash twice when doors are unlock, the dome light, the cargo space light will come on and dim after 15 seconds, and the hazard warning lights flash once.

M1428002600037

If the following type of symptom occurs, there may be a fault.

- All the doors cannot be locked or unlocked when the transmitter is operated.
- The secret code cannot be registered.
- The dome light, the cargo space light and the hazard warning lights do not operate through the answerback function.

KEYLESS ENTRY SYSTEM DIAGNOSTIC TROUBLESHOOTING STRATEGY

M1428001500037

Use these steps to plan your diagnostic strategy. If you follow them carefully, you will be sure that you have exhausted most of the possible ways to find a keyless entry system fault.

1. Gather information from customer.

2. Verify that the condition described by the customer exists.
3. Find the malfunction by following the Symptom Chart.
4. Verify that the malfunction is eliminated.


SYMPTOM CHART

M1428001800050

SYMPTOM		INSPECTION PROCEDURE	REFERENCE PAGE
Communication with scan tool is not possible.	Communication with all system is not possible.	–	Refer to GROUP 13AD, Symptom Procedure P.13Ad-2
	The ETACS-ECU input signal can not be detected by the scan tool.	–	P.42-21
All of the doors can not be locked or unlocked using the transmitter. (However, the central door lock system operates normally.)		1	P.42-126
The secret code cannot be registered.		2	P.42-128
The dome light, the cargo space light and the hazard warning lights do not operate through the answerback function. (However, the dome light, the cargo space light and the hazard warning lights operates normally.)		3	P.42-129
The horn do not operate through the answerback function.		–	Refer to GROUP 54 P.54-159

SYMPTOM PROCEDURES

INSPECTION PROCEDURE 1: All of the Doors can not be Locked or Unlocked Using the Transmitter. (However, the Central Door Lock System Operates Normally.)

W9802M05A
AC004797AB**CIRCUIT OPERATION**

The keyless entry receiver-ECU receives the lock/unlock signal from the transmitter.

TECHNICAL DESCRIPTION (COMMENT)

The cause may be a malfunction of the receiver and transmitter communication system.

TROUBLESHOOTING HINTS

- Malfunction of the keyless entry receiver-ECU
- Malfunction of the transmitter

DIAGNOSIS

Required Special Tool:

- MB991502: Scan Tool (MUT-II)
- MB991529: Diagnostic Trouble Code Check Harness

STEP 1. Select a tester.

Q: Do you use scan tool MB991502?

YES : Go to Step 2.

NO : Go to Step 3.

STEP 2. Check the input signal (by pulse check).

Check the keyless entry receiver-ECU input signal by using scan tool MB991502.

CAUTION


To prevent damage to scan tool MB991502, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991502.

- (1) Connect scan tool MB991502 to the data link connector (16-pin).
- (2) If the tone alarm of scan tool MB991502 sounds once when the transmitter's lock/unlock switches are operated, the keyless entry receiver-ECU input signal for switch circuits are normal.

Q: Is the input signal of transmitter normal?

YES : Go to Step 5.

NO : Go to Step 4.




STEP 3. Check the keyless entry receiver-ECU input signal (by using a voltmeter).


- (1) Use special tool MB991529 to connect a voltmeter between ground terminal 4 or 5 and the keyless entry receiver-ECU terminal 1 of the data link connector.
- (2) If a voltmeter indicator deflects once when transmitter's lock/unlock switches are operated, the keyless entry receiver-ECU input signal for that switch circuit system is normal.

Q: Is the input signal of transmitter normal?

YES : Go to Step 5.

NO : Go to Step 4.



**STEP 4. Measure the voltage at transmitter battery.**

- (1) Remove the transmitter battery. (Refer to [P.42-132.](#))
- (2) Measure the transmitter battery's voltage.
 - Voltage should be approximately 2.5 – 3.2 volts (battery positive voltage).

Q: Is the measured voltage approximately 2.5 – 3.2 volts?

YES : Go to Step 6.

NO : Replace transmitter battery (Refer to [P.42-132.](#)), then go to Step 5.

STEP 5. Check the transmitter.

Use other transmitter to register the secret code. (Refer to [P.42-132.](#))

Q: Does the lock/unlock switch operate normally?

YES : Replace the transmitter. Then go to Step 6.

NO : Replace the keyless entry receiver-ECU. Then go to Step 6.

STEP 6. Retest the system.

Q: Does the transmitter operate normally?

YES : The procedure is complete.

NO : Return to Step 1.

INSPECTION PROCEDURE 2: The Secret Code cannot be Registered.

NOTE: If the transmitter battery has been changed (Refer to [P.42-132.](#)) but the secret code cannot be registered, the keyless entry receiver-ECU may be faulty. Check the following circuits, replace the keyless entry receiver-ECU if necessary.

CIRCUIT OPERATION

- Refer to GROUP 13AD, Symptom procedure [P.13Ad-2.](#)

TECHNICAL DESCRIPTION (COMMENT)

The cause may be a malfunction of the keyless entry receiver-ECU or data link circuit.

TROUBLESHOOTING HINTS


- Malfunction of the keyless entry receiver-ECU
- Damaged harness wire or connector

Data Link Power Supply and Ground Circuit



Refer to GROUP 13AD, Symptom procedure [P.13Ad-2.](#)

INSPECTION PROCEDURE 3: The Dome Light, the Cargo Space Light and the Hazard Warning Lights do not Operate through the Answerback Function. (However, the Dome Light, the Cargo Space Light and the Hazard Warning Lights Operates Normally.)

Answerback Circuit



AC004799AB



CIRCUIT OPERATION

The keyless entry receiver-ECU sends a keyless entry system answerback signal to the ETACS-ECU.

TECHNICAL DESCRIPTION (COMMENT)

It is suspected that the keyless entry receiver-ECU does not send any signal to the ETACS-ECU, or the ETACS-ECU is defective.

TROUBLESHOOTING HITS

- Malfunction of the keyless entry receiver-ECU
- Malfunction of the ETACS-ECU
- Damaged harness wires or connectors


DIAGNOSIS

STEP 1. Check keyless entry receiver-ECU connector E-25 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Q: Is keyless entry receiver-ECU connector E-25 damaged?

YES : Repair or replace the damaged components. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection.

NO : Go to Step 2.






STEP 2. Check the harness wire between keyless entry receiver-ECU connector E-25 (terminal No. 6) and ETACS-ECU connector D-27 (terminal No.46).


NOTE: After inspecting intermediate connector E-42 inspect the wire. If intermediate connector E-42 is damaged, repair or replace it. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 4.

Q: Are there any damaged harness wires between keyless entry receiver-ECU connector E-25 (terminal No. 6) and ETACS-ECU connector D-27 (terminal No. 46)?

YES : Repair or replace the harness wire, then go to Step 3.

NO : Replace the ETACS-ECU. Then go to Step 3.





STEP 3. Measure the resistance at keyless entry receiver-ECU.

- (1) Remove the keyless entry receiver-ECU. (Refer to [P.42-135.](#))
- (2) Follow the table to check the keyless entry receiver-ECU continuity.

TESTER CONNECTION	SPECIFIED CONDITION
2 – 4	Less than 2 ohms

Q: Is the measured resistance less than 2 ohms?

YES : Replace keyless entry receiver-ECU, then go to Step 4.

NO : Go to Step 4.

STEP 4. Retest the system.

Q: Does the answerback operate normally?

YES : The procedure is complete. (This malfunction is intermittent. Refer to GROUP 00 [P.00-6](#), How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunction.

NO : Return to Step 1.

MEASUREMENT AT THE RECEIVER TERMINALS

M1428003600029





AC004487

TERMINAL	SIGNAL	REQUIREMENT	TERMINAL VOLTAGE
1	Receiver power supply	Always	Battery positive voltage
2	Ignition switch (ACC) signal	Ignition switch: "ACC" or "ON"	Battery positive voltage
		Ignition switch: "OFF"	0V
4	Ground	Always	0V
5	Data link switching input	Connect scan tool MB991502.	0V
		Disconnect scan tool MB991502.	Battery positive voltage
6	Multiplex communication	Always	0 – 5V (pulse signal)

SPECIAL TOOLS

M1428000600172

TOOL	TOOL NUMBER AND NAME	SUPERSESSION	APPLICATION
 B991502	MB991502 Scan tool (MUT-II)	MB991496-OD	For checking of keyless entry system [Input signal check]
 MB991529	MB991529 Diagnostic trouble code check harness	Tool not necessary if scan tool (MUT-II) is available	For checking of keyless entry system [Input signal check]

ON-VEHICLE SERVICE

HOW TO REPLACE THE TRANSMITTER BATTERY

M1428000900140


⚠ CAUTION

Do not allow water or dust to enter the inside of the transmitter when it is open. Also, do not touch the electronic device inside.

1. Remove the set screw to remove the battery from the transmitter.
2. Install a battery with its (+) side face-down.

Battery required for replacement: Coin type battery CR2032

3. Insert the claw first, and assemble the transmitter.
4. Verify that the keyless entry system operates.





SECRET CODE REGISTRATION METHOD

M1428001000162

Each individual secret code is registered inside the transmitter, and so it is necessary to register these codes with the EEPROM inside the keyless entry receiver-ECU in the following cases.

- When the transmitter or keyless entry receiver-ECU is replaced.
- If more transmitters are to be used.
- If it appears that a problem is occurring because of faulty registration of a code.

A maximum of two different code can be stored in the memory area of the EEPROM (two different transmitters can be used). When the code for the first transmitter is registered, the previously registered codes for two transmitters are cleared. Therefore, if you are using more than two transmitters or are adding a second transmitter, the codes for all the transmitters must be registered at the same time.



1. Check that the doors lock normally when the key is used.

⚠ CAUTION

To prevent damage to scan tool MB991502, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991502.

2. Connect scan tool MB991502 to the data link connector (16-pin).

NOTE: This will connect terminal (1) of the data link connector to ground, and the system will be in secret code registration standby mode.

3. Within 10 seconds after connecting scan tool MB991502 turn the ignition switch to "ACC" for 1 second and then to "OFF" for 1 second; repeat this procedure three times.

NOTE: The doors will lock and unlock once at this time and the system will switch to registration mode.

4. Press the transmitter switch, and then press it two times within 10 seconds of the first press. This will register the code.
5. After registration is completed, the code will be automatically locked and unlocked once.
6. If you are using two transmitters or have added a second transmitter, the same registration procedure should be carried out for the second transmitter, and it should be carried out within one minute after registration of the code for the first transmitter has been completed. After the second registration is completed, the doors will be automatically locked and unlocked once.
7. Registration mode will be terminated under the following condition:
 - When the secret codes for two transmitters have been registered.
 - When one minute has passed after registration mode started.
 - If scan tool MB991502 is disconnected (ground is released).
 - If the ignition switch is turned to "ON".
8. After registration mode has been completed, carry out the following to make sure that the keyless entry system operations.
 - Pull the ignition key out.
 - Close the all doors.

ETACS-ECU FUNCTION ADJUSTMENT PROCEDURE

M1428003700026

The following functions can be adjusted by operating input switches. The adjustments will be stored in the ECU memory even after a battery cable is disconnected:

1. Entry conditions the adjustment mode

The ETACS-ECU sounds a tone alarm once when all of the following conditions are satisfied, and then enters the adjustment mode:

- Data link control: "ON" (Connect scan tool MB991502 or ground the data link connector No.1 terminal.)

2. Exit conditions from the adjustment mode

The ETACS-ECU cancels the adjustment mode when any of the following conditions is satisfied:

- Diagnosis control: "OFF" (Disconnect scan tool MB991502 or disconnect the data link connector No.1 terminal from the ground.)
- Key reminder switch: "ON" (Pull out the ignition key.)



3. Adjustment of functions

- Switching of keyless entry answerback function. (From activation to deactivation, or vice versa)
- Initialization the above function (From deactivation to activation)
- Key reminder switch: "OFF"
- Ignition switch: "OFF"
- Door switch: "OFF" (Close the door.)
- If all of the conditions above are satisfied, the taillight switch will be turned on for more than 10 seconds.
- Ignition switch: Other than "OFF"
- Door switch: "ON" (Open the door.)
- After the ETACS-ECU has entered the adjustment mode, no adjustment is made within 3 minutes (If any adjustment is made within 3 minutes, the ETACS-ECU monitors a adjustment operation for other 3 minutes.)
- Other warning tone alarm sounds

FUNCTION	ADJUSTMENT PROCEDURE
Keyless entry answerback function	<p>When the transmitter lock switch is turned on twice continuously within 2 seconds, the lock answerback function toggles on and off.</p> <ul style="list-style-type: none"> • If the function toggles on, the tone alarm sounds once (default condition). • If the function toggles off, the tone alarm sounds twice. <p>When the transmitter unlock switch is turned on twice continuously within 2 seconds, the unlock answerback function toggles on and off.</p> <ul style="list-style-type: none"> • If the function toggles on, the tone alarm sounds once (default condition). • If the function toggles off, the tone alarm sounds twice.
Initialization of all the ETACS-ECU functions (From deactivation to activation)	<p>When the taillight switch remains on for more than 20 seconds, the tone alarm sounds twice and then the keyless entry system answerback.</p> <p>The tone alarm will sound in 10 seconds (indicating that the ETACS-ECU enters the adjustment mode), but the washer switch must remain off for 20 seconds in order to initialize all the functions.</p> <p>If the taillight switch remains on for more than 20 seconds without entering the adjustment mode, the system enters the adjustment mode in 10 seconds, but does not initialize all of the functions.</p>

KEYLESS ENTRY SYSTEM REMOVAL AND INSTALLATION

M1428001300107



00010236
AC005037AB

KEYLESS ENTRY RECEIVER-ECU REMOVAL STEPS

- QUARTER TRIM, LOWER (REFER TO GROUP 52A, TRIM [P.52A-36](#).)
1. KEYLESS ENTRY RECEIVER-ECU


ETACS-ECU REMOVAL

2. ETACS-ECU

INSPECTION

M1428001400030

HAZARD WARNING RELAY CONTINUITY CHECK



BATTERY VOLTAGE	TESTER CONNECTION	SPECIFIED CONDITION
Not applied	2 – 8 4 – 5	Open circuit
<ul style="list-style-type: none">Connect terminal 6 to the positive battery terminalConnect terminal 1 to the negative battery terminal	2 – 8 4 – 5	Less than 2 ohms

SUNROOF ASSEMBLY

GENERAL INFORMATION

M1426000100148

A motor-driven outer slide-type glass sunroof with a tilt-up mechanism is provided as an option. Even when the sunroof is fully closed, a sufficient amount of lighting and a feeling of openness can still be obtained by opening the sunroof sunshade.

SUNROOF DIAGNOSIS

INTRODUCTION TO SUNROOF DIAGNOSIS

M1426003100051

The operation of the sunroof is controlled by the sunroof-ECU. By operating the sunroof switch, the sunroof-ECU rotates the sunroof motor. If the following type of symptom occurs, there may be a fault

- The sunroof motor does not conduct load detection operation.
- The illumination light of the sunroof switch does not illuminate.
- The sunroof does not operate.

SUNROOF DIAGNOSTIC TROUBLESHOOTING STRATEGY

M1426001700046

Use these steps to plan your diagnostic strategy. If you follow them carefully, you will be sure that you have exhausted most of the possible ways to find a sunroof fault.

1. Gather information from customer.

2. Verify that the condition described by the customer exists.
3. Find the malfunction by following the Symptom Chart.
4. Verify that the malfunction is eliminated.

SYMPTOM CHART


M1426002000051




SYMPTOM	INSPECTION PROCEDURE	REFERENCE PAGE
The sunroof does not operate when the ignition switch is turned to "ON".	1	P.42-137
The sunroof does not operate when the sunroof switch is operated.	2	P.42-141
The sunroof motor does not operate.	3	P.42-144
Safety mechanism does not function.	4	P.42-147

SYMPTOM PROCEDURES

INSPECTION PROCEDURE 1: The Sunroof does not Operate when the Ignition Switch is Turned to "ON".

Sunroof -ECU Power Supply and Ground Circuit





CIRCUIT OPERATION

The sunroof-ECU power is supplied from ignition switch (IG1).

TECHNICAL DESCRIPTION (COMMENT)

The cause may be a malfunction of the sunroof-ECU power supply circuit system or the ground circuit system.

TROUBLESHOOTING HINTS

- Malfunction of the sunroof-ECU
- Damaged harness wires or connectors

DIAGNOSIS


STEP 1. Measure the power supply line voltage at sunroof-ECU connector E-07.


- (1) Remove the headlining. (Refer to GROUP 52A, Headlining P.52A-37.)
- (2) Disconnect sunroof-ECU connector E-07 and measure at the harness side.
- (3) Turn the ignition key "ON".
- (4) Measure the voltage between terminal 8 and ground.
 - The measured value should be approximately 12 volts (battery positive voltage).

Q: Is battery positive voltage (approximately 12 volts) present?

YES : Go to Step 4.

NO : Go to Step 2.






STEP 2. Check sunroof-ECU connector E-07 for loose, corroded or damaged terminals, or terminals pushed back in the connector

Q: Is sunroof-ECU connector E-07 damaged?


YES : Repair or replace the damaged components. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 5.


NO : Go to Step 3.



STEP 3. Check the harness wires between ignition switch (IG1) and sunroof-ECU connector E-07 (terminal No.8).

NOTE: After inspecting intermediate connector C-01, junction block D-08 and D-14 inspect the wire. If intermediate connector C-01, junction block D-08 or D-14 is damaged, repair or replace it. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 4.






Q: Is the harness wire damaged?

YES : Repair or replace the harness wire, then go to Step 4.

NO : Go to Step 5.




STEP 4. Check the harness wire between sunroof-ECU connector E-07 (terminal No.2) and ground.

NOTE: After inspecting intermediate connector C-01, inspect the wire. If intermediate connector C-01 are damaged, repair or replace them. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 5.

Q: Is the harness wire between sunroof-ECU connector E-07 (terminal No.2) and ground damaged?

YES : Repair or replace the harness wire, then go to Step 5.

NO : Replace the sunroof-ECU. Then go to Step 5.



STEP 5. Retest the system.


Q: Does the sunroof open and close normally?

YES : The procedure is complete.



NO : Return to Step 1.

INSPECTION PROCEDURE 2: The Sunroof does not Operate when the Sunroof Switch is Operated.

Sunroof Switch Circuit



W1P13M01AA
AC005068AB



CIRCUIT OPERATION

The sunroof-ECU monitors the sunroof switch status (slide open, slide closed, tilt down, tilt up) and operates the sunroof motor.


TECHNICAL DESCRIPTION (COMMENT)

The cause may be a malfunction of the sunroof switch power supply circuit system or of the ground circuit system.

TROUBLESHOOTING HINTS

- Malfunction of the sunroof-ECU
- Malfunction of the sunroof switch
- Damaged harness wires or connectors

DIAGNOSIS


**STEP 1. Measure the power supply voltage at sunroof switch connector E-03.**

- (1) Remove the headlining. (Refer to GROUP 52A, Headlining [P.52A-37.](#))
- (2) Disconnect sunroof switch connector E-03 and measure at the harness side.
- (3) Turn the ignition key "ON".
- (4) Measure the voltage between terminal 1 and ground, and between terminal 3 and ground.
 - The measured value should be approximately 12 volts (battery positive voltage).

Q: Does the measured voltage correspond with this range?

YES : Go to Step 4.

NO : Go to Step 2.


**STEP 2. Check sunroof switch connector E-03 for damage for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

Q: Is sunroof switch connector E-03 damaged?

YES : Repair or replace the damaged components. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 5.

NO : Go to Step 3.

CONNECTORS: E-03, E-07



E-03 COMPONENT SIDE

2	6	5	4	3
1	2	3	4	5

E-07 COMPONENT SIDE

10	9	8	7	6	5	4	3	2	1
----	---	---	---	---	---	---	---	---	---

AC201996 AB


STEP 3. Check the harness wires between sunroof switch connector E-03 (terminal No.1 and 3) and sunroof-ECU connector E-07 (terminal No.4 and 5).


Q: Are there any damaged wires between sunroof switch connector E-03 (terminal No.1 and 3) and sunroof-ECU connector E-07 (terminal No.4 and 5)?

YES : Repair or replace the harness wire. Then go to Step 4.

NO : Replace the sunroof-ECU. Then go to Step 4.

CONNECTOR: C-01



1	2	3	4			5	6	7	8	9
10	11	12	13	14	15	16	17	18	19	20

AC201993 AB

STEP 4. Check the harness wire between sunroof switch connector E-03 (terminal No.4) and ground.


NOTE: After inspecting intermediate connector C-01 inspect the wire. If intermediate connector C-01 is damaged, repair or replace it. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 5.

Q: Is the harness wire between sunroof switch connector E-03 (terminal No.4) and ground damaged?

YES : Repair or replace the harness wire, then go to Step 5.

NO : Replace the sunroof switch. Then go to Step 5.



CONNECTOR: E-03



COMPONENT SIDE

2	6	5	4	3
1	2	3	4	5

AC201995AB

STEP 5. Retest the system.**Q: Does the sunroof open and close normally?****YES :** The procedure is complete.**NO :** Return to Step 1.**INSPECTION PROCEDURE 3: The Sunroof Motor does not Operate.****Sunroof Motor Circuit**W1P13M02AA
AC005069AB**CIRCUIT OPERATION**

The sunroof-ECU monitors the sunroof switch status (slide open, slide close, tilt down, tilt up) and operates the sunroof motor.

TECHNICAL DESCRIPTION (COMMENT)

The cause may be a malfunction of the sunroof motor power supply/ground circuit system.

TROUBLESHOOTING HINTS

- Malfunction of the sunroof-ECU
- Malfunction of the sunroof motor
- Damaged harness wires or connectors

DIAGNOSIS

STEP 1. Measure the power supply/ground line at sunroof motor connector E-09.

- (1) Remove the headlining. (Refer to GROUP 52A, Headlining [P.52A-37.](#))
- (2) Disconnect sunroof motor connector E-09 and measure at the harness side.
- (3) Turn the ignition key "ON".
- (4) Measure the voltage between terminal 1 and ground while the sunroof switch is depressing to the slide open/close position. And measure the voltage between terminal 2 and ground while the sunroof switch is depressing to the slide open/close position.
 - The measured value should be approximately 12 volts (battery positive voltage).

Q: Does the measured voltage correspond with this range?

YES : Go to Step 4.



NO : Go to Step 2.


STEP 2. Check sunroof motor connector E-09 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Q: Is sunroof switch connector E-09 damaged?

YES : Repair or replace the damaged components. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 5.

NO : Go to Step 3.






STEP 3. Check the harness wires between sunroof-ECU connector E-07 (terminal No.9 and 10) and sunroof motor connector E-09 (terminal No.1 and 2).

Q: Are there any damaged wires between sunroof-ECU connector E-07 (terminal No.9 and 10) and sunroof motor connector E-09 (terminal No.1 and 2)?

YES : Repair or replace the harness wire, then go to Step 5.

NO : Replace the sunroof-ECU. Then go to Step 4.



STEP 4. Check the sunroof motor.

(1) Remove the sunroof motor. (Refer to [P.42-157.](#))

(2) Follow the table below to check for the direction of rotation of the drive gear when the battery is connected to the connector.

BATTERY CONNECTION	DRIVE GEAR ROTATION DIRECTION
Connect terminal 1 to the positive battery terminal Connect terminal 2 to the negative battery terminal	The drive gear rotates counterclockwise
Connect terminal 2 to the positive battery terminal Connect terminal 1 to the negative battery terminal	The drive gear rotates clockwise

Q: Is the sunroof motor damaged?

YES : Replace sunroof motor, then go to Step 5.

NO : Go to Step 5.

STEP 5. Retest the system.


Q: Does the sunroof open and close normally?

YES : The procedure is complete.



NO : Return to Step 1.



INSPECTION PROCEDURE 4: Safety Mechanism does not Function.

Sunroof-ECU Power Supply for Safety Mechanism and Ground Circuit



W3P02M34AA



**CIRCUIT OPERATION**

The power for the safety mechanism circuit in the sunroof-ECU is supplied from fusible link number 8.

TECHNICAL DESCRIPTION (COMMENT)

The cause may be a malfunction of the sunroof-ECU power supply for safety mechanism circuit system or of the ground circuit system.

TROUBLESHOOTING HINTS

- Malfunction of the sunroof-ECU
- Damaged harness wires or connectors


DIAGNOSIS**STEP 1. Measure the power supply line voltage at sunroof-ECU connector E-07.**

- (1) Remove the headlining. (Refer to GROUP 52A, Headlining [P.52A-37.](#))
- (2) Disconnect sunroof-ECU connector E-07 and measure at the harness side.
- (3) Measure the voltage between terminal 7 and ground.
 - Voltage should be approximately 12 volts (battery positive voltage).

Q: Is measured the voltage approximately 12 volts?

YES : Go to Step 4.


NO : Go to Step 2.

**STEP 2. Check sunroof-ECU connector E-07 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

Q: Is sunroof-ECU connector E-07 damaged?

YES : Repair or replace the damaged components. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 5.


NO : Go to Step 3.




STEP 3. Check the harness wires between fusible link number 8 and sunroof-ECU connector E-07 (terminal No. 7).

NOTE: After inspecting intermediate connectors C-01, D-02 and D-09, inspect the wire. If intermediate connectors C-01, D-02 or D-09 is damaged, repair or replace it. Refer to GROUP 00E [P.00E-2](#), Harness Connector Inspection. Then go to Step 4.


CONNECTOR: C-01




CONNECTOR: D-02



CONNECTOR: D-09





CONNECTOR: E-07



Q: Are there any damaged wires between fusible link number 8 and sunroof-ECU connector E-07 (terminal No. 7)?

YES : Repair or replace the harness wire, then go to Step 4.

NO : Go to Step 5.

CONNECTOR: C-01**CONNECTOR: E-07****STEP 4. Check the harness wires between sunroof-ECU connector E-07 and ground.**

NOTE: After inspecting intermediate connectors C-01, inspect the wire. If intermediate connectors C-01 is damaged, repair or replace it. Refer to GROUP 00E P.00E-2, Harness Connector Inspection. Then go to Step 5.

Q: Are there any damaged wires between sunroof-ECU connector E-07 and ground?

YES : Repair or replace the damaged components, then go to Step 5.

NO : Replace the sunroof-ECU. Then go to Step 5.

STEP 5. Retest the system.**Q: Does the safety mechanism work normally?**


YES : The procedures is complete.

NO : Return to Step 1.

CHECKING AT THE SUNROOF-ECU TERMINAL VOLTAGE CHART

M1426002400059

Sunroof-ECU Connector Terminal Arrangement







AC004980AB

TERMINAL NO.	CHECK ITEM	CHECK STATE		NORMAL STATE
2	Earth	Always		0V
3	Front door switch input	Front door switch	ON	0V
			OFF	Battery positive voltage
4	Sunroof switch (tilt up/open) input	Sunroof switch (tilt up/open position)	ON	0V
			OFF	Battery positive voltage
5	Sunroof switch (close) input	Sunroof switch (close position)	ON	0V
			OFF	Battery positive voltage
6	Ground	Always		0V
7	ECU power supply	Ignition switch: ON		Battery positive voltage
8	ECU power supply	Always		Battery positive voltage
9	Motor output	While sunroof is closing or moving up		Battery positive voltage
		Other then the above		0V
10	Motor output	While sunroof is opening or moving down		Battery positive voltage
		Other then the above		0V

SPECIAL TOOLS

M1426000600154

TOOL	TOOL NUMBER AND NAME	SUPERSESSON	APPLICATION
<div style="display: flex; flex-direction: column; align-items: flex-start;"> <div style="margin-bottom: 10px;">A </div> <div style="margin-bottom: 10px;">B </div> <div style="margin-bottom: 10px;">C </div> <div>D </div> </div> <p style="text-align: right; font-size: small;">MB991223AD</p>	MB991223 Harness set A: MB991219 Test harness B: MB991220 LED harness C: MB991221 LED harness adapter D: MB991222 Probe	MB991223	Measurement of terminal voltage A: Connector pin contact pressure inspection B: Power circuit inspection C: Power circuit inspection D: Commercial tester connection



ON-VEHICLE SERVICE

WATER TEST

M1426000900155

Check if there are any leaks in the sunroof by the following procedure.

1. Fully close the roof lid glass.
2. Adjust the water pressure so that water comes out of the hose to a height of approximately 50 cm (19.7 inches) when the hose is held vertically facing upwards.




3. Hold the end of the hose approximately 30 cm (11.8 inches) above the roof and let the water run onto the weatherstrip for 5 minutes or more.
4. Check that there is no water leak while letting the water run onto the roof. Some water will leak around the roof lid glass, but do not judge this as a malfunction. If the water does not leak through the sunroof housing drip channel, it is normal.
5. In the event of leakage, check the drain pipe, weatherstrip contact and others.

SUNROOF FIT ADJUSTMENT

M1426001000155

With the sunroof in the closed position, adjust the sunroof glass to 1 mm (0.04 inch) below roof surface at front of the glass and 1 mm (0.04 inch) above roof surface at rear of the glass and tighten the sunroof glass attaching screws. Check that the clearance between the roof lid glass and body edge is even around the circumference.



OPERATION CHECK

M1426002600161

Check the following items. If defective, replace the sunroof control unit.

CAUTION

Check that the following items are normal before carrying out this operation check.

1. Installation condition of the sunroof assembly
2. Installation, condition and foreign material of the sunroof drive cable
3. Improper fit of sunroof glass
4. Sunroof switch and sunroof motor assembly

Basically operation

NO.	SUNROOF INITIAL POSITION	SWITCH OPERATION	JUDGMENT (NORMAL)
01	Fully closed	1. Ignition switch: "ON" 2. Sunroof switch: OPEN 3. Sunroof switch: Release the OPEN button (Before tilt-up finishes)	The sunroof tilts up by switch operation 2, and stops by switch operation 3
02	Fully closed	1. Ignition switch: "ON" 2. Sunroof switch: OPEN (Keep pressing the OPEN button)	The sunroof moves to the tilt-up position and stops.
03	Tilt up	1. Ignition switch: "ON" 2. Sunroof switch: OPEN	The sunroof slides back from the tilt-up position toward the fully-open position, and then stops.
04	Tilt up	1. Ignition switch: "ON" 2. Sunroof switch: CLOSE	The sunroof closes from the tilt-up position.
05	Fully open	1. Ignition switch: "ON" 2. Sunroof switch: CLOSE 3. Sunroof switch: CLOSE (Release the CLOSE button)	The sunroof moves forward by switch operation 2, and stops by switch operation 3.

Jam preventing mechanism

NO.	SUNROOF INITIAL POSITION	SWITCH OPERATION	JUDGMENT (NORMAL)
01	Fully closed	1. Ignition switch: "ON" 2. Sunroof switch: OPEN Block the sunroof between fully closed position and tilted position.	Sunroof moves until the blocking force reaches 98N (22 lb). At this time check the current to the sunroof motor. If the motor stops at more than 15 A, the motor is normal. [Approximately 15 A at 98 N (22 lb)]
02	Tilt	1. Ignition switch: "ON" 2. Sunroof switch: OPEN Block the sunroof between fully tilted position* and fully open position.	Sunroof moves until the blocking force reaches 98 N (22 lb). Sunroof stops when the force has reached 98 N (22 lb).
03	Fully open	1. Ignition switch: "ON" 2. Sunroof switch: CLOSE Block the sunroof at 200 mm (7.9 in) before the sunroof is fully closed.	Sunroof moves until the blocking force reaches 98 N (22 lb). Sunroof stops in one seconds after the blocking force has reached 98 N (22 lb).
04	Fully open	1. Ignition switch: "ON" 2. Sunroof switch: CLOSE Block the sunroof at 5 mm (0.2 in) before the sunroof is fully closed.	Sunroof moves toward closed until the blocking force reaches 98 N (22 lb). Then the sunroof moves back toward open when the blocking force reaches 98 N (22 lb) and stops after second.
05	Fully open	1. Ignition switch: "ON" 2. Sunroof switch: CLOSE Block the sunroof at 3 mm (0.1 in) before the sunroof is fully closed.	Sunroof moves toward closed until the blocking force reaches 98 N (22 lb). Then the sunroof stops when the blocking force reaches 98 N (22 lb). (The sunroof does not move back toward open.)
06	Fully open	1. Ignition switch: "ON" 2. Sunroof switch: CLOSE Block the sunroof at 18 mm (0.7 in) before the sunroof is fully closed.	Sunroof moves toward closed before the blocking force reaches 98 N (22 lb). Then the sunroof moves back toward open when the blocking force reaches 98 N (22 lb) and stops after one second.

NO.	SUNROOF INITIAL POSITION	SWITCH OPERATION	JUDGMENT (NORMAL)
07	Fully open	<ol style="list-style-type: none"> 1. Ignition switch: "ON" 2. Sunroof switch: CLOSE Block the sunroof at 16 mm (0.6 in) before the sunroof is fully closed. 	Sunroof moves toward closed until the blocking force reaches 98 N (22 lb). Then the sunroof stops when the blocking force reaches 98 N (22 lb). (The sunroof does not move back toward open.)
08	Fully closed	<ol style="list-style-type: none"> 1. Ignition switch: "ON" 2. Sunroof switch: OPEN 3. Sunroof switch: Release the OPEN button 	<ol style="list-style-type: none"> 1. Sunroof tilts up. 2. Sunroof stops before tilt-up finishes.
09	Tilt up	<ol style="list-style-type: none"> 1. Ignition switch: "ON" 2. Sunroof switch: CLOSE 3. Ignition switch: OFF (Before the sunroof is fully open) 	<ol style="list-style-type: none"> 1. Sunroof moves toward open. 2. Sunroof stops.
10	Fully open	<ol style="list-style-type: none"> 1. Ignition switch: "ON" 2. Sunroof switch: CLOSE 3. Ignition switch: OFF (Before tilt-up finishes) 	<ol style="list-style-type: none"> 1. Sunroof tilts up. 2. Sunroof stops
11	Tilt up	<ul style="list-style-type: none"> • Ignition switch: "ON" • Sunroof switch: OPEN Block the sunroof between fully tilted position and fully open position. 	Sunroof moves toward closed until the blocking force reaches 98 N (22 lb). Then the sunroof stops when the blocking force reaches 98 N (22 lb).

Sunroof timer mechanism

NO.	SUNROOF INITIAL POSITION	ACTION		JUDGMENT (NORMAL)
01	Fully closed	A	1. Ignition switch: "ON" 2. Ignition switch: "LOCK" (OFF) 3. Sunroof switch: OPEN [Within 30 seconds after the ignition switch is turned "LOCK" (OFF).]	The sunroof automatic opens 30 seconds after the ignition switch is turned "LOCK" (OFF).
		B	1. Ignition switch: "ON" 2. Sunroof switch: OPEN 3. Ignition switch: "LOCK" (OFF) [The ignition switch is turned "LOCK" (OFF) while the sunroof switch is automatically opening.]	The sunroof automatic opens only 30 seconds after the ignition switch is turned "LOCK" (OFF).
02	Fully opened or while closing	1. Ignition switch: "ON" 2. Sunroof switch: CLOSE 3. Ignition switch: "LOCK" (OFF) 4. Sunroof switch: OPEN or CLOSE [Within 30 seconds after the ignition switch is turned "LOCK" (OFF).]		The sunroof closes while the sunroof switch is pushed to the CLOSE position. Then, the sunroof does not move when any switch is pushed.
03	Fully opened or while closing	1. Ignition switch: "ON" 2. Sunroof switch: CLOSE 3. Ignition switch: "LOCK" (OFF) [The ignition switch is turned "LOCK" (OFF) while the sunroof switch is pushed to the CLOSE position.]		The sunroof closes while the sunroof switch is pushed to the CLOSE position.
04	Fully closed	1. Ignition switch: "ON" 2. Ignition switch: "LOCK" (OFF) 3. Sunroof switch: OPEN [Within 30 seconds after the ignition switch is turned "LOCK" (OFF).] 4. Front door: OPEN [Within 30 seconds after the ignition switch is turned "LOCK" (OFF).]		The sunroof automatic opens and stops when the door is opened.
05	Fully closed	1. Ignition switch: ON 2. Ignition switch: LOCK (OFF) 3. Sunroof switch: OPEN [Within 30 seconds after the ignition switch is turned "LOCK" (OFF).] 4. Door switch: ON [Within 30 seconds after the ignition switch is turned "LOCK" (OFF).]		The sunroof closes while the sunroof switch is pushed to the CLOSE position. Then, the sunroof does not move when the door switch is opened.

NOTE: *: "Fully tilted position" is the position where the sunroof has tilted up and begins sliding.


SUNROOF ASSEMBLY

REMOVAL AND INSTALLATION

M1426001200160

Post-installation Operation <Roof lid glass assembly, Sunroof assembly>

- Sunroof Fit Adjustment (Refer to [P.42-152.](#))
- Sunroof Water Test (Refer to [P.42-152.](#))



AC004054AB

6. SUNROOF SWITCH DOME LIGHT ASSEMBLY

SUNROOF GLASS SEAL REMOVAL STEPS

<<A>> >>F<<

1. SUNROOF GLASS

<> >>E<<

2. SUNROOF GLASS SEAL

SUNROOF SUNSHADE REMOVAL STEPS

<<A>> >>F<<

1. SUNROOF GLASS

<<C>> >>C<<

3. REAR SUNROOF SUNSHADE

<<C>> >>C<<

4. FRONT SUNROOF SUNSHADE

<<D>>

5. SUNSHADE SLIDE BLOCK

SUNROOF-ECU REMOVAL STEPS

6. SUNROOF SWITCH DOME LIGHT ASSEMBLY

7. BRACKET

8. HEADLINING (REFER TO [P.52A-37.](#))

<<E>> >>D<<

9. SUNROOF-ECU

SUNROOF MOTOR REMOVAL STEPS

6. SUNROOF SWITCH DOME LIGHT ASSEMBLY

7. BRACKET

SUNROOF MOTOR REMOVAL STEPS (Continued)

8. HEADLINING (REFER TO [P.52A-37.](#))

SUNROOF GUIDE ASSEMBLY REMOVAL STEPS

<<A>> >>F<<

1. SUNROOF GLASS

<<C>> >>C<<

3. REAR SUNROOF SUNSHADE

<<C>> >>C<<

4. FRONT SUNROOF SUNSHADE

11. LOCATOR

<<F>> >>B<<

12. SUNROOF DRIVE CABLE CONNECTION

13. DRAIN CHANNEL

14. SUNROOF GUIDE ASSEMBLY

SUNROOF ASSEMBLY REMOVAL STEPS

6. SUNROOF SWITCH DOME LIGHT ASSEMBLY

7. BRACKET

8. HEADLINING (REFER TO [P.52A-37.](#))


15. CLIP

<<H>> >>A<<



16. DRAIN HOSE

SUNROOF ASSEMBLY REMOVAL**STEPS (Continued)**


17. SUNROOF ASSEMBLY
18. SET BRACKET

ADHESION POSITION

AC004055AB


**REMOVAL SERVICE POINTS****<<A>> SUNROOF GLASS REMOVAL**

1. Tilt the sunroof.
2. Remove the screws attaching the sunroof glass to the guide assemblies, and then lift the glass out of roof opening.




<> SUNROOF GLASS SEAL REMOVAL

Remove the seal by pulling it off of the glass starting at the splice joint.




<<C>> REAR SUNROOF SUNSHADE/FRONT SUNROOF SUNSHADE REMOVAL

1. Remove the rear sunroof sunshade first by pushing in the slide blocks to release them from the sunroof guide assembly on one side of the sunshade. Remove the rear sunroof sunshade out of roof opening.
2. Repeat step (1) for the front sunroof sunshade.




<<D>> SUNSHADE SLIDE BLOCK REMOVAL



Squeeze together the inboard end of the slide block with your fingers to allow the slide block to slide out of its channel, and then remove the slide block and spring.




<<E>> SUNROOF-ECU REMOVAL

1. Close the sunroof glass fully.
2. Insert a flat-tipped screwdriver, place it on the tab, and then press it to the right.
3. Lower the sunroof-ECU and slide to left.




**<<F>> SUNROOF DRIVE CABLES REMOVAL**

1. Tilt the sunroof guide assembly and then remove the sunroof guide rail rod holder.
2. Close the sunroof guide assembly and disconnect the sunroof drive cable end from the sunroof guide assembly.

**<<G>> SUNROOF GUIDE ASSEMBLY REMOVAL**

1. Slide the roof drip rear channel backward, and then remove the guide assembly screws, the rear screw and spacer.
2. Slide the rear of the guide assembly toward center of the vehicle and remove the guide assembly.



**<<H>> DRAIN HOSE REMOVAL**

Remove the grommet. Tie a cord to the end of the drain hose, wind plastic tape around it so that there is no unevenness, and pull the drain hose out into the wheel house.

INSTALLATION SERVICE POINTS

>>A<< DRAIN HOSE INSTALLATION

1. Tie the cord that was used during removal to the end of the drain hose, and wind the plastic tape around it so that there is no unevenness.
2. Pull the cord to pull through the drain hose.




3. Make the protrusion from the drain hose grommet as shown in the illustration.

>>B<< SUNROOF DRIVE CABLES INSTALLATION

⚠ CAUTION


If cables are kinked, replace them. Always replace the cables in pair and grease them before installation.


Close the sunroof guide assembly and install the sunroof drive cable end to the sunroof guide assembly.



>>C<< FRONT SUNROOF SUNSHADE/REAR SUNROOF SUNSHADE INSTALLATION


1. Install the front sunroof sunshade first by inserting the slide blocks on the right side of the sunshade into the lower slide position of the right guide assembly.
2. Push the sunshade slide blocks on the left side of the sunshade into the sunshade to allow the front sunroof sunshade to drop into position. Once in position, engage the slide blocks into the lower channel of the left guide assembly.






3. Push the front sunroof sunshade to full forward position.
4. Position the rear sunroof sunshade so that the stop tabs are against the stop bumpers on the guide assembly. Engage the right side slide blocks of the upper half of the sunshade into the upper channel on the right guide assembly. Engage the slide blocks on the left side of the sunshade into the upper channel in the left guide assembly.
5. Slide the sunshade back and forth to check that it functions smoothly.


>>D<< SUNROOF-ECU INSTALLATION



1. Look into the "viewing windows" while turning the rotating wheel. Turn the rotating wheel until the white timing marks appear. When the white timing marks appear in the "viewing windows" at the same time, stop turning the rotating wheel.
2. Close the sunroof fully. Install the timed sunroof control unit. Make sure that the sunroof cable is properly inserted into the control unit.



3. Insert a flat-tipped screwdriver, place it on the tab, and press it to the right, being careful not to pinch the wiring.




>>E<< SUNROOF GLASS SEAL INSTALLATION

1. Starting at the rear center of the sunroof glass, begin installing the seal by pushing it onto the edge of the glass panel and gently pulling on it while installing.
2. Approximately 102 mm (4.0 inches) before completing the installation, lay the end of the seal over top of the beginning of the seal. Cut the seal so there is an extra 3.18 mm (0.125 inch) of the seal past the point where the seal lines up with the beginning of the seal
3. Apply Loctite R 410 Black Toughened Instant Adhesive or equivalent to the splice joint area where two ends of the seal meet.
4. With the approximately 102 mm (4.0 inches) of the seal unattached, push two ends of the seal together at glue joint.
5. Install the remainder of the seal by pushing the seal onto the edge of the glass panel. The 3.18 mm (0.125 inch) of extra seal material should strengthen the seal at the splice joint.

>>F<< SUNROOF GLASS INSTALLATION

1. Position the sunroof glass onto the guide assemblies and align the mounting holes.
2. Apply Loctite R Small Screw Thread locker 222 or equivalent to the sunroof glass attaching screws and install them, going to the next step before tightening.




INSPECTION

SUNROOF MOTOR CHECK

M1426002500045

Check the rotation direction of the drive gear when the battery is connected to the connector.




TESTER CONNECTION	DRIVE GEAR OPERATION
<ul style="list-style-type: none"> Connect terminal 2 to the positive battery terminal Connect terminal 1 to the negative battery terminal 	The drive gear rotates clockwise
<ul style="list-style-type: none"> Connect terminal 1 to the positive battery terminal Connect terminal 2 to the negative battery terminal 	The drive gear rotates counterclockwise

SUNROOF SWITCH CONTINUITY CHECK

M1426001600094

Operate the sunroof switch and check for the continuity between each of the terminals.




SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
At the Open position	3 – 4	Less than 2 ohms
At the Off position	1 – 4 3 – 4	Open circuit
At the Close position	1 – 4	Less than 2 ohms

UNDER COVER

REMOVAL AND INSTALLATION

M1421002800041



AC003810 AB

1. TRANSFER CASE PROTECTOR

UNDER SKID PLATE REMOVAL STEPS

2. UNDER COVER
3. UNDER SKID PLATE
4. SKID PLATE BRACKET

SPECIFICATIONS

FASTENER TIGHTENING SPECIFICATIONS

M1426003000087

ITEM	SPECIFICATION
Body mounting	
Body mounting self jam nut	27 – 31 N·m (20 – 23 ft-lb)
Door	
Door hinge bolt	26 N·m (19 ft-lb)
Door hinge nut	26 N·m (19 ft-lb)
Power window motor bolt	5.4 ± 0.5 N·m (48 ± 4 in-lb)
Striker screw	12 N·m (106 in-lb)
Door latch assembly screw	6 N·m (53 in-lb)
Hood	
Hood latch bolt	9 N·m (80 in-lb)
Hood support rod bolt	9 N·m (80 in-lb)
Hood hinge bolt (hood side)	12 N·m (106 in-lb)
Hood hinge bolt (body side)	22 N·m (16 ft -lb)
Hood hinge nut (body side)	12 N·m (106 in-lb)
Keyless entry system	
Keyless entry receiver-ECU	5 N·m (44 in-lb)
Liftgate	
Liftgate hinge nut	14 N·m (124 in-lb)
Liftgate hinge bolt	12 N·m (106 in-lb)
Striker bolt	9 N·m (80 in-lb)
Joint ball	12 N·m (106 in-lb)
Liftgate gas spring bolt	5 N·m (44 in-lb)
Liftgate latch assembly bolt	9 N·m (80 in-lb)
Sunroof	
Sunroof assembly bolt	5 N·m (44 in-lb)
Sunroof assembly nut	5 N·m (44 in-lb)
Sunroof glass bolt	5 N·m (44 in-lb)
Sunroof guide assembly bolt	3 N·m (27 in-lb)
Set bracket bolt	5 N·m (44 in-lb)
Set bracket nut	5 N·m (44 in-lb)

SERVICE SPECIFICATIONS

M1426000300078

<DOOR>

ITEM		STANDARD VALUE
Door outside handle play mm (in)		2.8 (0.11)
Power window operation current A		7 or more [20°C (68°F)]
Door inside handle play mm (in)		7.3 (0.29) or more
Glass pad and glass holder installation position mm (in)	Distance (A) between glass holder and rear edge of glass	106.7 – 108.2 (4.20 – 4.26)
	Distance (B) between glass holders	417.5 – 420.5 (16.44 – 16.56)
	Distance (C) between glass holder and rear edge of glass	<Vehicles with power windows> 127 – 131 (5.0 – 5.2) <Vehicles without power windows> 62 – 66 (2.4 – 2.6)

<LIFTGATE>

ITEM	STANDARD VALUE
Liftgate handle play mm (in)	1.5 – 5.5 (0.06 – 0.22)

SEALANTS AND ADHESIVES

M1426000500072

<DOOR>

ITEM	SPECIFIED SEALANT	REMARK
Waterproof film	3 M™ AAD8633 or equivalent	Ribbon sealer

<LIFTGATE>

ITEM	SPECIFIED SEALANT	REMARK
Waterproof film	3 M™ AAD8633 or equivalent	Ribbon sealer

<WINDOW GLASS>

ITEM	SPECIFIED SEALANT
Liftgate window glass	3 M™ AAD8609 or equivalent
Quarter window glass	3 M™ AAD8513 or equivalent
Windshield	3 M™ AAD8609 or equivalent

<SUNROOF>

ITEM	SPECIFIED SEALANT
Sunroof glass attaching screws	Loctite® Small Screw Threadlocker 222 or equivalent
Sunroof glass sealing	Loctite® 410 Black Toughened Instant Adhesive or equivalent

COMPONENT IDENTIFICATION

M1421005400194

DOOR HINGES

APPLICABLE LOCATION		IDENTIFICATION MARK
Front left side door	Upper hinge	F1
	Lower hinge	E1
Front right side door	Upper hinge	E1
	Lower hinge	F1
Rear left side door	Upper hinge	A1
	Lower hinge	B1
Rear right side door	Upper hinge	B1
	Lower hinge	A1

DOOR CHECK

APPLICABLE LOCATION		IDENTIFICATION MARK
LH	Front door	19L
	Rear door	25L
RH	Front door	19R
	Rear door	25R

DOOR OUTER OPENING WEATHERSTRIP

APPLICABLE LOCATION	IDENTIFICATION COLOR
Right door	Brown or yellow
Left door	Natural (white)

NOTES