GROUP 11B

ENGINE OVERHAUL <3.0L ENGINE>

CONTENTS

SPECIAL TOOLS	11B-2	CYLINDER HEAD AND VALVES	11B-26
		REMOVAL AND INSTALLATION	11B-26
GENERATOR AND DRIVE BELT	11B-4	INSPECTION	11B-29
REMOVAL AND INSTALLATION	11B-4		
		OIL PAN AND OIL PUMP	11B-33
INTAKE MANIFOLD PLENUM AND		REMOVAL AND INSTALLATION	11B-33
THROTTLE BODY ASSEMBLY	11B-6	INSPECTION	11B-37
REMOVAL AND INSTALLATION	11B-6		
		PISTON AND CONNECTING ROD	11B-39
IGNITION SYSTEM	11B-7	REMOVAL AND INSTALLATION	11B-39
REMOVAL AND INSTALLATION	11B-7	INSPECTION	11B-45
TIMING BELT	11B-8	CRANKSHAFT AND CYLINDER	
REMOVAL AND INSTALLATION	11B-8	BLOCK	11B-47
INSPECTION	11B-13	REMOVAL AND INSTALLATION	11B-47
		INSPECTION	11B-51
INTAKE MANIFOLD AND FUEL			
PARTS	11B-15	BRACKET	11B-54
REMOVAL AND INSTALLATION	11B-15	REMOVAL AND INSTALLATION	11B-54
EXHAUST MANIFOLD	11B-19	SPECIFICATIONS	11B-54
REMOVAL AND INSTALLATION	11B-19	FASTENER TIGHTENING	
		SPECIFICATIONS	11B-54
ROCKER ARMS AND CAMSHAFT	11B-20	GENERAL SPECIFICATIONS	11B-57
REMOVAL AND INSTALLATION	11B-20	SERVICE SPECIFICATIONS	11B-57
INSPECTION	11B-23	SEALANTS AND ADHESIVES	11B-59

SPECIAL TOOLS

M1113000600023

TOOL	TOOL NUMBER AND NAME	SUPERSESSION	APPLICATION
D998781	MD998781 Flywheel stopper	General service tool	Loosening and tightening crankshaft bolts
B990767	MB990767 End yoke holder Use with MD998715	MB990767-01	Holding camshaft sprocket when loosening or torquing bolt.
	MD998715 Pin	MIT308239	
	MD998769 Crankshaft spacer	General service tool	Rotation of crankshaft when installing piston and timing belt
D998767	MD998767 Tensioner wrench	MD998752-01	Adjustment of timing belt tension
D998443	MD998443 Lash adjuster holder (8)	MD998443-01	Supporting of the lash adjuster to prevent it from falling when rocker shaft assembly is removed or installed
D998713	MD998713 Camshaft oil seal installer	MD998713-01	Installation of camshaft oil seal
B991559	MB991559 Camshaft oil seal installer adaptor	_	Installation of camshaft oil seal (left bank) (use with MD998713)


TSB Revision

TOOL	TOOL NUMBER AND NAME	SUPERSESSION	APPLICATION
	MD998442 Air bleed wire	General service tool	Air bleeding of auto lash adjuster
	MD998051 Cylinder head bolt wrench	MD998051-01 or General service tool	Loosening and tightening cylinder head bolts
	MD998772 Valve spring compressor	General service tool	Compression of valve spring
	MD998774 Valve stem seal installer	MD998774-01	Installation of valve stem seal
	MD998717 Crankshaft front oil seal installer	MD998717-01	Installation of crankshaft front oil seal
	MD998718 Crankshaft rear oil seal installer	MD998718-01	Installation of crankshaft rear oil seal

GENERATOR AND DRIVE BELT

REMOVAL AND INSTALLATION

M1113001300166



REMOVAL STEPS

- COOLING FAN
- 2. FAN CLUTCH
- 3. DRIVE BELT
- 4. COOLING FAN PULLEY
- 5. COOLING FAN BRACKET
- 6. DRIVE BELT TENSIONER PULLEY
- 7. TIMING INDICATOR
- 8. GENERATOR
- 9. ACCESSORY MOUNT STAY
- 10. TUBE

Required Special Tool:

• MD998781: Flywheel Stopper


REMOVAL STEPS (Continued)

- 11. OIL FILLER CAP
- 12. OIL FILLER
- 13. ENGINE HANGER
- 14. ACCESSORY MOUNT
- 15. ADJUSTING BOLT
- 16. ADJUSTING STUD
- <<A>>> >>A<< 17. CRANKSHAFT BOLT
 - 18. CRANKSHAFT PULLEY WASHER
 - 19. DAMPER PULLEY

REMOVAL SERVICE POINT

<<A>> CRANKSHAFT BOLT LOOSENING


- 1. Using special tool MD998781, hold the drive plate.
- 2. Remove the crankshaft bolt.




INSTALLATION SERVICE POINT

>>A<< CRANKSHAFT BOLT TIGHTENING

1. Using special tool MD998781, hold the drive plate.






- 2. Clean the bolt hole in crankshaft bolt and damper pulley's seating surface.
- 3. Degrease the cleaned seating surface of the damper pulley.
- 4. Install the damper pulley.
- 5. Apply oil to the threads of crankshaft bolt and the outer surface of washer.
- 6. Install the washer to the crankshaft bolt with its inside chamfered side toward the bolt head.
- 7. Tighten the crankshaft bolt to the specified torque.

Tightening torque: $185 \pm 5 \text{ N} \cdot \text{m} (139 \pm 3 \text{ ft-lb})$

INTAKE MANIFOLD PLENUM AND THROTTLE BODY ASSEMBLY

REMOVAL AND INSTALLATION

M1113003300076



AK000488AB

REMOVAL STEPS

- 1. IGNITION COIL
- 2. IGNITION POWER TRANSISTOR
- 3. EGR VALVE
- 4. EGR VALVE GASKET
- MANIFOLD DIFFERENTIAL PRESSURE SENSOR
- 6. O-RING
- 7. EGR PIPE
- 8. EGR PIPE GASKET


REMOVAL STEPS (Continued)

- 9. INTAKE MANIFOLD PLENUM STAY
- 10. WATER OUTLET FITTING BRACKET
- 11. THROTTLE BODY
- >>A<< 12. THROTTLE BODY GASKET
 - 13. AIR INTAKE FITTING
 - 14. INTAKE FITTING GASKET
 - 15. WATER PUMP BRACKET
 - 16. UPPER INTAKE MANIFOLD
 - 17. INTAKE MANIFOLD PLENUM GASKET

INSTALLTION SERVICE POINT

>>A<< THROTTLE BODY GASKET INSTALLATION

Position the tab of gasket as shown in the illustration.




IGNITION SYSTEM

REMOVAL AND INSTALLATION

M1113001600101

AK000431AB



REMOVAL STEPS


- 1. SPARK PLUG CABLES
- 2. SPARK PLUGS

TSB Revision

TIMING BELT

REMOVAL AND INSTALLATION

M1113001900191



REMOVAL STEPS

- 1. TIMING BELT FRONT COVER CAP
- 2. TIMING BELT FRONT UPPER COVER, RIGHT
- 3. TIMING BELT FRONT UPPER COVER, LEFT
- 4. TIMING BELT FRONT LOWER COVER
- <<A>>> >>D<< 5. TIMING BELT
 - 6. CRANKSHAFT POSITION SENSOR
 - 7. CRANKSHAFT POSITION SENSOR
 - >>C<< 8. AUTO-TENSIONER

AK000489AB **REMOVAL STEPS (Continued)**

- 9. TENSIONER PULLEY
- 10. TENSIONER ARM
- 11. SHAFT
- 12. IDLER PULLEY
- 13. IDLER PULLEY SPACER
- >>B<< 14. CRANKSHAFT SPROCKET
- >>B<< 15. CRANKSHAFT SPACER
- >>B<< 16. CRANKSHAFT SENSING BLADE
- <> >>A<< 17. CAMSHAFT SPROCKET BOLT
 - 18. CAMSHAFT SPROCKET 19. HARNESS PROTECTOR
 - 20. TIMING BELT REAR LEFT COVER

TSB Revision

Required Special Tools:

MB990767: End Yoke Holder

MD998715: Pins


• MD998767: Tensioner Pulley Wrench

• MD998769: Crankshaft Spacer

REMOVAL SERVICE POINTS


<<A>> TIMING BELT REMOVAL

⚠ CAUTION




Mark the belt running direction for reference in reinstallation.

NOTE: If there is oil or water on any part, check the front case oil seal, camshaft oil seal, and water pump for leaks.



<> CAMSHAFT SPROCKET BOLT REMOVAL

Use special tools MB990767 and MD998715 to prevent the camshaft sprocket from turning, and then loosen the camshaft sprocket bolt.





INSTALLATION SERVICE POINTS

>>A<< CAMSHAFT SPROCKET BOLT INSTALLATION

Use special tools MB990767 and MB998715 to prevent the camshaft sprocket from turning, and then tighten the camshaft sprocket bolt.

Tightening torque: 88 \pm 10 N·m (65 \pm 7 ft-lb)






>>B<< CRANKSHAFT SENSING BLADE/CRANKSHAFT SPACER/CRANKSHAFT SPROCKET INSTALLATION

- 1. Clean the hole in the crankshaft sprocket.
- 2. Clean and degrease the mating surfaces of the crankshaft sprocket; sensing blade; and spacer


NOTE: Degreasing is necessary to prevent decrease in friction between the mating surface due to presence of oil.



>>C<< AUTO-TENSIONER INSTALLATION

If the auto-tensioner rod is fully extended, set it in the retracted position with the following procedure.

- 1. Set the auto-tensioner in a vice.
- 2. Slowly close the vice to force the rod in until the set hole (A) of the rod is lined up with the set hole (B) of the cylinder.
- 3. Insert a wire [1.4 mm (0.06 inch) in diameter] into the set holes.
- 4. Remove the auto-tensioner from the vice.




>>D<< TIMING BELT INSTALLATION

⚠ CAUTION


If the camshaft sprocket is rotated with the piston at the top dead center on the compression stroke of the number 1 cylinder, the valve and piston might interfere.


1. Move the timing mark of the crankshaft sprocket three teeth to slightly lower the piston below the top dead center on the compression stroke of the number 1 cylinder.




- 2. Line up the timing marks of the left bank camshaft sprocket.
- 3. Line up the timing marks of the right bank camshaft sprocket.

ENGINE OVERHAUL <3.0L ENGINE> TIMING BELT










- 4. Line up the timing marks of the crankshaft sprockets.
- 5. Install the timing belt on each sprocket in the following sequence.
 - Install the timing belt on the crankshaft sprocket and then on the idler pulley, while tightening it to prevent slackness.
 - (2) Install the timing belt on the left bank camshaft sprocket.
 - (3) Install the timing belt on the water pump pulley, while taking up the slack.
 - (4) Install the timing belt on the right bank camshaft sprocket.
 - (5) Install the timing belt on the tensioner pulley.
- 6. Lightly press the tensioner pulley against the belt and temporarily tighten the center bolt.
- 7. Check to see that the timing marks of all the sprockets are in a alignment.

8. Using special tool MD998769, rotate the crankshaft a quarter of a turn counterclockwise. Then rotate it back clockwise to verify that all the timing marks are in alignment.







- 9. Mount special tool MD998767 and torque wrench on the tensioner pulley.
- 10. Torque it to 4.4 N·m (39 in-lb) with the torque wrench.
- 11. While holding the tensioner pulley in position, tighten the center bolt to the specified torque.

Tightening torque: $48 \pm 6 \text{ N} \cdot \text{m} (35 \pm 4 \text{ ft-lb})$

- 12.Rotate the crankshaft two turns clockwise and leave it alone for approximately five minutes.
- 13. Check to see whether the metal wire inserted when the auto-tensioner was installed can be removed without any resistance.


If the metal wire can be removed without any resistance, it means that the belt has a proper tension. Therefore, remove the metal wire. In this condition, check that the projection of the rod of the auto-tensioner is within the standard value.

Standard value: 3.8 – 4.5 mm (0.15 – 0.17 inch)

14.If the metal wire offers resistance when removed, repeat the previous steps (9) through (12) until a proper belt tension is obtained.

INSPECTION


M1113002000094




TIMING BELT

Replace the belt if any of the following conditions exist.


 Hardening of rubber backing.
 Back side is glossy without resilience and leaves no indent when pressed with fingernail.



- 2. Cracks on rubber back
- 3. Cracks or peeling of canvas
- 4. Cracks on tooth bottom
- 5. Cracks on belt




6. Abnormal wear of belt sides. Normal wear is indicated if the sides are sharp as if cut by a knife. Abnormal wear is indicated if the sides are ragged.




- 7. Abnormal wear on teeth.
- 8. Missing tooth.


ENGINE OVERHAUL <3.0L ENGINE> TIMING BELT



TENSIONER PULLEY AND IDLER PULLEY

Turn the pulley. If it does not rotate smoothly, or develops noise or excessive play, replace the pulley.





AUTO-TENSIONER

- 1. Check for oil leaks. If oil leaks are evident, replace the autotensioner.
- 2. Check the rod end for wear or damage and replace the autotensioner if necessary.
- 3. Measure the rod protrusion. If it is out of specification, replace the auto-tensioner.

Standard value: 12 mm (0.5 inch)

4. Press the rod with a force of 98 to 196 N (22 to 44 pounds) and measure the movement of the rod.

If the measured value is out of the standard value, replace the auto-tensioner.


Standard value: 1.0 mm (0.03 inch) or less

AKX00652AB

INTAKE MANIFOLD AND FUEL PARTS

REMOVAL AND INSTALLATION

M1113004300132




REMOVAL STEPS

- >>G<< 1. ENGINE COOLANT TEMPERATURE GAUGE UNIT
- >>F<< 2. ENGINE COOLANT TEMPERATURE SENSOR
 - 3. WATER OUTLET FITTING
 - 4. WATER OUTLET FITTING GASKET
 - 5. WATER HOSE
- >>D<< 6. WATER OUTLET PIPE
- >>**D**<< 7. O-RING
 - 8. WATER HOSE

REMOVAL STEPS (Continued)

- 9. WATER INLET FITTING
- >>E<< 10. THERMOSTAT
 - 11. THERMOSTAT CASE
 - 12. THERMOSTAT CASE GASKET
 - 13. WATER PASSAGE
 - 14. WATER PASSAGE GASKET
- >>**D**<< 15. WATER PIPE
- >>**D**<< 16. O-RING
 - 17. WATER HOSE



AK000493AC

REMOVAL STEPS

- 18. INJECTOR HARNESS
- 19. INJECTOR AND FUEL RAIL
- 20. INSULATOR
- >>C<< 21. FUEL PRESSURE REGULATOR
 - 22. O-RING
 - 23. INSULATOR
- >>**B**<< 24. INJECTOR

REMOVAL STEPS (Continued)

- 25. O-RING
- 26. GROMMET
- 27. FUEL PIPE
- 28. O-RING
- 29. FUEL RAIL
- >>A<< 30. INTAKE MANIFOLD
 - 31. INTAKE MANIFOLD GASKET



>>A<< INTAKE MANIFOLD INSTALLATION

- 1. Tighten the nuts on the right bank to $7 \pm 1 \text{ N} \cdot \text{m}$ (62 ± 9 in-lb).
- 2. Tighten the nuts on the left bank to the specified torque.


Tightening torque: 20 − 23 N·m (14 − 17 ft-lb)

3. Tighten the nuts on the right bank to the specified torque.

Tightening torque: 20 – 23 N·m (14 – 17 ft-lb)

4. Tighten the nuts on the left bank and those on the right bank again in that order.

Tightening torque: $20 - 23 \text{ N} \cdot \text{m} (14 - 17 \text{ ft-lb})$




>>B<< INJECTOR INSTALLATION

⚠ CAUTION

Use care not to let engine oil enter the fuel rail.

- 1. Before installing the injector, lubricate the O-ring with a drop of new engine oil for easy installation.
- 2. Insert the injector top end into the fuel rail. Be careful not to damage the O-ring during installation.



>>C<< FUEL PRESSURE REGULATOR INSTALLATION

⚠ CAUTION

Do not let engine oil enter the fuel rail.


Before installing the pressure regulator, lubricate the O-ring with a drop of new engine oil for easy installation.


>>D<<O-RING AND WATER PIPE INSTALLATION

⚠ CAUTION

Keep the O-ring free of oil or grease.


Wet the O-ring (with water) to easy assembly.






>>E<< THERMOSTAT INSTALLATION

Install the thermostat in the thermostat case with its jiggle valve located at the top position.



>>F<< SEALANT APPLICATION TO ENGINE COOLANT TEMPERATURE SENSOR

Apply 3M™ AAD Part number 8731 or equivalent to the engine coolant temperature sensor.




>>G<< SEALANT APPLICATION TO ENGINE COOLANT TEMPERATURE GAUGE UNIT

Apply 3M™ AAD Part number 8672 or equivalent to the engine coolant temperature gauge unit.

EXHAUST MANIFOLD

REMOVAL AND INSTALLATION

M1113004900093



AK000436AB

REMOVAL STEPS

- 1. OIL DIPSTICK
- 2. O-RING
- 3. OIL DIPSTICK GUIDE
- 4. O-RING
- 5. HEAT PROTECTOR, RIGHT
- 6. EXHAUST MANIFOLD, RIGHT


REMOVAL STEPS (Continued)

- 7. EXHAUST MANIFOLD GASKET
- 8. HEAT PROTECTOR, LEFT
- 9. EXHAUST MANIFOLD, LEFT
- 10. EXHAUST MANIFOLD GASKET
- 11. WATER PUMP
- 12. WATER PUMP GASKET

ROCKER ARMS AND CAMSHAFT

REMOVAL AND INSTALLATION

M1113005400303



REMOVAL STEPS

- 1. BLOW-BY HOSE
- 2. PCV HOSE
- 3. PCV VALVE
- 4. ROCKER COVER
- 5. ROCKER COVER GASKET
- 6. OIL SEAL
- >>D<< 7. CAMSHAFT OIL SEAL

REMOVAL STEPS (Continued)

- <<a>>> >> C<< 8. ROCKER ARMS AND SHAFT
- <<a>>> >> C<< 9. ROCKER ARMS AND SHAFT
 - >>C<< 10. ROCKER SHAFT SPRING
 - 11. ROCKER ARM A
 - 12. ROCKER ARM B
 - 13. ROCKER ARM SHAFT
 - >>B<< 14. LASH ADJUSTER

TSB Revision

REMOVAL STEPS (Continued)

- 15. ROCKER ARM C
- 16. ROCKER ARM SHAFT

>>B<< 17. LASH ADJUSTER

- 18. THRUST CASE (RIGHT BANK ONLY)
- 19. O-RING (RIGHT BANK ONLY)
- >>**A**<< 20. CAMSHAFT

Required Special Tools:

- MB991559: Camshaft Oil Seal Installer Adapter
- MD998442: Air Bleed Wire

- MD998443: Lash Adjuster Holder
- MD998713: Camshaft Oil Seal Installer


REMOVAL SERVICE POINT

<<A>> ROCKER ARMS AND SHAFT REMOVAL



If the lash adjuster is re-used, clean the lash adjuster. (Refer to lash adjuster inspection P.11B-23.)

Set special tool MB998443 to prevent the lash adjuster coming free and falling to the floor.



INSTALLATION SERVICE POINTS

>>A<< CAMSHAFT INSTALLATION


⚠ CAUTION

Use care to prevent confusion of the right and left bank camshafts.

1. Apply engine oil to the camshaft journals and cams and then install the camshafts.

NOTE: The right bank camshaft is identified by a slit 4 mm (0.16 inch) wide at the rear end of the camshaft.






2. Check to see that the dowel pin of the camshaft is located at the position shown.



>>B<< LASH ADJUSTER INSTALLATION

If the lash adjuster is re-used, clean the lash adjuster. (Refer to lash adjuster inspection P.11B-23.)

Fit the lash adjuster onto the rocker arm without allowing diesel fuel to spill out. Fit special tool MD998443 to prevent the lash adjuster coming free and falling to the floor.





>>C<< ROCKER ARM, ROCKER ARM SHAFT AND ROCKER SHAFT SPRING INSTALLATION

1. Temporarily tighten the rocker shaft with bolts so that all the intake valve rocker arms do not push on the valves.

Tightening torque: 31 \pm 3 N·m (23 \pm 2 ft-lb)


2. Insert the rocker shaft spring from above and mount it at right angles to the plug guide.






3. Make sure that the notch of the rocker shaft is in the position shown in the illustration.

NOTE: Mount the rocker shaft spring before installing the exhaust rocker arms and rocker arm shaft.





>>D<< CAMSHAFT OIL SEAL INSTALLATION

Use special tools MD998713 and MB991559 to install the camshaft oil seal.

INSPECTION


M1113005500021

ROCKER ARM SHAFT

Check the rocker arm mounting areas of the rocker arm shafts for wear or damage. Replace as necessary.


ROCKER ARM

- 1. Check the roller surface and replace the rocker arm if recesses, damage or heat seizure is observed.
- 2. Check roller rotation and replace the rocker arm if uneven rotation or roller backlash of the roller is observed.
- 3. Check the inside diameter and replace the rocker arm if damage or seizure is observed.



CAMSHAFT

- Check the camshaft bearing journals for damage and binding. If the journals are binding, check the cylinder head for damage. Also check the cylinder head for clogged oil holes.
- 2. Check the tooth surface of the distributor drive gear teeth of the camshaft and replace if abnormal wear is evident.



3. Check the cam surface for abnormal wear and damage and replace if necessary. Also measure the cam height and replace if out of minimum limit.

Standard value:

Intake 37.71 mm (1.485 inches)

Exhaust 37.14 mm (1.462 inches)


Minimum limit:

Intake 37.21 mm (1.465 inches)

Exhaust 36.64 mm (1.443 inches)


LASH ADJUSTERS


⚠ CAUTION




- Do not attempt to disassemble the lash adjusters.
- Use only fresh diesel fuel to clean the lash adjusters.
- 1. Prepare three containers and approximately 5 dm³ (30.5 quart) of diesel fuel. Into each container, pour enough diesel fuel to completely cover a lash adjuster when it is standing upright. Then, perform the following steps with each lash adjuster.
- 2. Place the lash adjuster in container A and clean its outside surface.

NOTE: Use a nylon brush if deposits are hard to remove.








⚠ CAUTION


The steel ball spring is extremely weak, so the lash adjuster's functionality may be lost if the air bleed wire is pushed in hard.

3. While gently pushing down the internal steel ball using wire [0.5 mm (0.020 inch) in diameter] or special tool MD998442, move the plunger through five to ten strokes until it slides smoothly. In addition to eliminating stiffness in the plunger, this operation will remove dirty oil.

NOTE: If the plunger remains stiff or the mechanism appears otherwise abnormal, replace the lash adjuster.




4. Remove the lash adjuster from the container. Then, push down the steel ball gently and push the plunger to eliminate diesel fuel from the pressure chamber.




⚠ CAUTION

The steel ball spring is extremely weak, so the lash adjuster's functionality may be lost if the air bleed wire is pushed in hard.

- 5. Place the lash adjuster in container B. Then, gently push down the internal steel ball using a wire [0.5 mm (0.020 inch) in diameter] or special tool MD998442 and move the plunger through five to ten strokes until it slides smoothly. This operation will clean the lash adjuster's pressure chamber.
- Remove the lash adjuster from the container. Then, push down the steel ball gently and push the plunger to eliminate diesel fuel from the pressure chamber.





⚠ CAUTION

Do not use container C for cleaning. If cleaning is performed in container C, foreign matter could enter the pressure chamber when the chamber is filled with diesel fuel.


- 7. Place the lash adjuster in container C. Then, gently push down the internal steel ball using a wire [0.5 mm (0.020 inch) in diameter] or special tool MD998442.
- WIRE OR MD998442

 DIESEL
 FUEL

 AKX00631AB

8. Stand the lash adjuster with its plunger at the top, then push the plunger downward firmly until it moves through its greatest possible stroke. Return the plunger slowly, then release the steel ball and allow the pressure chamber to fill with diesel fuel.

AKX00630AB




- 9. Remove the lash adjuster from the container, then stand the lash adjuster with its plunger at the top. Push the plunger firmly and check that it does not move.
 - NOTE: If the lash adjuster contracts or moves, perform the operations (7) through (9) again to fill it with diesel fuel completely. Replace the lash adjuster if it still contracts or moves after performing these steps.
- 10.Stand the lash adjuster upright to prevent diesel fuel from spilling out. Do not allow the lash adjuster to become contaminated by dirt or other foreign matter. Fit the lash adjuster onto the engine as soon as possible.

CYLINDER HEAD AND VALVES

REMOVAL AND INSTALLATION

M1113006900022



AKX00644AB

			REMOVAL STEPS
< <a>>>	>>D<<	1.	CYLINDER HEAD
		_	VAVACLIED

2. WASHER

3. CYLINDER HEAD ASSEMBLY

BOLT

4. CYLINDER HEAD GASKET

<>> >>C<< 5. RETAINER LOCK

6. VALVE SPRING RETAINER

>>B<< 7. VALVE SPRING

8. INLET VALVE

<> >>C<< 9. RETAINER LOCK

10. VALVE SPRING RETAINER

>>B<< 11. VALVE SPRING

REMOVAL STEPS (Continued)

12. EXHAUST VALVE

>>A<< 13. VALVE STEM SEAL

14. VALVE SPRING SEAT

>>A<< 15. VALVE STEM SEAL

16. VALVE SPRING SEAT

17. INLET VALVE GUIDE

18. SNAP RING

19. EXHAUST VALVE GUIDE

20. INLET VALVE SEAT

21. EXHAUST VALVE SEAT

22. CYLINDER HEAD

Required Special Tools:

• MD998051: Cylinder Head Bolt Wrench


• MD998772: Valve Spring Compressor

MD998774: Valve Stem Seal Installer




<<A>> CYLINDER HEAD BOLT REMOVAL

Use special tool MD998051 to loosen the cylinder head bolt.



<> RETAINER LOCK REMOVAL

- 1. Using special tool MD998772, compress the spring.
- 2. Remove the retainer locks.



INSTALLATION SERVICE POINTS

>>A<< VALVE STEM SEAL INSTALLATION

1. Install the valve spring seat.


⚠ CAUTION

 Valve stem seals for intake valves and for exhaust valves are different. Be sure to install the correct ones.

• Valve stem seal identification color

Intake: GRAY


Exhaust: GRAY GREEN



⚠ CAUTION


Always use the special tool to install the valve stem seal. Improperly installed valve stem seals may leak oil.

2. Using special tool MD998774, install a new stem seal to the valve guide.




>>B<< VALVE SPRING INSTALLATION


Install the valve spring end with its identification color toward the spring retainer.



>>C<< RETAINER LOCK INSTALLATION

Using special tool MD998772, compress the valve spring and insert the retainer lock into position.





>>D<< CYLINDER HEAD BOLT INSTALLATION

⚠ CAUTION

Attach the head bolt washer in the direction shown in the figure.

1. Tighten the bolts in two three stages in the illustrated sequence.


Tightening torque: $108 \pm 5 \text{ N} \cdot \text{m} (80 \pm 4 \text{ ft-lb})$

2. Back off the bolts once and tighten them to the specified torque in the same procedure as shown in step (1).



M1113007000022






Standard value: 0.03 mm (0.0012 inch) Limit: 0.2 mm (0.007 inch)


2. If the service limit is exceeded, correct to meet the specification.


Grinding limit: *0.2 mm (0.007 inch)


3. *If the service limit is exceeded, correct to meet the specification.


Cylinder head height (specification when new): 120 mm (4.7 inches)











VALVE

- Check the valve face for correct contact. If incorrect, reface using a valve refacer. The valve should make a uniform contact with the seat at the center of the valve face.
- 2. If the margin exceeds the service minimum limit, replace the valve.

Standard value:

<Intake> 1.0 mm (0.04 inch)

<Exhaust> 1.2 mm (0.05 inch)

Minimum limit:

<Intake> 0.5 mm (0.02 inch)

<Exhaust> 0.7 mm (0.03 inch)

3. Measure the valve's total length. If the measurement is less than specified, replace the valve.

Standard value:

<Intake> 112.30 mm (4.421 inches)

<Exhaust> 114.11 mm (4.493 inches)

Minimum limit:

<Intake> 111.80 mm (4.402 inches)

<Exhaust> 113.61 mm (4.473 inches)

VALVE SPRINGS

1. Measure the free height of the spring and, if it is smaller than the minimum limit, replace the spring.

Standard value: 51.0 mm (2.01 inches) Minimum limit: 50.0 mm (1.97 inches)

2. Measure the squareness of the spring and, if the limit is exceeded, replace the spring.

Standard value: 2° or less

Limit: 4°

VALVE GUIDES

Measure the clearance between the valve guide and valve stem. If the limit is exceeded, replace the valve guide, valve, or both.

Standard value:


<Intake> 0.02 - 0.05 mm (0.0008 - 0.0019 inch)

<Exhaust> 0.04 - 0.07 mm (0.0016 - 0.0027 inch)

Limit:

<Intake> 0.10 mm (0.003 inch)

<Exhaust> 0.15 mm (0.005 inch)




VALVE SEAT

Assemble the valve, then measure the valve stem projection between the end of the valve stem and the spring seating surface. If the measurement exceeds the specified limit, replace the valve seat.

Standard value: 49.30 mm (1.941 inches)

Limit: 49.80 mm (1.960 inches)



VALVE SEAT RECONDITIONING PROCEDURE

↑ CAUTION

Before correcting the valve seat, check for the clearance between the valve guide and valve and, if necessary, replace the valve guide.


- 1. Using the special tool or a seat grinder, correct to obtain the specified seat width and angle.
- 2. After correcting the valve seat, lap the valve and valve seat using lapping compound. Then, check the valve stem projection.

VALVE SEAT REPLACEMENT PROCEDURE

⚠ CAUTION

Before replacing the valve seat, check the valve guide and, if necessary, replace the valve guide.

1. Cut the valve seat from the inside to thin the wall thickness. Then, remove the valve seat.



oversize valve seat diameter.

Seat ring hole diameter:
Intake valve

0.3 oversize 34.30 – 34.33 mm (1.3504 – 1.3516 inches)

2. Rebore the valve seat hole in the cylinder head to a selected


 $0.6\ oversize\ 34.60-34.63\ mm\ (1.3622-1.3634\ inches)$


Exhaust valve


0.3 oversize 31.80 – 32.83 mm (1.2520 – 1.2531 inches)


0.6 oversize 32.10 - 32.13 mm (1.2638 - 1.2650 inches)

 Before fitting the valve seat, either heat the cylinder head up to approximately 250°C (482°F) or cool the valve seat in liquid nitrogen, to prevent the cylinder head bore from galling.









VALVE GUIDE REPLACEMENT PROCEDURE

- 1. Remove the snap ring from the exhaust valve guide.
- 2. Using a press, remove the valve guide toward the cylinder head gasket surface.

⚠ CAUTION

Do not install a valve guide of the same size again.

3. Re bore the valve guide hole of the cylinder head so that it fits the press-fitted oversize valve guide.

Valve guide hole diameter:

0.05 oversize 11.05 - 11.07 mm (0.4350 - 0.4358 inch) 0.25 oversize 11.25 - 11.27 mm (0.4429 - 0.4457 inch) 0.50 oversize 11.50 - 11.52 mm (0.4528 - 0.4535 inch)

- 4. Install the new snap ring into the groove of exhaust valve guide.
- 5. Press-fit the valve guide until it protrudes 14 mm (0.55 inch) from the cylinder head top surface as shown in the illustration.


NOTE: When press-fitting the valve guide, work from the cylinder head top surface.

NOTE: After installing the valve guides, insert new valves in them to check for sliding condition.

OIL PAN AND OIL PUMP

REMOVAL AND INSTALLATION

M1113008100163



AK000495AC

REMOVAL STEPS

>>G<< 1. OIL PRESSURE SWITCH

>>F<< 2. OIL FILTER

3. OIL FILTER BRACKET

OIL FILTER BRACKET GASKET

DRAIN PLUG

>>**E**<< 6. DRAIN PLUG GASKET

<<**A>> >D<** 7. OIL PAN

8. COVER

BAFFLE PLATE

10. OIL SCREEN

REMOVAL STEPS (Continued)

- 11. OIL SCREEN GASKET
- 12. PLUG
- 13. RELIEF SPRING
- 14. RELIEF PLUNGER
- >>C<< 15. CRANKSHAFT OIL SEAL
- >>B<< 16. OIL PUMP CASE
 - 17. O-RING
 - 18. OIL PUMP COVER

<> >>A<< 19. OIL PUMP OUTER ROTOR <> >>A<< 20. OIL PUMP INNER ROTOR

Required Special Tool:

• MD998717: Crankshaft Front Oil Seal Installer

TSB Revision

REMOVAL SERVICE POINTS


<<A>> OIL PAN REMOVAL


- 1. Remove the bolts A shown in the illustration first.
- 2. Remove all other bolts.


⚠ CAUTION

Do not use a scraper or special tool to remove the oil pan.

3. Remove the oil pan.








<> OUTER ROTOR/INNER ROTOR REMOVAL


Make alignment dots on the outer and inner rotors for assembly.





INSTALLATION SERVICE POINTS


>>A<< INNER ROTOR/OUTER ROTOR INSTALLATION

Apply engine oil to the rotors. Then, install the rotors ensuring that the alignment dots made at disassembly are properly aligned.









>>B<<OIL PUMP CASE INSTALLATION

- 1. Clean the gasket surfaces of oil pump case and cylinder block.
- 2. Apply a 3mm (0.12 inch) diameter bead of sealant Mitsubishi Genuine Parts number MD970389, or equivalent to the oil pump case. Be sure to install the oil pump case quickly while the sealant is wet (within 15 minutes).
- 3. Tighten the oil pump case bolts to specified torque.


Tightening torque: $14 \pm 1 \text{ N} \cdot \text{m}$ ($124 \pm 9 \text{ in-lb}$)

4. After installation, keep the sealed area away from the oil for approximately one hour.

>>C<< CRANKSHAFT OIL SEAL INSTALLATION

- 1. Install the guide of special tool MD998717 to the front end of the crankshaft.
- 2. Apply engine oil to the lip area of a new oil seal and push it in until it contacts the oil pump case.

3. Using special tool MD998717, press-fit the oil seal into the oil pump case.




>>D<< UPPER OIL PAN INSTALLATION

- 1. Clean the gasket surfaces of the cylinder block and upper oil pan.
- 2. Apply a 4 mm (0.16 inch) diameter bead of sealant Mitsubishi Genuine Parts number MD970389, or equivalent to the upper oil pan. Be sure to install the upper oil pan quickly while the sealant is wet (within 15 minutes).

⚠ CAUTION

When installing the upper oil pan, be sure not to expel the sealant from the upper oil pan flange at portion A in the illustration.

- 3. Tighten the upper oil pan bolts in the sequence shown. Tightening torque: 9 ± 3 N·m (80 ± 27 in-lb)
- 4. After installation, keep the sealed area away from the oil for approximately one hour.




>>E<< DRAIN PLUG GASKET INSTALLATION

⚠ CAUTION


If the gasket is installed in the wrong direction, oil leaks will be occurred.

Install the drain plug gasket as illustrated.



>>F<<OIL FILTER INSTALLATION

- 1. Clean the installation surface of the filter bracket.
- 2. Apply engine oil to the O-ring of the oil filter.
- 3. Screw the oil filter on until the O-ring contacts the bracket. Then tighten 3/4 turn [14 \pm 1 N·m (124 \pm 9 in-lb)]



>>G<< SEALANT APPLICATION TO OIL PRESSURE A CAUTION

Keep the end of threaded portion clear of sealant. Avoid an overtightening.

Apply 3M™ AAD Part number 8672 or equivalent to the oil pressure switch.





M1113008200063



1. Check the tip clearance.


Standard value: 0.06 – 0.18 mm (0.003 – 0.007 inch)





2. Check the side clearance.

Standard value: 0.04 - 0.10 mm (0.002 - 0.004 inch)




3. Check the body clearance.

Standard value: 0.10 - 0.18 mm (0.004 - 0.007 inch) Limit: 0.35 mm (0.013 inch)

PISTON AND CONNECTING ROD

REMOVAL AND INSTALLATION

M1113008400368



AKX00729AB

REMOVAL STEPS

1. NUT

<<a>>> >> F<< 2. CONNECTING ROD CAP

>>D<< 3. CONNECTING ROD BEARING, LOWER

>>E<< 4. PISTON AND CONNECTING ROD ASSEMBLY

>>D<< 5. CONNECTING ROD BEARING, UPPER

REMOVAL STEPS (Continued)

>>**C**<< 6. PISTON RING NO.1

>>C<< 7. PISTON RING NO.2

>>**B**<< 8. OIL RING

<> >>A<< 9. PISTON PIN


10. PISTON

11. CONNECTING ROD

12. BOLT

Required Special Tool:

• MIT216941: Piston Pin Setting Tool




AKX00734AB

REMOVAL SERVICE POINTS


<<A>> CONNECTING ROD CAP REMOVAL

- 1. Mark the cylinder number on the side of the connecting rod big end for correct reassembly.
- 2. Keep the removed connecting rods, caps, and bearings in order according to the cylinder number.



<> PISTON PIN REMOVAL

ITEM NO.	PART NO.	DESCRIPTION
1	MIT310134	Base
2	MIT310136	Piston support
3	MIT310137	Connecting rod guide pin
4	MIT310138	Connecting rod guide pin
5	MIT310139	Connecting rod guide pin
6	MIT310140	Piston support
7	MIT310141	Connecting rod guide pin
8	MIT310142	Piston support
9	MIT48143	Press pin
10	216943	Stop screw
11	10396	Nut




- 1. Remove the stop screw from the base.
- 2. Select the correct piston support for your application. (See above) Fit the piston support onto the base. Place the base on the press support blocks.
- 3. Insert the press pin through the piston pin hole. Select the correct connecting rod guide pin. (See above.) Thread the guide pin onto the threaded portion of the press pin.
- 4. Position the piston assembly on the piston support in the press. With the press pin up as shown, insert the guide pin through the hole in the piston and through the hole in the piston support.

⚠ CAUTION

To avoid piston damage, the piston support must seat squarely against the piston. Verify that the piston pin will slide through the hole in the piston support.

- 5. Press the piston pin out of the assembly.
- 6. Remove the piston pin from the piston pin.




INSTALLATION SERVICE POINTS

>>A<< PISTON PIN INSTALLATION

1. When replacing the piston pin, read off the cylinder bore size mark on the cylinder block as illustrated, and select a piston according to the flowing table.


CYLINDER BORE SIZE MARK	PISTON CLASS	PISTON SIZE MARK
I	Α	А
II	В	None
Ш	С	С

NOTE: The piston size mark shows on the top of the piston.



- Thread the stop screw and jam nut assembly into the base. Fit the correct piston support on top of the base. Insert the press pin, threaded end up, into the hole in the piston support until the press pin touches the stop screw.
- 3. Using the graduations on the press pin, adjust the stop screw to the depth.

Depth: 60 mm (2.36 inches)




- 4. Place the base on the press support blocks.
- 5. Slide the piston pin over the threaded end of the press pin, and thread the correct guide pin up against it.
- 6. Coat the piston pin with engine oil, and with the connecting rod held in position, slide the guide pin through the piston and connecting rod.
- 7. Press the piston pin through the connecting rod until the guide pin contacts the stop screw.


⚠ CAUTION


Due to production tolerance variations, it is necessary to visually inspect the piston pin depth after installation to verify that the piston pin is centered. Adjust if necessary.


8. Remove the piston assembly from the base. Remove the guide pin and press pin from the assembly.




9. Check that the piston moves smoothly.









>>B<<OIL RING INSTALLATION

1. Fit the oil ring spacer into the piston ring groove.

NOTE: The side rails and spacer may be installed in either direction.

NOTE: New spacers and side rails are colored for identification of their sizes.

SIZE	COLOR
Standard	None
0.50 mm (0.020 in) oversize diameter	Blue
1.00 mm (0.040 in) oversize diameter	Yellow

⚠ CAUTION

Do not use any piston ring expander when installing the side rail.

2. Install the upper side rail.

To install the side rail, first fit one end of the rail into the piston groove, then press the remaining portion into the position by finger. See illustration.

- 3. Install the lower side rail in the same procedure as described in step 2.
- 4. Make sure that the side rails move smoothly in either direction.

>>C<< PISTON RING NO.2/PISTON RING NO.1 INSTALLATION

1. To prevent wrong installation, check the identification mark of each piston ring. The identification mark is stamped near the ring gap:

Identification mark Number 1 ring: T Number 2 ring: 2T


NOTE: Size marks on piston rings are as follows.


SIZE	SIZE MARK
Standard	None
0.50 mm (0.020 in) oversize diameter	50
1.00 mm (0.040 in) oversize diameter	100


2. Using a piston ring expander, fit the number 2 piston ring into the number 2 groove of piston.


NOTE: Install the piston rings with their identification mark facing up, to the piston crown side.

3. Install the number 1 piston ring in the same manner as step 2.









>>D<< CONNECTING ROD BEARING INSTALLATION


1. Measure the crankshaft pin diameter and confirm its classification from the following table. In the case of a crankshaft supplied as a service part, identification colors/marks of its pins are painted/stamped at the positions shown in the illustration.


CRANKSHAFT PIN OUTSIDE DIAMETER		CONNECTING ROD	BEARING
IDENTIFI CATION COLOR	SIZE mm (in)	IDENTIFICA TION COLOR	IDENTIFICA TION COLOR
Yellow	49.995 – 50.000	White	Yellow
	(1.9683 – 1.9685)	None	Yellow
		Yellow	None
None	None 49.985 – 49.995 (1.9679 – 1.9683)	White	Yellow
		None	None
		Yellow	Blue
White	49.980 – 49.985	White	None
(1.9678 – 1.9679)	None	Blue	
		Yellow	Blue
Blue	Blue 49.976 – 49.980 (1.9676 – 1.9678)	White	Blue
		None	Blue
		Yellow	Red

- 2. If the crankshaft pin outside diameter Identification color is "yellow" and the connecting rod Identification color is "yellow," for example, select a bearing whose Identification color is "none." If there is no Identification color paint on the crankshaft, measure the pin outside diameter and select a bearing appropriate for the measured value.
- 3. Install the selected bearing in the big end and in the cap of the connecting rod.

>>E<< PISTON AND CONNECTING ROD INSTALLATION


- 1. Apply engine oil on the circumference of the piston, piston rings, and oil ring.
- 2. Arrange the piston ring and oil ring gaps (side rail and spacer) as shown in the illustration.
- 3. Rotate the crankshaft so that the crank pin is on the center of the cylinder bore.






Care must be taken not to nick the crank pin.

- 5. Insert the piston and connecting rod assembly into the cylinder with the front mark on the piston crown pointing to the timing belt side.
- 6. Using a suitable piston ring compressor tool, install the piston and connecting rod assembly into the cylinder block.



>>F<< CONNECTING ROD CAP INSTALLATION

 Mate the correct bearing cap with the correct connecting rod by checking with the alignment marks marked during disassembly. If a new connecting rod is used which has no alignment mark, position the notches for locking the bearing on the same side.



2. Check if the thrust clearance in the connecting rod big end is correct.

Standard value: 0.10 - 0.25 mm (0.004 - 0.009 inch) Limit: 0.4 mm (0.02 inch)

INSPECTION

M1113008500020

PISTON


Replace the piston if scratches or seizure is evident on its surfaces (especially the thrust surface). Replace the piston if it is cracked.


PISTON PIN


- 1. Insert the piston pin into the piston pin hole with a thumb. You should feel a slight resistance. Replace the piston pin if it can be easily inserted or there is an excessive play.
- 2. The piston and piston pin must be replaced as an assembly.

PISTON RING

1. Check the piston ring for damage, excessive wear, and breakage and replace if defects are evident. If the piston has been replaced with a new one, the piston rings must also be replaced with new ones.







Standard value:

Number 1: 0.03-0.07 mm (0.0012-0.0027 inch) Number 2: 0.02-0.06 mm (0.0008-0.0023 inch)

Limit: 0.1 mm (0.003 inch)

3. Insert the piston ring into the cylinder bore. Force the ring down with a piston, the piston crown being in contact with the ring, to correctly position it at right angles to the cylinder wall. Then, measure the end gap with a feeler gauge. If the ring gap is excessive, replace the piston ring.

Standard value:

Number 1: 0.30 – 0.45 mm (0.012 – 0.017 inch) Number 2: 0.45 – 0.60 mm (0.018 – 0.023 inch)

Oil: 0.20 - 0.60 mm (0.008 - 0.023 inch)

Limit:

Number 1, Number 2: 0.8 mm (0.03 inch)


Oil: 1.0 mm (0.03 inch)




The crankshaft oil clearance can be measured easily by using plastic gauging material, as follows:

- 1. Remove oil from the crankshaft pin and the bearing inner surface.
- 2. Cut plastic gauging material to the same length as the width of the bearing and place it on the pin in parallel with its axis.
- 3. Install the connecting rod cap carefully and tighten the nuts to the specified torque.
- 4. Carefully remove the connecting rod cap.
- Measure the width of the smashed plastic gauging material at its widest section by using a scale printed on the plastic gauging material bag.

Standard value: $0.02-0.05\ mm\ (0.0008-0.0019\ inch)$ Limit: $0.1\ mm\ (0.003\ inch)$






CRANKSHAFT AND CYLINDER BLOCK

REMOVAL AND INSTALLATION

M1113008700347



REMOVAL STEPS

- 1. ADAPTER PLATE
- 2. DRIVE PLATE BOLT
- 3. CRANKSHAFT ADAPTOR
- 4. REAR PLATE
- >>E<< 5. OIL SEAL CASE
- >>D<< 6. CRANKSHAFT REAR OIL SEAL
- >>C<< 7. BEARING CAP BOLT
- >>C<< 8. BEARING CAP


REMOVAL STEPS (Continued)

- >>B<< 9. THRUST BEARING A
- >>B<< 10. THRUST BEARING B
- >>A<< 11. CRANKSHAFT BEARING, LOWER
 - 12. CRANKSHAFT
- >>B<< 13. THRUST BEARING B
- >>B<< 14. THRUST BEARING A
- >>A<< 15. CRANKSHAFT BEARING, UPPER
 - 16. CYLINDER BLOCK

Required Special Tool:


MD998718: Crankshaft Rear Oil Seal Installer

INSTALLATION SERVICE POINTS




>>A<< CRANKSHAFT BEARING INSTALLATION


 Measure the crankshaft journal diameter and confirm its classification from the following table. In the case of a crankshaft supplied as a service part, identification colors/ marks of its journals are painted/stamped at the positions shown in the illustration.




2. The cylinder block bearing bore diameter identification marks are stamped at the position shown in the illustration from left to right, beginning at No.1.

CRANKSHAFT JOURNAL OUTSIDE DIAMETER		CYLINDER BLOCK BEARING BORE	CRANKSHAFT BEARING
IDENTIFICATION MARK	SIZE mm (in)	IDENTIFICATION MARK	IDENTIFICATION MARK
Yellow	59.994 – 60.000	I	1
	(2.3620 – 2.3622)	II	2
		III	3
None	59.988 – 59.994 (2.3617 – 2.3620)	I	2
		II	3
		III	4
	59.982 - 59.988	I	3
	(2.3615 – 2.3617)	II	4
		III	5
	59.978 – 59.982 (2.3613 – 2.3615)	I	4
		II	5
		III	6






- 3. From the following table, select a bearing whose size is appropriate for the crankshaft journal outside diameter. If the crankshaft journal outside diameter identification color is "yellow" and the cylinder block bearing bore identification mark is "III", for example, select a bearing whose identification mark is "3".
 - If there is no identification color paint on the crankshaft, measure the journal outside diameter and select a bearing appropriate for the measured valve.
- 4. Install bearings with a groove to the cylinder block.
- 5. Install the bearings having no groove to the bearing cap.



>>B<< CRANKSHAFT THRUST BEARING INSTALLATION

- 1. Install the thrust bearing in the No.3 bearing bore in the cylinder block and in the bearing cap. For easier installation, apply engine oil to the bearings; this will help hold them in position.
- 2. The thrust bearings must be installed with their groove toward the crankshaft web.

>>C<< BEARING CAP/BEARING CAP BOLT INSTALLATION





- 1. Attach the bearing cap on the cylinder block as shown in the illustration.
- 2. Tighten the bearing cap bolts to specified torque in the sequence shown in the illustration.

Tightening torque: 94 \pm 4 N·m (69 \pm 3 ft-lb)

- 3. Check that the crankshaft rotates smoothly.
- 4. Check the end play. If it exceeds the limit value, replace the thrust bearing.


Standard value: 0.05 – 0.25 mm (0.002 – 0.009 inch) Limit: 0.3 mm (0.01 inch)





>>D<< CRANKSHAFT REAR OIL SEAL INSTALLATION

Using special tool MD998718, press-fit a new crankshaft rear oil seal into the oil seal case.



>>E<< OIL SEAL CASE INSTALLATION

- 1. Apply the sealant Mitsubishi Genuine Part number MD970389 or equivalent to the oil seal case.
- 2. Apply a small amount of engine oil to the entire circumference of the oil seal lip section, and place the oil seal case on the cylinder block.

NOTE: Install the oil seal case within 15 minutes after applying liquid gasket.


NOTE: Then wait at least one hour. Never start the engine or let engine oil or coolant touch the adhesion surface during that time.


INSPECTION

M1113008800087

CRANKSHAFT JOURNAL OIL CLEARANCE <PLASTIC GAUGING MATERIAL METHOD>

- 1. Remove oil from the crankshaft journal and crankshaft bearing inner surface.
- 2. Install the crankshaft.
- Cut plastic gauging material to the same length as the width of the bearing and place it on the journal in parallel with its axis.





4. Install the crankshaft bearing cap carefully and tighten the bolts to the specified torque.

Tightening torque: $74 \pm 4 \text{ N} \cdot \text{m}$ ($54 \pm 3 \text{ ft-lb}$)

- 5. Carefully remove the crankshaft bearing cap.
- 6. Measure the width of the smashed plastic gauging material at its widest section by using a scale printed on the plastic gauging material bag.

Standard value: 0.02 - 0.04 mm (0.0008 - 0.0016 inch)

Limit: 0.1 mm (0.003 inch)

CRANKSHAFT REAR OIL SEAL

- 1. Check the oil seal lip for wear and damage.
- 2. Check the rubber for deterioration or hardening.
- 3. Check the oil seal case for cracks and damage.

CYLINDER BLOCK

- 1. Visually check for scratches, rust, and corrosion. Use also a flaw detecting agent for the check. If defects are evident, correct, or replace.
- 2. Using a straightedge and feeler gauge, check the block top surface for warpage. Make sure that the surface is free from gasket chips and other foreign matter.

Standard value: 0.05 mm (0.002 inch)

Limit: 0.1 mm (0.003 inch)

3. If the distortion is excessive, correct within the allowable limit or replace.

Grinding limit: *0.2 mm (0.008 inch)

*Includes/combined with cylinder head grinding.

Cylinder block height (when new):


210.4 - 210.6 mm (8.283 - 8.291 inches)


- 4. Check the cylinder walls for scratches and seizure. If defects are evident, correct (bored to an oversize) or replace.
- 5. Using a cylinder gauge, measure the cylinder bore and cylindricality. If worn badly, correct by boring the cylinders to an oversize and replace pistons and piston rings. Measure at the points shown in the illustration.


Standard value:

Cylinder Inside Diameter: 91.1 mm (3.587 inches)

Cylindricality: 0.01 mm (0.0003 inch)







BORING CYLINDER

1. Oversize pistons to be used should be determined on the basis of the largest bore cylinder.

Piston size identification

SIZE	IDENTIFICATION MARK
0.50 mm (0.020 in) Oversize diameter	0.50
1.00 mm (0.040 in) Oversize diameter	1.00

NOTE: Size mark is stamped on the piston top.

- 2. Measure the outside diameter of the piston to be used. Measure it in the thrust direction as shown.
- 3. Based on the measured piston Outside Diameter (OD), calculate the boring finish dimension.

Boring finish dimension = Piston OD + (clearance between piston OD and cylinder) – 0.02 mm (0.0008 inch) (honing margin)

⚠ CAUTION

To prevent distortion that may result from temperature rise during honing, bore cylinders in the order of number 2, number 4, number 6, number 1, number 3 and number 5.

- 4. Bore all cylinders to the calculated boring finish dimension.
- 5. Hone to the final finish dimension (piston OD + clearance between piston OD and cylinder).

Standard value:

Cylinder Inside Diameter: 91.1 mm (3.587 inches) Cylindricality: 0.01 mm (0.0003 inch)

6. Check the clearance between the piston and cylinder.


Clearance between piston and cylinder: 0.02 – 0.04 mm (0.0008 – 0.0015 inch)

NOTE: When boring cylinders, finish all six cylinders to the same oversize. Do not bore only one cylinder to an oversize.

BRACKET

REMOVAL AND INSTALLATION

M1113009000051



REMOVAL STEPS

- 1. ENGINE SUPPORT BRACKET, RIGHT
- 2. ENGINE SUPPORT BRACKET, LEFT

SPECIFICATIONS

FASTENER TIGHTENING SPECIFICATIONS

M1113023400343

ITEMS	SPECIFICATIONS	
Generator and drive belt		
Accessory mount bolt	39 ± 5 N·m (29 ± 4 ft-lb)	
Accessory mount stay bolt (M10)	44 ± 5 N·m (32 ± 4 ft-lb)	
Accessory mount stay bolt (M8)	24 ± 4 N·m (17 ± 3 ft-lb)	
Cooling fan bolt	11 ± 1 N·m (97 ± 9 in-lb)	
Cooling fan bracket bolt	41 ± 8 N·m (30 ± 6 ft-lb)	

TSB Revision	
--------------	--

ITEMS	SPECIFICATIONS
Crankshaft bolt	185 ± 5 N·m (139 ± 3 ft-lb)
Drive bolt tensioner pulley nut	44 ± 5 N·m (32 ± 4 ft-lb)
Engine hanger bolt	17 ± 2 N·m (13 ± 1 ft-lb)
Fan clutch nut	11 ± 1 N·m (97 ± 9 in-lb)
Generator bolt (M10)	49 ± 5 N·m (36 ± 4 ft-lb)
Generator bolt (M8)	23 ± 3 N·m (17 ± 2 ft-lb)
Oil filler bolt	22 ± 4 N·m (16 ± 3 ft-lb)
Power steering pump bracket bolt	44 ± 10 N·m (33 ± 7 ft-lb)
Timing indicator bolt	11 ± 1 N·m (97 ± 9 in-lb)
Intake manifold plenum and throttle body assemb	ly
Air intake fitting bolt and nut	18 ± 2 N·m (13 ± 2 ft-lb)
Exhaust gas recirculation pipe bolt	18 ± 2 N·m (13 ± 2 ft-lb)
Exhaust gas recirculation pipe flare nut	59 ± 10 N·m (43 ± 7 ft-lb)
Exhaust gas recirculation valve bolt	22 ± 4 N·m (16 ± 3 ft-lb)
Ignition coil bolt	11 ± 1 N·m (97 ± 9 in-lb)
Intake manifold plenum stay bolt (M10)	35 ± 6 N·m (26 ± 4 ft-lb)
Intake manifold plenum stay bolt (M8)	18 ± 2 N·m (13 ± 2 ft-lb)
Upper Intake manifold bolt	18 ± 2 N·m (13 ± 2 ft-lb)
Manifold differential pressure sensor bolt	4.9 ± 1 N⋅m (43 ± 9 in-lb)
Throttle body bolt	12 ± 1 N·m (106 ± 9 in-lb)
Water outlet fitting bracket bolt	14 ± 1 N·m (124 ± 9 in-lb)
Water pump bracket bolt	24 ± 3 N·m (18 ± 2 ft-lb)
Ignition system	·
Spark plugs	25 ± 5 N·m (18 ± 4 ft-lb)
Timing belt	
Auto tensioner bolt	23 ± 3 N·m (17 ± 2 ft-lb)
Camshaft position sensor bolt	8.8 ± 1 N·m (78 ± 9 in-lb)
Camshaft sprocket bolt	88 ± 10 N·m (65 ± 8 ft-lb)
Crankshaft position sensor bolt	8.8 ± 1 N·m (78 ± 9 in-lb)
Idler pulley bolt	44 ± 5 N·m (32 ± 4 ft-lb)
Tensioner arm bolt	44 ± 10 N·m (32 ± 7 ft-lb)
Tensioner pulley bolt	48 ± 6 N·m (35 ± 4 ft-lb)
Timing belt cover nut	5 ± 1.0 N·m (44 ± 9 in-lb)
Timing belt front cover bolt (M8)	14 ± 1 N·m (124 ± 9 in-lb)
Timing belt front cover bolt (M6)	11 ± 1 N·m (97 ± 9 in-lb)
Timing belt rear cover bolt	14 ± 1 N·m (124 ± 9 in-lb)
Intake manifold and fuel parts	
Engine coolant temperature gauge unit	11 ± 1 N·m (97 ± 9 in-lb)
Engine coolant temperature sensor	29 ± 10 N·m (21 ± 7 ft-lb)
Fitting bolt	12 ± 1 N·m (106 ± 9 in-lb)

ITEMS	SPECIFICATIONS
Fuel pipe bolt	9 ± 1 N·m (80 ± 9 in-lb)
Fuel pressure regulator bolt	9 ± 1 N·m (80 ± 9 in-lb)
Fuel rail bolt	12 ± 1 N·m (106 ± 9 in-lb)
Intake manifold nut	22 ± 1 N·m (16 ± 1 ft-lb)
Thermostat case bolt	19 ± 1 N·m (14 ± 1 ft-lb)
Water inlet fitting bolt	24 ± 4 N·m (18 ± 1 ft-lb)
Water outlet fitting bolt	19 ± 1 N·m (14 ± 1 ft-lb)
Water outlet pipe bolt	13 ± 2 N⋅m (115 ± 18 in-lb)
Water passage bolt	19 ± 1 N⋅m (14 ± 1 ft-lb)
Water pipe bolt	13 ± 2 N⋅m (115 ± 18 in-lb)
Exhaust manifold	
Oil dipstick guide bolt	49 ± 6 N⋅m (36 ± 4 ft-lb)
Exhaust manifold nut	44 ± 5 N·m (32 ± 4 ft-lb)
Heat protector bolt	14 ± 1 N·m (124 ± 9 in-lb)
Water pump bolt	24 ± 3 N·m (18 ± 2 ft-lb)
Rocker arms and camshaft	
PCV valve	10 ± 2 N⋅m (89 ± 18 in-lb)
Rocker cover bolt	3.5 ± 0.5 N·m (31 ± 4 in-lb)
Rocker shaft bolt	31 ± 3 N⋅m (23 ± 2 ft-lb)
Thrust case bolt	13 ± 2 N⋅m (115 ± 18 in-lb)
Cylinder head and valve	
Cylinder head bolt	108 \pm 5 N·m (80 \pm 4 ft-lb) → back off → 108 \pm 5 N·m (80 \pm 4 ft-lb)
Oil pan and oil pump	
Baffle plate bolt	11 ± 1 N⋅m (97 ± 9 in-lb)
Cover bolt	11 ± 1 N⋅m (97 ± 9 in-lb)
Drain plug	39 ± 5 N⋅m (29 ± 4 ft-lb)
Oil filter bracket bolt (M10)	41 ± 8 N⋅m (30 ± 6 ft-lb)
Oil filter bracket bolt (M8)	23 ± 3 N·m (17 ± 2 ft-lb)
Oil pan bolt	9 ± 3 N·m (52 ± 27 in-lb)
Oil pressure switch	10 ± 2 N⋅m (89 ± 18 in-lb)
Oil pump case bolt	14 ± 1 N⋅m (124 ± 9 in-lb)
Oil pump cover bolt	10 ± 2 N⋅m (89 ± 18 in-lb)
Oil screen bolt	19 ± 3 N·m (14 ± 2 ft-lb)
Oil screen stay bolt	14 ± 1 N·m (124 ± 9 in-lb)
Relief plug	44 ± 5 N·m (32 ± 4 ft-lb)
Piston and connecting rod	
Connecting rod cap nut	51 ± 1 N·m (38 ± 1 ft-lb)
Crankshaft and cylinder block	•
Bearing cap bolt	94 ± 4 N·m (69 ± 3 ft-lb)

ITEMS	SPECIFICATIONS
Drive plate bolt	74 ± 2 N·m (54 ± 1 ft-lb)
Oil seal case bolt	11 ± 1 N·m (97 ± 9 in-lb)
Rear plate bolt	11 ± 1 N·m (97 ± 9 in-lb)
Bracket	
Engine support bracket bolt (M12)	75 ± 10 N·m (55 ± 7 ft-lb)
Engine support bracket bolt (M10)	41 ± 8 N·m (30 ± 6 ft-lb)
Engine support bracket bolt (M8)	22 ± 4 N·m (16 ± 3 ft-lb)

GENERAL SPECIFICATIONS

M1113000200111

DESCRIPTIONS		SPECIFICATIONS	
Туре			60° V, OHV, SOHC
Number of cylind	lers		6
Combustion char	mber		Pentroof type
Total displaceme	ent cm ³ (cu in)		2,972 (181.4)
Cylinder bore mm (in)		91.1 (3.59)	
Piston stroke mm (in)		76.0 (2.99)	
Compression rat	io		8.9
Valve timing	Intake valve	Opens (BTDC)	19°
		Closes (ABDC)	45°
	Exhaust valve	Opens (BBDC)	49°
		Closes (ATDC)	15°
Lubrication syste	em	1	Pressure feed, full-flow filtration
Oil pump type			Trochoid type

SERVICE SPECIFICATIONS

M1113000300118

ITEMS		STANDARD VALUE	LIMIT
Timing belt			
Auto-tensioner rod lengtl	n mm (in)	3.8 – 4.5 (0.15 – 0.17)	_
Auto-tensioner rod protru	usion length mm (in)	12 (0.5)	-
Auto-tensioner rod pushe [when pushed with a force (22 – 44 lb)] mm (in)		1.0 (0.03) or less	-
Rocker arms and cams	haft		
Camshaft cam height mm (in)	Intake	37.71 (1.485)	Minimum 37.21 (1.465)
	Exhaust	37.14 (1.462)	Minimum 36.64 (1.443)
Camshaft journal outside diameter mm (in)		45 (1.8)	-
Cylinder head and valv	es		
Cylinder head flatness of gasket surface mm (in)		Less than 0.03 (0.001)	0.2 (0.007)

ITEMS		STANDARD VALUE	LIMIT
Cylinder head grinding limit of gasket surface mm (in) Total resurfacing depth of cylinder head and cylinder block		_	0.2 (0.007)
Cylinder head overall height mm (in)		120 (4.7)	_
Valve thickness of valve	Intake	1.0 (0.04)	Minimum 0.5 (0.02)
head (margin) mm (in)	Exhaust	1.2 (0.05)	Minimum 0.7 (0.03)
Valve overall height mm	Intake	112.30 (4.421)	Minimum 111.80 (4.402)
(in)	Exhaust	114.11 (4.493)	Minimum 113.61 (4.473)
Valve stem outside	Intake	6.0 (0.24)	_
diameter mm (in)	Exhaust	6.0 (0.24)	_
Valve stem to valve	Intake	0.02 - 0.05 (0.0008 - 0.0019)	0.10 (0.003)
guide clearance mm (in)	Exhaust	0.04 - 0.07 (0.0016 - 0.0027)	0.15 (0.005)
Valve face angle mm (in)		45° – 45.5°	_
Valve spring free length	mm (in)	51.0 (2.01)	50.0 (1.97)
Valve spring load/installed height N (lb) /mm (in)		267/44.2 (60.0/1.74)	_
Valve spring out-of-squareness		2° or less	4°
Valve seat valve contact	width mm (in)	0.9 – 1.3 (0.04 – 0.05)	_
Valve guide inside diame	eter mm (in)	6.0 (0.32)	_
Valve guide projection from cylinder head upper surface mm (in)		14 (0.6)	_
Valve stem projection mr	n (in)	49.30 (1.941)	49.80 (1.960)
Oversize rework dimensions of valve	0.05 oversize diameter	11.05 – 11.07 (0.4351 – 0.4358)	_
guide hole mm (in)	0.25 oversize diameter	11.25 – 11.27 (0.4429 – 0.4437)	_
	0.50 oversize diameter	11.50 – 11.52 (0.4528 – 0.4535)	_
Intake oversize rework dimensions of valve	0.3 oversize diameter	34.30 – 34.33 (1.3504 – 1.3515)	_
seat hole mm (in)	0.6 oversize diameter	34.60 – 34.63 (1.3623 – 1.3633)	_
Exhaust oversize rework dimensions of	0.3 oversize diameter	31.80 – 31.83 (1.2520 – 1.2531)	_
valve seat hole mm (in)	0.6 oversize diameter	32.10 – 32.13 (1.2638 – 1.2650)	_
Oil pan and oil pump	<u>I</u>	1	<u>I</u>
Oil pump tip clearance mm (in)		0.06 - 0.18 (0.003 - 0.007)	_
Oil pump side clearance mm (in)		0.04 - 0.10 (0.002 - 0.003)	_
Oil pump body clearance mm (in)		0.10 - 0.18 (0.004 - 0.007)	0.35 (0.013)
Oil pressure at curb idle [oil temperature is 75 to	,	80 (11.6) or more	_

ITEMS		STANDARD VALUE	LIMIT
Piston and connecting	rod		
Piston outside diameter mm (in)		91.1 (3.587)	_
Piston ring to ring	No.1	0.03 - 0.07 (0.0012 - 0.0027)	0.1 (0.003)
groove clearance mm (in)	No.2	0.02 - 0.06 (0.0008 - 0.0023)	0.1 (0.003)
Piston ring end gap mm	No.1	0.30 - 0.45 (0.012 - 0.017)	0.8 (0.03)
(in)	No.2	0.45 - 0.60 (0.018 - 0.023)	0.8 (0.03)
	Oil ring side rail	0.20 - 0.60 (0.008 - 0.023)	1.0 (0.03)
Piston pin outside diame	ter mm (in)	22.0 (0.87)	_
Piston pin press-in load N (lb) (room temperature)		7,350 – 17,200 (1,653 – 3,866)	_
Crankshaft pin oil clearance mm (in)		0.02 - 0.05 (0.0008 - 0.0019)	0.1 (0.003)
Connecting rod big end side clearance mm (in)		0.10 - 0.25 (0.003 - 0.009)	_
Crankshaft and cylinde	r block		
Crankshaft end play mm (in)		0.05 - 0.25 (0.002 - 0.009)	0.3 (0.01)
Crankshaft journal outside diameter mm (in)		60 (2.362)	-
Crankshaft pin outside diameter mm (in)		50 (1.969)	_
Crankshaft journal oil cle	arance mm (in)	0.02 - 0.04 (0.0008 - 0.0015)	0.1 (0.003)
Piston to cylinder clearance mm (in)		0.02 - 0.04 (0.0008 - 0.0015)	_
Cylinder block flatness of gasket surface mm (in)		0.05 (0.02)	0.1 (0.003)
Cylinder block grinding limit of gasket surface mm (in) total resurfacing depth of both cylinder head and cylinder block		_	0.2 (0.008)
Cylinder block overall height mm (in)		210.4 – 210.6 (8.283 – 8.291)	_
Cylinder bore inside diameter mm (in)		91.1 (3.587)	_
Cylindricality mm (in)		0.01 (0.0003)	_

SEALANTS AND ADHESIVES

M1113000500093

ITEMS	SPECIFIED SEALANT	QUANTITY
Engine coolant temperature sensor	3M™ AAD Part No. 8731 or equivalent	As required
Engine coolant temperature gauge unit	3M™ AAD Part No. 8672 or equivalent	As required
Oil pressure switch	3M™ AAD Part No. 8672 or equivalent	As required
Oil pump case	MITSUBISHI genuine part No. MD970389 or equivalent	As required
Oil pan	MITSUBISHI genuine part No. MD970389 or equivalent	As required
Oil seal case	MITSUBISHI genuine part No. MD970389 or equivalent	As required

NOTES