1

2

FUSIBLE LINK ①

RELAY BOX

⑱ 15A

0.85R-B

15 D-241

0.85R-B

②

·AUDIO SYSTEM
·AUTOMATIC AIR CONDITIONER
·BRAKE WARNING LAMP, FUEL FILTER WARNING LAMP, FUEL WARNING LAMP AND OIL PRESSURE WARNING LAMP
·CENTRE DISPLAY
·CHARGING SYSTEM
·CRUISE CONTROL SYSTEM
·DOOR AJAR WARNING BUZZER
·ENGINE CONTROL SYSTEM
·FRONT FOG LAMP
·GLOW SYSTEM
·HBB, EBD, ABS AND ASTC
·HEADLAMP
·HEADLAMP WASHER
·INVECS-II 5A/T
·METER AND GAUGE
·MMCS
·REAR FOG LAMP
·REAR SEAT ENTERTAINMENT SYSTEM
·REAR WIPER AND WASHER
·SEAT BELT WARNING BUZZER
·SPARE CONNECTOR (FOR ACCESSORY)
·SPARE CONNECTOR (FOR AUDIO)
·SPARE CONNECTOR (FOR REAR DISPLAY)
·SRS
·SUNROOF
·SUPER SELECT 4WD II SYSTEM
·TAIL LAMP, POSITION LAMP, LICENCE PLATE LAMP AND LIGHTING MONITOR BUZZER
·TURN-SIGNAL LAMP AND HAZARD WARNING LAMP
·VANITY MIRROR LAMP
·WINDSHIELD WIPER AND WASHER

IGNITION SWITCH (IG1)

(R-B) 4 D-401

<F>2L-B 6 D-403

J/B

② 7.5A 8 D-419

20

ETACS-ECU

POWER SOURCE

6

3 D-410

(B-W)

3 A

GND GND

56 D-420 3 D-419 58 67 51 72 73 D-420

B 1.25B (B)

11 D-405

<F>2B

<F>2B

17 16

FUSIBLE LINK ②

5R 1 D-240

5R 1 D-404

⑮ 15A

12 D-405

(GR-R) 127

J/C (4) D-34

85

(GR-R) (G-O)

<T> (BR-B) 6

<T> (R-G) 17

J/C (CAN1) D-03

1 12

<T> (LG) <T> (B-Y) W-R

1 9 6 14 16

DIAGNOSIS CONNECTOR D-127

4 5

B B

4

D-03
MU801516

D-34
Refer to J/C circuit

D-127
MU803797
FRONT SIDE

D-240
MU801405

D-241

D-419
J/B SIDE

D-420
(MU803766)

D-401
MU801857

D-403
MU801331

D-404
MU801403

D-405

D-410
MU801685

Wire colour code
B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
BR : Brown O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver

H9B08E14AC