


POWER DISTRIBUTION SYSTEM (Diesel-powered vehicles)
(CONTINUED)



Remark
The above circuit diagram shows the current flow at the ignition key position ACC, ON and BT combined. Be sure trace the appropriate circuit depending on the ignition key position.