


<Reference>

Glow Plug Energization Timing Chart




T<sub>1</sub>: Glow indicator lamp  
 T<sub>2</sub>: Glow plug relay drive time after ignition switch is turned ON  
 T<sub>3</sub>: Glow plug relay drive time after engine starts (afterglow)

NOTE  
 After glow time T<sub>3</sub> becomes longer as the engine coolant temperature drops.

DEN0063




GLOW CONTROL UNIT INSPECTION

120002539



Vehicles with EGR

Vehicles without EGR



DEN0821  
 00003260