

MULTI-PURPOSE FUSES

Power supply circuit		No.	Rated capacity (A)	Load circuit
Battery		1	20	Rear A/C control unit
Ignition switch	(IG2)	2	—	—
		3	10	DRL control unit, blower relay, rear heater relay and headlamp washer relay
		4	10	Radio and clock
	(ACC)	5	15	Remote control mirror, cigarette lighter and accessory socket relay
		Battery		6
Ignition switch	(IG2)	7	10	Over drive control relay, variable shock absorber control unit and ABS power relay
		8	10	Power window relay and heated seat
	(ACC)	9	15	Wiper and washer
		10	10	Horn and auto-cruise control unit
	(IG1)	11	10	Combination meter and motor antenna control unit
		12	10	Turn-signal lamp and hazard lamp
Battery		13	10	Rear heater blower motor
		14	15	Accessory socket
		15	—	—
		16	25	Blower motor
		17	15	Stop lamp
Ignition switch	(IG1)	18	15	Back-up lamp and rear differential lock control unit
Battery		19	10	Engine control unit, room lamp, map lamp, cargo space lamp, combination meter, clock, door lock control unit, radio, clock and auto-cruise control unit

(In junction block)

