

C-141

81 ANTENNA POWER ON  
82 AMP POWER ON

---

C-144

43 CAN-BOX DATA RX  
45 HFM SIGNAL (+)  
46 HFM SIGNAL (-)  
47 VIDEO2-IN  
48 VIDEO2-R  
49 SEIELD (VIDEO2-L/R)  
53 AUDIO REMOTE  
58 CAN-BOX DATA CLK  
59 CAN-BOX DATA TX  
63 SEIELD (VIDEO2-IN)  
64 VIDEO2-L  
65 VIDEO2 DETECT  
69 SEIELD (STEERING REMO)

---

C-143

21 BATTERY (+)  
24 PS-R Sift lever <M/T, TC-SST> or selector lever <A/T, CVT>: R position  
25 GND

---

C-142

2 SPEAKER RL (-)  
3 SPEAKER FL (-)  
6 AMP DATA  
7 SPEAKER FR (-)  
8 SPEAKER RR (-)  
9 MAIN GND  
10 ILLUMINATION (+)  
11 SPEAKER RL (+)  
12 SPEAKER FL (+)  
13 VSS  
14 ACCESSORY (+)  
15 SPEAKER FR (+)  
16 SPEAKER RR (+)  
17 BATTERY (+)