



C-104



C-106



C104

21	+12 Ign (Y)	31	
22	Wheel Int	32	Wheel Int
23	CAN	33	CAN
24		34	Ant Power (P)
25	Speaker Rear Right + (Y-R)	35	Speaker Rear Right - (Gr-R)
26	Speaker Front Right + (W-R)	36	Speaker Front Right - (B-R)
27	Speaker Rear Left + (Y-L)	37	Speaker Rear Left - (Gr-L)
28	Speaker Front Left + (W-L)	38	Speaker Front Left - (B-Y)
29	Dimmer ? (G-W)	39	
30	+12 Batt (R-W)	40	Ground (B)

C106

1		10	
2	Hand free ground	11	
3	Hand free audio	12	
4	AUX Right	13	AUX left
5	Ground for 6 and 15	14	AUX ground
6	Input form sattelite radio 1	15	Input form sattelite radio 2
7	CAN ampl	16	
8	To switch panel	17	CAN ampl
9	To switch panel	18	To switch panel